



marine engines

section 6

8210 series

workshop manual

Publication No. L32034003
Date 10 - 1991

IVECO *aifo*

The data contained in this publication may not have been updated following modifications carried out by the manufacturer, at any time, for technical or commercial reasons and also to conform to the requirements of the law in the various countries.

This publication supplies features and data together with the suitable methods for repair operations to be carried out on each single component of the engine. Following the supplied instructions and using the inherent specific fixtures, a correct repair procedure will be obtained in due time, protecting the operators from all possible accidents. Before starting any repair, be sure that all accident prevention devices are available and efficient. Therefore check and wear what indicated by the safety provision: protective glasses, helmet, gloves, safety shoes. Before use, check all work, lifting and transport equipment.

INDEX

Page

GENERAL	1
SEA WATER PUMP.....	3
FRESH WATER-SEA WATER HEAT EXCHANGER	4
FITTING TOLERANCES	5
FAULT - FINDING DIAGNOSIS	13
DISMANTLING THE ENGINE	20
ENGINE BLOCK	24
CRANKSHAFT	27
ENGINE FLYWHEEL RING GEAR REPLACEMENT.....	30
PISTON-CONNECTING ROD ASSEMBLY	30
PISTON RINGS	31
CONNECTING RODS	34
CAMSHAFT	38
VALVE SYSTEM CONTROL.....	39
CYLINDER HEADS	43
CYLINDER HEAD ASSEMBLY.....	47
ROCKER SHAFTS-PUSHRODS	48
LUBRICATION	50
COOLING SYSTEM	53
ENGINE ASSEMBLY	54
TIGHTENING TORQUE DATA.....	60
SPECIAL TOOLS	63

8210 SRM 36

INDEX	Page
GENERAL	2
SEA WATER PUMP.....	3
FRESH WATER-SEA WATER HEAT EXCHANGER	4
FITTING TOLERANCES	9
FAULT - FINDING DIAGNOSIS	13
DISMANTLING THE ENGINE	20
ENGINE BLOCK	24
CRANKSHAFT	27
ENGINE FLYWHEEL RING GEAR REPLACEMENT.....	30
PISTON-CONNECTING ROD ASSEMBLY	30
PISTON RINGS	31
CONNECTING RODS	34
CAMSHAFT	38
VALVE SYSTEM CONTROL.....	39
CYLINDER HEADS	40
CYLINDER HEAD ASSEMBLY.....	47
ROCKER SHAFTS-PUSHRODS	48
LUBRICATION	50
COOLING SYSTEM	53
ENGINE ASSEMBLY	54
TIGHTENING TORQUE DATA.....	60
SPECIAL TOOLS	63

ENGINE SPECIFICATIONS

Engine type 8210M22
 4 - stroke Diesel with direct injection
 Cylinders, number and arrangement..... 6, in line
 Bore x stroke 137 x 156 mm
 Displacement..... 13.8 l
 Compression ratio 16 : 1
 Net power at flywheel (*) :
 - Continuous duty 162 kW (220 CV)
 At 2200 rpm
 Engine rotation :
 (see from flywheel) CCW
 (*) Net rating at flywheel according to ISO 3046-1
 - Ambient reference conditions : 750 mmHg ; 25° C ;
 30 % relative humidity.

TIMING

Valve Timing :
 - Intake
 opens : before T.D.C..... 16°
 closes : after B.D.C. 52°
 - Exhaust
 opens : before B.D.C. 58°
 closes : after T.D.C. 18°
 Clearance between valve and rockers for
 timing checks mm
 Operating clearance between valves and rockers, cold
 engine :
 - intake 0.30 mm
 - exhaust 0.40 mm

FUEL SYSTEM

Rotary injection pump type PES 6P.
 Fixed injection pump delivery start advance 22° ± 1°
 Fuel injectors setting..... 200 + 8 bar
 Firing order 1 - 5 - 3 - 6 - 2 - 4

LUBRICATION

Minimum oil pressure :
 - at full throttle 4 - 5.5 kg/cm²
 - when idling 1.5 kg/cm²

COOLING SYSTEM

Cooling by dual water circuit :
 - Primary circuit (closed) by fresh water;
 - Secondary circuit (open) by sea water.

Water circulation is provided by a self priming pump featuring a neoprene impeller.

Complete sea water circuit is protected from corrosion by replaceable sacrificial anodes.

STARTING

By starter motor.

ELECTRIC SYSTEM

- Voltage 24 V
 - Self-regulated alternator 24 V, 30 A
 - Starting motor power 6.6 kW
 - Battery (optional) 2, each 190 Ah

MARINE GEAR

Available in different models for their overhauling see the specific manual of the manufacturer.

ENGINE SPECIFICATIONS

Engine type8210SRM36
 4 - stroke Diesel with direct injection
 Cylinders, number and arrangement.....6, in line
 Bore x stroke 137 x 156 mm
 Displacement..... 13.8 l
 Compression ratio..... 16 : 1
 Net power at flywheel (*) :
 - Light-duty commercial..... 265 kW (360 CV)
 At 1800 rpm
 Engine rotation :
 (see from flywheel) CCW

(*) Net rating at flywheel according to ISO 3046-1
 - Ambient reference conditions : 750 mmHg ; 25° C ;
 30 % relative humidity.

TIMING

Valve Timing :
 - Intake
 opens : before T.D.C..... 16 °
 closes : after B.D.C..... 40 °
 - Exhaust
 opens : before B.D.C. 58 °
 closes : after T.D.C. 18 °
 Clearance between valve and rockers for
 timing checks mm
 Operating clearance between valves and rockers, cold
 engine :
 - intake 0.30 mm
 - exhaust..... 0.40 mm

FUEL SYSTEM

In line injection pump type PES 6P.
 Fixed injection pump delivery start advance 22° ± 1°
 Fuel injectors setting..... 250 + 8 bar
 Firing order..... 1 - 5 - 3 - 6 - 2 - 4

TURBOCHARGING

The engine is turbocharged by turbocharger driven by the exhaust gases .

The turbocharger is lubricated with the engine oil under pressure.

LUBRICATION

Minimum oil pressure :

- at full throttle 4 kg/cm²
 - when idling 1.5 kg/cm²

COOLING SYSTEM

Cooling by dual water circuit :

- Primary circuit (closed) by fresh water;
 - Secondary circuit (open) by sea water.

Water circulation is provided by a self priming pump featuring a neoprene impeller.

Complete sea water circuit is protected from corrosion by replaceable sacrificial anodes.

STARTING

By starter motor.

ELECTRIC SYSTEM

- Voltage 24 V
 - Self-regulated alternator 28 V, 40 A
 - Starting motor power 6.6 kW
 - Battery (optional).....2, each 176 Ah

MARINE GEAR

Available in different models for their overhauling see the specific manual of the manufacturer.

SEA WATER PUMP

GENERALITIES

The sea water circulation for cooling the fresh water and the marine gear oil is ensured by a self-priming pump type neoprene impeller


INSTRUCTION FOR USE

Each time the engine is started, check that the sea water intake valve is open. Dry running of the pump would damage the impeller (1) in a very short time.

Under normal operating conditions of the engine check every 800 hours the state of the neoprene impeller, after removing first the cover

Make sure that it is free from cracks or excessive wear of the lobe.

If not replace it.



FRESH WATER-SEA WATER HEAT EXCHANGER

GENERALITIES

When the fresh water circulating in the engine reaches temperature values in excess of :

- 68 °C (8210 M22.)
- 74 °C (8210 SRM36.)

is conveyed under thermostatic control to the fresh water-sea water heat exchanger, where it is cooled and returned to circulation.


This heat exchanger consists essentially of a cast iron body with the fresh water circulation therein and a copper tube bundle containing the circulating sea water for cooling the fresh water.

MAINTENANCE

For ensuring the perfect efficiency of the fresh water-sea water heat exchanger it is necessary to clean periodically the tube bundle:

- Remove the tube bundle from the exchanger body and immerse it into a solution of water and anti-incrustator type "P3" or the like (*) which does not attack copper, brass, aluminium and tin.
- After the end of the reaction (indicated by effervescence) after about 15 to 20 minutes, rinse the tube bundle abundantly with running water for completely eliminating any residue of the solution and re-assemble the bundle into the exchanger body.

(*) When using solvents observe the prescriptions of the makers.



FITTING DATA

DESCRIPTION	mm
ENGINE BLOCK - CONNECTING RODS	
Cylinder sleeve bore dia. (fitted and machined) $\begin{cases} \text{Class A} \\ \text{Class B} \end{cases}$	$\begin{cases} 136.955 \text{ to } 136.990 \\ 136.990 \text{ to } 137.025 \end{cases}$
Outside standard cylinder sleeve bore dia.	143.020 to 143.040
Oversize on outside replacement cylinder bore dia.	0.25
Cylinder bore dia. in engine block	142.975 to 143.000
Sleeve interference fit in block	0.020 to 0.065
Sleeve length	281.5 to 282
Sleeve protrusion in block	- 0.02 to + 0.055
Camshaft bush housing bore dia:	
□ Front	68.515 to 68.550
□ Front intermediate	68.015 to 68.050
□ Rear intermediate	67.515 to 67.550
□ Rear	67.015 to 67.050
Crankshaft bearing housing bore dia.	107.976 to 108.001
Standard tappet housing bore dia.	34.010 to 34.045
Big end bore dia.	88.482 to 88.504
Small end bore dia.	52.849 to 52.894
Big end standard bearing thickness	1.826 to 1.835
Undersize bearing for replacement big end bore dia.	0.254-0.508-0.762-1.016
Small end bushing O.D.	53.010 to 53.061
Small end bushing fitted I.D.	48.019 to 48.035
Piston pin clearance in small end bushing	0.019 to 0.040
Small end bushing interference fit	0.116 to 0.212
Crankpin clearance in big end half bearings	0.077 to 0.139
Max connecting rod parallelism tolerance:	
□ At 125 mm from connecting rod stem	0.07
PISTONS - PINS - RINGS	
Piston dia. at right angles to pin bore:	
□ At 35 mm from base of skirt $\begin{cases} \text{Class A} \\ \text{Class B} \end{cases}$	$\begin{cases} 136.758 \text{ to } 136.782 \\ 136.793 \text{ to } 136.817 \end{cases}$
Piston pin bore dia. in piston	48.000 to 48.006
Piston pin dia.	47.995 to 48.000
Ring groove width in piston $\begin{cases} \text{1st Top groove (measured on bore} \\ \text{dia. of 134 mm)} \\ \text{2nd groove} \\ \text{3rd groove} \\ \text{4th groove} \end{cases}$	$\begin{cases} 3.720 \text{ to } 3.750 \\ 3.050 \text{ to } 3.070 \\ 3.050 \text{ to } 3.070 \\ 5.530 \text{ to } 5.550 \end{cases}$

DESCRIPTION	mm
Ring thickness:	
□ Top compression ring, double taper, chromium plated (measured at 1.5 mm from dia. 134 mm)	3.575 to 3.595
□ 2nd compression ring, straight	2.978 to 2.990
□ 3rd compression ring, straight	2.978 to 2.990
□ 4th oil scraper ring, slotted, spring-loaded	5.478 to 5.490
Piston fit in sleeve (measured on standard axis to pin, 35 mm from piston base)	
□ Clearance	0.173 to 0.232
Piston pin clearance in piston	0 to 0.011
Ring clearance in piston (vertical):	
□ Top compression ring, double taper	0.125 to 0.175
□ 2nd compression ring, straight	0.060 to 0.092
□ 3rd compression ring, straight	0.060 to 0.092
□ 4th oil scraper ring	0.040 to 0.072
Ring gap in sleeve:	
□ Top compression ring, double taper	0.60 to 0.80
□ 2nd compression ring, straight	0.50 to 0.70
□ 3rd compression ring, straight	0.50 to 0.70
□ 4th oil scraper ring	0.40 to 0.60
Piston weight	3325 to 3370 g
CRANKSHAFT - BEARINGS	
Main journal dia.	102.874 to 102.901
Main bearing housing bore dia.	107.976 to 108.001
Standard main bearing thickness	2.487 to 2.496
Main bearing undersize range	0.254-0.508-0.762-1.016
Crankpin dia.	84.708 to 84.735
Main journal in bearing:	
□ Clearance	0.085 to 0.148
Centre main journal length between thrust washers	65.00 to 65.10
Centre main bearing housing width over thrust washer faces	60.150 to 60.200
Centre main bearing housing plus thrust washer width	64.780 to 64.930
Standard thrust washer thickness	2.311 to 2.362
Thrust washer oversize range (0.127 mm)	2.438 to 2.489
Between shaft and centre main bearing with thrust washers:	
□ Clearance	0.070 to 0.320
Max. permissible misalignment on main journals (total gauge reading)	0.05
Max. permissible misalignment between crankpins and main journals	± 0.25
Max. main journal ovalization after grinding	0.008
Max. main journal and crankpin taper after grinding	0.012

DESCRIPTION	mm
CYLINDER HEAD	
Valve guide housing bore in head	17.977 to 17.995
Valve guide O.D.	18.005 to 18.030
Valve guide oversize	0.04-0.20-0.24
Valve guide fitted I.D.	11.025 to 11.045
Valve guide interference fit in head	0.010 to 0.053
Valve stem dia.	10.982 to 11.000
Valve stem and guide interference: □ Clearance	0.025 to 0.063
Valve seat angle $\begin{cases} \text{inlet} \\ \text{exhaust} \end{cases}$	$45^\circ \pm 5'$ $45^\circ \pm 5'$
Valve face angle $\begin{cases} \text{inlet} \\ \text{exhaust} \end{cases}$	$45^\circ \pm 5'$ $45^\circ \pm 5'$
Max. valve stem distortion over one complete revolution with dial gauge stylus in midstem position	0.04
Valve seat width	~ 4.3
Valve seat O.D. $\begin{cases} \text{inlet} \\ \text{exhaust} \end{cases}$	61.080 to 61.105 51.080 to 51.105
Valve seat I.D. $\begin{cases} \text{inlet} \\ \text{exhaust} \end{cases}$	60.900 to 60.930 50.900 to 50.930
Valve seat interference fit in head $\begin{cases} \text{inlet} \\ \text{exhaust} \end{cases}$	0.150 to 0.205
Valve fitted depth in cylinder head $\begin{cases} \text{inlet} \\ \text{exhaust} \end{cases}$	1.4 to 1.8 1.3 to 1.9
Nozzle protrusion over cylinder head	1.5 to 2
VALVE SPRINGS	
Outside free spring height	~ 84.7
Inside free spring height	~ 75.2
Outside spring height under 41 ± 2 kg	58.1 ± 0.5
Inside spring height under 15 ± 0.65 kg	52.6
VALVE GEAR	
Camshaft bushing housing fitted in engine block: □ Front □ Front intermediate □ Rear intermediate □ Rear	68.515 to 68.550 68.015 to 68.050 67.515 to 67.550 67.015 to 67.050
Bushing interference fit in engine block	There should be always interference
Bushing fitted I.D. after reaming: □ Front □ Front intermediate □ Rear intermediate □ Rear	62.599 to 62.660 62.099 to 62.160 61.600 to 61.661 61.100 to 61.160

DESCRIPTION	mm
Camshaft journal dia.:	
□ Front	62.500 to 62.530
□ Front intermediate	62.000 to 62.030
□ Rear intermediate	61.500 to 61.530
□ Rear	61.000 to 61.030
Camshaft journal and bushing fit:	
□ Clearance { Front	0.069 to 0.160
Front intermediate	0.069 to 0.160
Rear intermediate	0.070 to 0.161
Rear	0.070 to 0.160
Cam lift - intake and exhaust	8
Tappet housing bore dia.	34.010 to 34.045
«Crowned» tappet O.D. { Measured at top and base	33.840 to 33.860
Measured at middle	33.920 to 33.940
Oversize spare tappet	0.10-0.20-0.30
Tappet interference fit in housing (with reference to max. tappet dia.):	
□ Clearance	0.070 to 0.125
Rocker axle bore dia.	25.000 to 25.033
Rocker shaft dia.	24.979 to 25.000
Rocker shaft interference fit:	
□ Clearance	≤ 0.054
Rocker bushing seat dia.	28.939 to 28.972
Rocker bushing O.D.	29.032 to 29.070
Rocket bushing I.D. (with fitted bushing)	25.020 to 25.041
Rocker bushing interference fit in shaft:	
□ Clearance	0.020 to 0.062
MAIN AND SCAVENGE OIL PUMPS	
By-pass valve opening calibration pressure	$1 \pm 0.1 \text{ kg/cm}^2$
Oil pressure relief valve opening start	$5 \pm 0.25 \text{ kg/cm}^2$
INJECTION PUMP	
Distance between flange and pump body	13.5
Camshaft end float	0.02 to 0.06
Spider pin end float	~ 1
Distance between knuckle pin and speed governor case	35
Idle spring operation range	2.0 ± 0.2
Counterweights end float (for checking silentblock preloading)	0.05 to 0.1

FITTING DATA

DESCRIPTION	mm
ENGINE BLOCK - CONNECTING RODS	
Cylinder sleeve bore dia. (fitted and machined) { Class A Class B	136.955 to 136.990 136.990 to 137.025
Outside normal cylinder sleeve bore dia.	143.020 to 143.040
Oversize on outside replacement cylinder bore dia.	0.05-0.25
Cylinder bore dia. in engine block	142.975 to 143.000
Sleeve interference fit in block	0.020 to 0.065
Sleeve length	281.5 to 282
Sleeve protrusion in block	-0.02 to +0.045
Camshaft bush housing bore dia:	
□ Front	68.515 to 68.550
□ Front intermediate	68.015 to 68.050
□ Rear intermediate	67.515 to 67.550
□ Rear	67.015 to 67.050
Crankshaft bearing housing bore dia.	107.976 to 108.001
Normal tappet housing bore dia.	34.009 to 34.034
Big end bore dia.	88.482 to 88.504
Small end bore dia.	54.852 to 54.899
Big end bearing thickness	1.826 to 1.835
Undersize bearing for replacement big end bore dia.	0.254-0.508-0.762-1.016
Small end bushing O.D.	55.015 to 55.065
Small end bushing fitted I.D.	50.019 to 50.035
Piston pin clearance in small end bushing	0.019 to 0.040
Small end bushing interference fit	0.117 to 0.215
Crankpin clearance in big end half bearings	0.077 to 0.139
Max. connecting rod parallelism tolerance:	
□ At 125 mm from connecting rod stem.	0.07
PISTONS - PINS - RINGS	
Piston dia. at right angles to pin bore:	
□ At 33 mm from base of skirt { Class A Class B	136.813 to 136.827 136.848 to 136.862
Piston pin bore dia. in piston	50.000 to 50.006
Piston pin dia.	49.995 to 50.000
1st Top groove (measured on bore dia. of 134 mm)	
2nd groove	
3rd groove	
Ring groove width in piston	3.720 to 3.750 3.070 to 3.090 5.530 to 5.550

DESCRIPTION	mm
Ring thickness:	
□ Top compression ring, double taper, chromium plated (measured at 1.5 mm from dia. 3.575 to 3.595 137 mm)	
□ 2nd compression ring, straight	2.978 to 2.990
□ 3rd oil scraper ring, slotted, spring-loaded	5.478 to 5.490
Piston fit in sleeve (measured on normal axis to pin, 33 mm from piston base):	
□ Clearance	0.128 to 0.177
Piston pin clearance in piston	0 to 0.011
Ring clearance in piston (vertical):	
□ Top compression ring, double taper	0.122 to 0.163
□ 2nd compression ring, straight	0.080 to 0.112
□ 3rd oil scraper ring	0.040 to 0.072
Ring gap in sleeve:	
□ Top compression ring, double taper	0.50 to 0.75
□ 2nd compression ring, straight	0.50 to 0.75
□ 3rd oil scraper ring	0.40 to 0.60
CRANKSHAFT - BEARINGS	
Main journal dia.	102.879 to 102.901
Main bearing housing bore dia.	107.976 to 108.001
Main bearing thickness	2.487 to 2.496
Main bearing undersize range	0.254-0.508-0.762-1.016
Crankpin dia.	84.713 to 84.735
Main journal in bearing:	
□ Clearance	
Centre main journal length between thrust washers	65.00 to 65.10
Centre main bearing housing width over thrust washer faces	60.150 to 60.200
Centre main bearing housing plus thrust washer width	64.772 to 64.924
Standard thrust washer thickness	2.311 to 2.362
Thrust washer oversize range	0.127
Between shaft and centre main bearing with thrust washers:	
□ Clearance	0.076 to 0.328
Max. permissible misalignment on main journals (total gauge reading)	0.05
Max. permissible misalignment between crankpins and main journals	±0.25
Max. main journal ovalization after grinding	0.008
Max. main journal and crankpin taper after grinding	0.012

DESCRIPTION	mm
CYLINDER HEAD	
Valve guide housing bore in head	17.977 to 17.995
Valve guide O.D.	18.005 to 18.030
Valve guide oversize	0.04-0.20-0.24
Valve guide fitted I.D.	11.025 to 11.045
Valve guide interference fit in head	0.010 to 0.053
Valve stem dia.	10.982 to 11.000
Valve stem and guide interference: □ Clearance	0.025 to 0.063
Valve seat angle { inlet exhaust	60° ± 5' 45° ± 5'
Valve face angle { inlet exhaust	60°30' + 5' 45°30' + 5'
Max. valve stem distortion over one complete revolution with dial gauge stylus in midstem position	0.04
Valve seat width	4.3 approx.
Valve seat O.D. { inlet exhaust	59.080 to 59.105 51.075 to 51.090
Valve seat I.D. { inlet exhaust	58.900 to 58.930 50.900 to 50.930
Valve seat interference fit in head { inlet exhaust	0.150 to 0.205 0.145 to 0.190
Valve fitted depth in cylinder head { inlet exhaust	1.4 to 1.8 1.3 to 1.9
Nozzle protrusion over cylinder head	1.5 to 2
VALVE SPRINGS	
Outside free spring height	~ 90.5
Inside free spring height	~ 83.1
Outside spring height under 50 ± 2 kg	58.1 ± 0.5
Inside spring height under 21.2 ± 0.65 kg	52.6
VALVE GEAR	
Camshaft bushing housing fitted in engine block:	
□ Front	68.515 to 68.550
□ Front intermediate	68.015 to 68.050
□ Rear intermediate	67.515 to 67.550
□ Rear	67.015 to 67.050
Bushing interference fit in engine block	There should be always interference
Bushing fitted I.D. after reaming:	
□ Front	62.559 to 62.660
□ Front intermediate	62.099 to 62.120
□ Rear intermediate	61.600 to 61.661
□ Rear	61.100 to 61.160

DESCRIPTION	mm
Camshaft journal dia.:	
□ Front	62.500 to 62.530
□ Front intermediate	62.000 to 62.030
□ Rear intermediate	61.500 to 61.530
□ Rear	61.000 to 61.030
Camshaft journal and bushing fit:	
□ Clearance { Front	0.069 to 0.160
Front intermediate	0.069 to 0.160
Rear intermediate	0.070 to 0.161
Rear	0.070 to 0.160
Cam lift - { intake	7.921
exhaust	8
Tappet housing bore dia.	34.009 to 34.034
"Crowned" tappet O.D. { Measured at top and base	33.888 to 33.863
Measured at middle	33.920 to 33.940
Oversize spare tappet	0.10-0.20-0.30
Tappet interference fit in housing (with reference to max. tappet dia.):	
□ Clearance	0.069 to 0.114
Rocker axle bore dia.	25.000 to 25.033
Rocker shaft dia.	24.979 to 25.000
Rocker shaft interference fit:	
□ Clearance	≤0.054
Rocker bushing seat dia.	28.939 to 28.972
Rocker bushing O.D.	29.030 to 29.060
Rocker bushing I.D. (with fitted bushing)	25.020 to 25.041
Rocker bushing interference fit in shaft:	
□ Clearance	0.020 to 0.062
OIL PUMP	
Drive shaft dia. on rear cover	25.910 to 25.940
Bushing I.D. (after fitting)	20.040 to 20.061
Gear shaft O.D.	19.987 to 20.000
Driven gear bushing seat dia.	22.910 to 22.940
Driven gear bushing O.D.	22.979 to 23.000
Bushing I.D. (after fitting)	20.020 to 20.053
Clearance between driving gear shaft and bushing	0.040 to 0.074
Clearance between driven gear shaft and bushing	0.020 to 0.060
Oil pressure relief valve seat dia.	17.016 to 17.043
Oil pressure relief valve dia.	16.982 to 17.000
Relief valve interference fit in seat	0.016 to 0.061
Calibration pressure for by pass valve (kg/cm ²)	1 ± 0.1
Oil pressure relief valve opening start (kg/cm ²)	5.5 to 6

FAULT-FINDING DIAGNOSIS

TROUBLE	POSSIBLE CAUSE	REMEDY
The engine does not start	Battery charged partially.	Check batteries and charge them. If necessary, replace them.
	Battery terminal connections corroded or loose.	Clean, check and tighten nuts on battery terminals. Replace cable terminals and nuts, if badly corroded.
	Incorrect timing of injection pump.	Check and carry out injection pump timing.
	Deposits or water in fuel lines.	Detach pipes and clean them with air. Disassemble and clean injection pump. Dry fuel tank and refuel.
	Insufficient fuel reserve.	Refuel.
	Defective fuel pump.	Overhaul pump or change it.
	Air bubbles in fuel lines or in injection pump.	Check pipes and fuel feed pump to detect the reasons of air presence; bleed air from injection pump unscrewing the relevant plug and manually operating fuel feed pump.
	Defective starter.	Repair or replace starter.
The engine syops	Too low idling.	Adjust idle speed by adjusting screw.
	Uneven delivery of injection pump.	Adjust delivery. If broken, replace pumping element spring. Replace tappets plunger and barrel, if seized or not sealing.
	Foreign matter or water in fuel pipings.	Detach pipes and clean with air. Disassemble and clean injection pump. Clean fuel tank and refuel.
	Fuel filters clogged.	Remove filter elements and replace them, if necessary.
	Abnormal clearance between valves and valve rockers.	Adjust clearance.
	Valves burnt, corroded or cracked.	Replace valves.
	Air in fuel feed or injection systems.	Check pipes for possible cracks; check for loose connectors. Replace worn parts, then bleed air from pipes and proceed to deaerate injection pump and fuel filter unscrewing the relevant plugs and operating the fuel feed pump manually.
	Fuel filter and fuel feed pump valves clogged.	Replace fuel filter and overhaul fuel feed pump valves.
	Injection pump controls broken.	Replace defective parts and check pump timing.
The engine warms up excessively	Defective water pump.	Check clearance between impeller blades and pump casing. Overhaul the assembly and replace gasket.
	Thermostat failure.	Valve stem jamming in guide.

TROUBLE	POSSIBLE CAUSE	REMEDY
The engine warms up excessively	Scale in water passages in engine block and cylinder head.	Wash thoroughly in compliance with directions given for the type of scale remover used.
	Insufficient tension of water pump belt.	Check and adjust belt tensions.
	Incorrect engine timing.	Check timing and proceed to correct timing.
	Incorrect injection pump calibration (upwards or downwards).	On test bed correct pump delivery so that injection has the prescribed delivery.
	Air cleaner clogged.	Clean air cleaner and inherent system.
The engine is under power and its operation is uneven	Incorrect timing of injection pump.	Check pump timing and correct it.
	Excessive wear in plungers and barrels of injection pump.	Overhaul injection pump and replace worn-out parts.
	Incorrect calibration of speed governor.	Check governor calibration and again calibrate it, if necessary.
	Injector nozzles clogged or incorrect injector operations.	Clean nozzle holes with suitable tool and totally overhaul injectors.
	Foreign matter or water in injection feed system.	Thoroughly clean and refill with new fuel.
	Defective fuel feed pump.	Disassemble pump, and, if necessary, replace pump components.
	Incorrect clearance between valves and rockers.	Check clearance and proceed to a correct adjustment.
	Low compression.	With tool 99395682 check compression pressure at T.D.C.. If this is less than 20 kg/cm ² , overhaul the engine.
	Defective turbocharger.	Overhaul the assembly or replace it.
	Air cleaner clogged.	Clean air cleaner and inherent system.
The engine knocks abnormally	Incorrect adjustment of injection pump peak capscrew or of control rod stop.	Adjust stops correctly.
	Incorrect injector operations.	Check that nozzle pin does not cause resistance and calibration is of prescribed value.
	Fuel lines clogged.	Remove pipes; clean them and replace those which are damaged or clogged.

TROUBLE	POSSIBLE CAUSE	REMEDY
The engine knocks abnormally	Incorrect injection pump timing.	Correct pump timing so that injection takes place according to the prescribed advance angles.
	Crankshaft knocks because of excessive clearance of one or more main bearings or of high thrust clearance.	Recondition crankshaft journals and mount undersize bearings. Replace thrust washer halves with oversized ones.
	Crankshaft unbalanced.	Check shaft alignment; if necessary correct as required and check balance.
	Flywheel capscrew loose.	Replace loose screws and tighten to the prescribed torque value.
	Connecting rods out-of-alignment.	Straighten connecting rods under a hydraulic press, and check parallelism.
	Piston knocks due to slap.	Replace cylinder sleeves and pistons.
	Noisy piston pins due to excessive clearance in piston and in connecting rod bushing. Loose bushings in connecting rod seat.	Replace piston pin with an oversize one and adjust piston hubs and connecting rod bushings. Replace bushings with new ones.
	Tapping due to noisy valve system.	Adjust clearance between valves and rockers and check if there are broken springs or excessive clearance between stems and guides, or tappets and seats.
The engine smokes abnormally 1) Black or dark grey smoke:	Excessive pump delivery.	Detach pump and adjust delivery according to the data of calibration table.
	Injection pump retarded excessively.	Correct timing.
	Injection pump excessively advanced.	Correct timing.
	Nozzle holes (or some of them) partially or totally clogged.	Replace injectors with a set of new injectors, or clean and recondition the original ones with suitable fixtures.
	Air cleaner clogged or worn-out.	Clean or replace filter element.
	Nozzle pin intermittently locked in open position.	Check injectors, check for possible locked pins, broken springs, too low calibration.
	Governor adjustment over max. stated.	Bench adjust governor, according to table data.
	Nozzle sprays are sent to the head because of incorrect injector assembly.	Check nozzle protrusion as to head face.
	Excessive lift of injector pin due to abnormal wear.	Replace affected nozzle.
	Engine compression loss due to: — Piston rings stuck. — Cylinder sleeve worn-out. — Valves worn-out or adjusted incorrectly.	Overhaul engine or repair concerned parts.

TROUBLE	POSSIBLE CAUSE	REMEDY
1) Dark grey or black smoke:	Incorrect type of injector, or injectors of different types or uncalibrated.	Replace injectors or calibrate them.
	Injection pipes of inadequate inside bore, pipe ends squashed because of repeated refitting.	Check conditions of ends and connectors. Replace where necessary.
2) Blue, grey/blue, or clear grey smoke	Excessive injection delay.	Correct pump timing.
	Injector needles blocked or defective injectors.	Check for blocked needles or broken springs.
	Oil seeping through piston rings due to stuck rings or to wear of sleeve walls.	Overhaul engine.
	Engine oil seeping through intake valve guides, due to wear of valve stems or guides.	Recondition cylinder head
	Engine too cold (thermostat missing or not present).	Replace thermostat.
The engine does not stop	Governor broken.	Unscrew the joint connecting fuel supply, then repair as necessary.
	Seizure of flow pushrod.	Unscrew the joint connecting fuel supply and repair as required.
	Hard pushrod motion.	Clean pushrod seat, and check that malfunction is not due to careless mounting of rod.
	Governor parts cause resistance.	Free of governor sleeve and from control level.
	Excessive clearance between the various governor parts.	Remove all clearances, only leaving minimum tolerances; in case replace worn-out parts.
Stepless change of max. speed (engine not loaded)	Governor springs too weak, causing an excessive sensitivity from governor.	Replace governor springs.
	Excessive clearance between the various parts transmitting control to pump.	Adjust all clearances among the various parts transmitting control (be sure that pushrod stroke is exactly as prescribed).
The pump does not deliver fuel	Foreign matter in pipes.	Clean thoroughly.
	Dirty fuel filters.	Clean thoroughly.
	Squashed pipes.	Replace pipes or, if possible repair them (the low pressure ones).
	Air in injection pump.	Deaerate pump.


TROUBLE	POSSIBLE CAUSE	REMEDY
The pump does deliver fuel	Plunger tappets may be seized.	Remove part and repair it (if failure is minor); if necessary, replace it.
	Plunger seized.	Change defective pumping element, as barrels and piston are not interchangeable.
	Delivery valve seized.	If failure is only due to foreign matter, clean valve and slightly regrind taper faces with an emery cloth; if reasons are different, replace pair valve holder - valve which are not interchangeable from each other.
The pump does not deliver enough fuel	Imperfect seal unions.	Be sure that fuel feeding pipe nut washers are not broken or deformed; then tighten joints very carefully.
	Imperfect seal in delivery valves of some elements.	Replace their pair valve - tube holder.
	Pumping elements worn-out.	Replace pumping elements.
The pump feeds abnormally	Air bubbles in fuel feed pump.	Deaerate fuel feed pump.
	Plunger return spring broken.	Replace spring.
	The plunger is about to seize.	Thoroughly clean plunger and its cylinder.
	Tappet pin worn-out.	Replace tappet.
Injection start faulty timed	Uneven delivery start.	Adjust delivery start replacing adjusting shims.
	Eccentric damaged.	Replace camshaft, using the stroboscopic check method.
The control rod shakes	Vibration due to high pump stress.	Check the efficiency of spring small blocks of adjusting device.
	Critical engine rpm.	Check the efficiency of spring small blocks of adjusting device.
INJECTORS The injector drips	Nozzle and needle valve (pin) are not sealed.	Thoroughly clean nozzle, if the trouble is due to foreign matter preventing normal operation; otherwise replace the nozzle valve pair.
Too high injection pressure	Incorrect injector calibration.	Calibrate injector with the greatest care.
	Valve seized inside spray nozzle.	Replace nozzle-valve pair.
	Adjusting spring too strong.	Replace spring with a more suitable one.
Fuel seeps from injector unions	The upper air bleeder plug is not tightened.	Tighten it.
	Nozzle check nut not tightened.	Tighten it.
Abnormal jet	Nozzle holes clogged by carbon deposits.	Clean nozzle holes with the suitable tool and steel wire of smaller diameter than holes. Then clean the whole nozzle.
	Holes deformed due to wear.	Replace nozzle-valve pair.

TROUBLE	POSSIBLE CAUSE	REMEDY
INJECTION PUMP		
Injection pump Difficult starting	Electromagnet for excess fuel device.	Check electric contacts on control button and on that same electromagnet.
	Air in fuel feed system.	Deaerate system until only diesel oil comes out from filter drain screw.
	Fuel filters clogged.	Replace filters, clean the filter corresponding to hand primer.
	Injectors with nozzles seized or clogged.	Check injectors; overhaul or replace nozzle; proceed to calibrate.
	Incorrect pump keying on engine.	Check if the static keying of injection pump on engine is correct.
	Starting delivery not complying with calibration table.	Place injection pump on test bed and verify excess fuel delivery.
Abnormal idling		
Abnormal idling	Injector uncalibrated or nozzles seized or clogged.	Check injectors; overhaul or replace nozzles; proceed to calibrate.
	Speed governor.	On test bed check the correct setting up and operation of speed governor.
	Unbalanced delivery.	Check and adjust at test bench.
Low efficiency		
Low efficiency	Fuel filters clogged.	Replace filters, clean filter oil hand primer and on suction pump reservoir.
	Air cleaner dirty.	Through the pilot lamp in the cab, check if the cartridge is clogged; if necessary, clean it or replace it.
	Injector uncalibrated or nozzles seized or clogged.	Check injectors, overhaul or replace nozzles; proceed to calibrate.
	Wrong pump keying on engine.	Check if the static keying of injection pump on engine meets the calibration table.
	Injection pump has insufficient fuel inlet.	Detach injection pump from engine and verify calibration at test bed.
	LDA device.	Be sure that the diaphragm has no holes, that the control spring is adequate and with a correct load (test bench checking). Verify that the turbocharger compressor wheel can rotate freely and the tabs have no failure marks. Check for adequate pressure inside intake manifold according to engine rpm at full load.

TROUBLE	POSSIBLE CAUSE	REMEDY
Excessive exhaust smoke with cold engine	Wrong injection pump keying on engine.	Check the static keying of injection pump on engine.
	Injector uncalibrated or nozzles seized or clogged.	Check injectors, overhaul or replace nozzles, proceed to calibrate.
	Insufficient compression pressure.	Check with motometer.
Excessive exhaust smokes (black) with engine under load	Excessive fuel delivery to engine.	Check max. pump delivery at test bench.
	Low air induction.	Check air cleaner through its suitable inspection hole.
	Wrong injection pump timing on engine.	Check the static timing of injection pump on engine.
	Injectors uncalibrated, or nozzles seized or clogged.	Check injectors, overhaul or replace nozzles, proceed to calibrate.
Excessive fuel consumption	Fuel leakages.	Check pipes and joints.
	Dirty air cleaner.	Through the pilot lamp in the cab check if the cartridge is clogged; if necessary, clean it or replace it.
	Injectors uncalibrated, or nozzle seized or clogged.	Check injectors, overhaul or replace nozzles, proceed to calibrate.
	Injection pump excessively uncalibrated.	Check and adjust injection pump at test bench.
	Abnormal operation of L.D.A. device.	Check and adjust at test bench.
	Incorrect pump keying on engine.	Check static pump keying on engine.

DISMANTLING THE ENGINE


FIGURE 14



23432

After removing the heat exchanger on one side and the turbocharger oil return pipe on the opposite side, fit brackets 99361015 (2) and 99361014 (1). Then place the engine on revolving stand 99322230 (3).


FIGURE 15



23433

Remove starter and also clutch, if not yet detached. Remove turbocharger (1) and pipings (2-3-4).


FIGURE 16



23434

Remove LDA device air line (1), fuel delivery and return lines (2) from injectors. Remove fuel delivery lines and draw out heat shield (3).


FIGURE 17



23435

Take off the exhaust manifold (1) and the fuel filter (4). Detach line (2) conveying water to cylinder heads. Disconnect oil return line (3).


FIGURE 18



23436

Using tool 99365136 (1) remove injection pump (2) by disconnecting it from the control shaft (3). Remove line (4) conveying water to block.


FIGURE 19



23437

Remove air conveyor (3) and intake manifold (1). Disconnect water outlet line (2) from cylinder head.

FIGURE 20




Remove the oil breather (4) together with its line. Take off compressor head cooling water line (1). Disconnect pipe (5). Remove oil dipstick (2).

FIGURE 21


Take off the viscostatic fan assembly and position it vertically. Loosen tensioner and remove water pump belts. Withdraw the alternator.

FIGURE 22




Loosen screws (3) and remove pulley (2). Withdraw damper and then water pump (1).

FIGURE 23




Fit tool 99360351 (1) to flywheel (2), then almost totally slacken flywheel hub check nut (3 figure 24). This protects the operator from possible sudden hub release during withdrawing.

FIGURE 24




Fit puller 99340032 with relevant brackets to crankshaft damper hub (2), position clamp (6) and with hydraulic unit 99341033 (4) and hydraulic pump 99341034 (1) extract damper hub (2).

FIGURE 25




Remove rocker covers (1).
Take off clamp brackets (2) and draw out injectors (3).

FIGURE 26




Loosen support nuts (1) and withdraw the complete rocker shafts (2).
Remove valve stem caps (3) and withdraw rocker pushrods (4).

FIGURE 27




Loosen bolts and using a hoist and tool 99360502 (1) remove cylinder heads (2) and gaskets (3).

FIGURE 28




With suitable pliers (1) take off tappets (2).

FIGURE 29




Rotate the engine by 180°, unscrew oil sump bolts (1) and remove it.
Remove front timing cover (2).

FIGURE 30




Remove injection pump driving gear (4) and its support.
Take off camshaft driving gear (3), withdraw driving gear (2) with relevant support.
Remove gear system lubrication line (1).

FIGURE 31




Remove oil delivery lines (4-5).
Take off suction strainer (1). Loosen screws (3) and withdraw oil pump (2).

FIGURE 32



Loosen nuts (1) securing connecting rod caps (2). Remove caps and half-bearings.


FIGURE 33



Rotate engine and position it vertically.
Withdraw cylinder sleeves (2) and piston-connecting rod assemblies (1).


NOTE - If connecting rods and connecting rod caps are not numbered, stamp the number of the relevant cylinder.

FIGURE 34




Again position engine horizontally.
Remove capscrews (1). Take off tool 99360351 (2) and withdraw engine flywheel (3).

FIGURE 35




Unscrew capscrew (3) and remove rear support (2). Unscrew capscrew and remove main bearing caps (1).

FIGURE 36



Using a hoist and tool 99360500 (1) lift and remove crankshaft (2).
Take off main half-bearings (3).


FIGURE 37



Rotate engine and position it vertically. Position tool 99360711 (2) and withdraw cylinder sleeves (1). To position plate (3) remove oil nozzles.

NOTE - If cylinder sleeves cannot be withdrawn with tool (2) owing to excessive interference, use hydraulic device 99305007.

FIGURE 38



Again position engine horizontally. Unscrew bolts (3) securing thrust plate (2) and take off camshaft (1). Withdraw camshaft support bushings using a suitable driver. Place a pair of rings and lift engine block with a hoist; then remove front end plate. This plate is to be removed only to prevent deterioration during engine block handling and washing.


ENGINE BLOCK

After engine disassembly, clean engine block thoroughly.

CHECKS AND MEASUREMENTS


Check cylinder sleeve surface for traces of seizure, scoring, excessive ovalization, taper and wear.

FIGURE 39




NOTE - To define the class it pertains to (A or B), never measure cylinder sleeve internally (with the component free) because it is easily distortable.

FIGURE 40



To check cylinder sleeve bore (4) for ovalization, taper and wear, use gauge 99395687 (2) equipped with a dial gauge reset with micrometer (2, fig. 39) having a diameter of 137 mm.

FIGURE 41



2209


- 1 MISURAZIONE = 1st MEASUREMENT
 2 MISURAZIONE = 2nd MEASUREMENT
 3 MISURAZIONE = 3rd MEASUREMENT

Diagram for checking cylinder sleeve diameters.

Measurements must be performed for each cylinder at three different sleeve levels on two planes at right angles, that is, one parallel to longitudinal centre line (a), and one perpendicular to that same centre line (b). If excessive ovality or taper is found, replace cylinder sleeves using tool 99360711 (figure 43).

NOTE - Since the inside sleeve surface is treated with liquid nitriding, no grinding, lapping or dressing is allowed. If necessary, the sleeves can be removed and installed several times in different position without impairing their conditions.


FIGURE 42



2210

O.D. value of a standard cylinder sleeve, and I.D. of sleeve lining.

FIGURE 43




Before fitting the new cylinder sleeves, check housing diameters on engine block: they should be of 142.975 to 143.000 mm.

In case of an ovality over 0.10 mm on engine block, bore housing 143.225 to 143.250 mm and use sleeves oversized by 0.25 mm. Cylinder sleeves fit in their housings is 0.020 to 0.065 mm.

This type of fit requires a fitting load (after the sleeve has been inserted 100 mm in its housing) of 400 kg or more, namely 1.5 kgm. To do so, use tool 99360711 (1) and torque wrench (2). The required load for sleeve fitting should never exceed 4500 kg (15 kgm). Use tool 99360711 (1) and torque wrench (2).

During cylinder sleeve fitting, lubricate only the engine block housing, taking care not to grease sleeve housing rim, thus avoiding that too much oil may cause an incorrect sleeve fitting and possible breaks in the rim.


FIGURE 44



2203


Diagram for checking sleeve I.D., so as to define selection class values and to stamp the relevant letter on engine block.

FIGURE 45



When fitting has been completed, check sleeve standoff above cylinder block (2) using dial gauge (1). It should be from -0.020 to $+0.045$ mm.

FIGURE 46




Check flatness of block face (2) using straightedge (1) and a feeler gauge (3).

After inspecting distortion areas, grind the surface as required, taking care to remove as little material as possible.

NOTE - Block face skimming must be carried out only with cylinder sleeves removed.


NOTE - If block skimming is carried out, restore the sleeve rim depth, which should be of 5.97 to 6.02 mm.

FIGURE 47




Remove dowel (1) using suitable tool (2).

NOTE - Remove dowels only if block skimming is to be carried out.




Details on tappets and their housings on the block.



Details on tappets and their housings on the block.

Tappet replacement, because of excessive housing clearances, requires oversized tappets and housing boring. Tappets are supplied with standard spares and oversized of 0.10, 0.20, 0.30 mm.


FIGURE 49



Details on camshaft bushings and their housing on engine block.


To remove and insert bushing use a suitable tool.
During insertion, take care to position bushings so that their holes are aligned with those of capscrew seats and those for lubrication oil.

CRANKSHAFT



Crankshaft journal and main half-bearing details.

FIGURE 51



Main journal measurements.

Before regrinding, with micrometer (1) measure crankshaft journals (2) and define the undersize diameter required.


Remember that ovality must be limited to 0.008 mm and taper to 0.012 mm.

Undersize range is 0.254 - 0.508 - 0.762 - 1.016 mm.

NOTE - Crankshaft journals and crankpins must always be ground to the same undersize class.

CHECK OF CRANK SHAFT JOURNAL AND CRANKPIN ALIGNMENTS


FIGURE 52



This check must be carried out after grinding, placing crankshaft (1) on two V-blocks (2) and using dial gauge (3).


- Main journal alignment: max. tolerance 0.20 mm (total dial gauge reading), and 0.10 mm between two adjoining journals.

FIGURE 53



- Crankpin alignment as to main journals. Each pair of crankpins and each pair of main journals should lie on the same plane. Max. tolerance is ± 0.25 mm. Max. allowed tolerance between shaft rotation axis and crankpin surfaces, is ± 0.10 mm.


FIGURE 54



Flywheel face check.


Flywheel mounting flange: when the shaft is rotated, crankshaft flange eccentricity relative to main journals (B) should not exceed 0.04 mm; crankshaft flange runout on periphery (A) (on a dia. 2 to 4 mm less than the max resting surface dia.) should not exceed 0.02 mm.

FIGURE 55



Check that lubrication circuit caps have no leakages at an internal pressure of 15 bar. If so, replace them using tool 99386010 (1) for fitting.


FIGURE 56



2208

Details of front, intermediate and rear main journal fillets.


FIGURE 57



2208

Details of crankpin fillets.


FIGURE 58



2208

Details of central main journal fillets.
When grinding main journals, carefully observe fillet values, as these should not change as to those indicated

FIGURE 59




16539

Insertion of a calibrated wire for clearance measurement:

- Thoroughly clean all parts and wipe-out oil.
- Place a calibrated wire on crankshaft journals (1) parallel to the longitudinal axis (see the arrow).
- Insert caps and tighten the screws (already lubricated) at the prescribed torque.
- Remove caps and measure clearance, comparing the calibrated wire width (arrow) with scale graduation on the container (2).

FIGURE 60



16540


Check the measurement of crankshaft (2) end float by gauge (1).

Standard clearance is 0.076 to 0.328 mm.

If excessive end float is noticed, replace thrust washers with new ones of standard thickness or oversized by 0.127 mm if necessary.

ENGINE FLYWHEEL RING GEAR REPLACEMENT


FIGURE 61



23459

If ring gear teeth (1) of engine starter flywheel (2) are seriously damaged, replace the whole ring gear. To remove/install ring gear on flywheel use a suitable drift; before installation, heat ring gear to 80°C.

FIGURE 62



23460


Engine flywheel assembly.

Using tool 99360351 (2) and torque wrench (3) tighten capscrews (1) to a torque of 102 Nm (10.5 kgm); then furtherly tighten by 60°.

NOTE - Screws can be reused as long as thread dia. (measured at 25 mm from tip) is not lower than 15.5 mm.

PISTON-CONNECTING ROD ASSEMBLY


FIGURE 63



23461

Piston ring (1) removal/installation by means of remover/installer 99360184 (2).

FIGURE 64



23462

Piston ring (1) assembly/disassembly by means of round-nose pliers (2).


FIGURE 65



23463

Piston pin removal (1). If it is difficult to remove the pin, use a suitable driver.


FIGURE 66



PISTON-CONNECTING ROD ASSEMBLY COMPONENTS

1. Piston - 2. Double taper ring - 3. Ring - 4. Oil scraper ring - 5. Pin - 6. Piston rings - 7. Half-bearings - 8. Connecting rod.


FIGURE 67



Measure piston diameter (2) by micrometer gauge (1) to define clearance.

NOTE - Diameter must be measured 33 mm from skirt base.

FIGURE 68



Piston-cylinder liner clearance can be checked not only by measuring piston and liner diameters, but also with a feeler gauge (1), as indicated in the figure.


PISTON RINGS

FIGURE 69




Checking clearance between piston rings (1) and relevant grooves on piston (2) by feeler gauge (3).

FIGURE 70



Check piston ring thickness (2) with micrometer gauge (1).


FIGURE 72



23467

Detail of the first groove for double taper compression ring.
Groove height is measured on 134 mm dia.


FIGURE 73



16554

Checking clearance between double taper ring (2) and its groove on piston, with a feeler gauge (1).

FIGURE 74



3513


Diagram for measuring X clearance between the first piston groove and the double taper ring.

Due to the special shape of the first compression ring (double taper section), the gap between groove and ring is measured as follows: position piston (1) so that it protrudes from engine block with ring (2) half out of cylinder sleeve (3).

On this position, insert feeler gauge and check gap (X) between ring and groove. Gap should be 0.122 to 0.163 mm.

8210 M 22

FIGURE 69




27264

Details of pistons, piston pins and rings.

*Dimension obtained on 134 mm dia.

8210 SRM 36

FIGURE 71




23466

Details of pistons, piston pins and rings.

* Dimension obtained on 134 mm dia.

CONNECTING RODS

FIGURE 75



Piston ring end (2) gap inspection by feeler gauge (1).

.8210SRM36

Gap between ring ends in cylinder sleeve should be:


- Top compression ring, double taper mm 0.50 to 0.75
- 2nd compression ring, straight mm 0.50 to 0.75
- 3rd ring, oil scraper mm 0.40 to 0.60

.8210M22

Ring gap in sleeve:


- Top compression ring, double taper mm 0.60 to 0.80
- 2nd compression ring, straight mm 0.50 to 0.70
- 3rd compression ring, straight mm 0.50 to 0.70
- 4th oil scraper ring mm 0.40 to 0.60

FIGURE 76



If the gap is less than the minimum allowed, rectify piston ring ends with tool 99360188; if gap is greater than the maximum allowed, replace rings.

FIGURE 77




Check for connecting rod axis misalignment, using gauge 99395363 (1).

Max. allowable tolerance is 0.07 mm measured 125 mm from the longitudinal rod centreline.

For misalignment over the allowed tolerance, straighten connecting rod using a hydraulic press.


FIGURE 78



Straightening connecting rod stem (2) by press (1),.

8210 SRM 36

FIGURE 79




23468

Details of connecting rods, bearings, bushing, piston pin.

* Dimension to be obtained after fitting the bushing.

8210 M 22


FIGURE 77



27005

Details of connecting rods, bearings, bushing and piston pin.


*Dimension to be obtained after fitting the bushing.



Bushing (2) removal/refitting is carried out by hydraulic press (1) with the aid of a suitable tool. After fitting, remove the portion of bushing protruding laterally from connecting rod small end; then re-grind bushing to obtain diameter 48.019 to 48.035 mm.

8210M22


FIGURE 80



Bushing (3) removal/fitting is carried out by hydraulic press (1) with the aid of installer/remover tool 99360270 (2). After fitting, remove the portion of bushing protruding laterally from connecting rod small end; then re-grind bushing to obtain diameter 50.019 to 50.035 mm.

.8210SRM36


FIGURE 81



Checking connecting rod weight tolerance.


On connecting rod weight, the tolerance is ± 20 gr. It must be checked with the connecting rod complete with small end bushing, cap, screw and nuts.

FIGURE 82



NOTE - Before installing the connecting rod-piston assembly, check its squareness. It should be perfect. If not replace the affected parts.

FIGURE 83




23469

DIAGRAM FOR INSERTING THE CONNECTING ROD - PISTON ASSEMBLY IN CYLINDER

1. Stamp mark area with the number of the cylinder which the connecting rod pertains to - 2. Raised arrow indicating engine direction of rotation - 3. Camshaft.

NOTE - In case of connecting rod removal and installation, replace old screws and nuts with new ones.

FIGURE 84



16563

Connecting rod-piston (1) installation in cylinder sleeves (2) with piston ring clamp 99360603 (3).


Installation of connecting rod-piston assemblies in cylinder sleeves must be carried out checking that:

- Each piston - connecting rod assembly is of a same class (A or B).

- The connecting rod number corresponds to cylinder number.
- Writing "LATO PUNTERIE" (TAPPETS END) stamped on piston crown is positioned towards camshaft.
- Connecting rod numbers are positioned at camshaft end.
- Piston ring openings are shifted 120° one another. Thoroughly lubricate pistons, rings, and cylinder sleeve insides included. **8210SRM36**

- piston ring openings are shifted 90° one another; Thoroughly lubricate pistons, rings, and inside of cylinder sleeves. **8210M22**


FIGURE 85



16564

After installation, with dial gauge (1) check that the piston protrusion (2) is -0.275 to $+0.225$ in relation to the block face.

FIGURE 86



16565

Application of calibrated wire (arrow) to detect crankpin clearance.


To detect clearance, operate as follows:

- Thoroughly clean all components and wipe out oil.
- Insert on crankshaft journals (1) a calibrated wire (see arrow).

- Place a cap and tighten nuts at prescribed torque. Screws and nuts must be lubricated.
- Remove cap and detect clearance comparing calibrated wire width (see arrows) with scale graduation on container (1).

CAMSHAFT


FIGURE 87



2201

Camshaft details.

FIGURE 88




16566

Camshaft journal and lobe surfaces should be smooth. If pick-up or scoring are detected, remove the whole shaft and its bushings.

With dial gauge (1) check journal (2) alignment; misalignment should not exceed 0.10 mm; if higher, straighten shaft with a press.


FIGURE 89



16567

With camshaft on V-blocks, with dial gauge (1) check cam lobe lift, which should be 7.921 mm for intake and 8 mm for exhaust.


FIGURE 90



13768

To check camshaft running clearance, measure bushing bore I.D. and camshaft pin (3): the difference is the real clearance.
If clearance over 0.161 mm is detected, replace bushings and, if necessary, also camshaft.

FIGURE 91




16569

Camshaft (1) installation.

Before installing camshaft, lubricate journals with engine oil.


VALVE SYSTEM CONTROL

FIGURE 92



23470

When installing valve system gears the numbers 1-2-3 (see arrows) on the gears should be in line with the same numbers on adjacent gears.



P.M.S. = T.D.C.

P.M.I. = B.D.C.

ANTICIPO INIEZIONE = INJECTION ADVANCE

APERTURA = OPENING

CHIUSURA = CLOSING

ASPIRAZIONE = INTAKE

SCARICO = EXHAUST


ORDINE DI SCOPPIO = FIRING ORDER

Valve system diagram.

Data refers to theoretical check gap of 0.55 mm between valves and rockers.


CYLINDER HEADS

FIGURE 94



Removal/installation of valves is carried out with tool 99360138 (1).


FIGURE 95



PARTS COMPOSING VALVE ASSEMBLY

1. External spring washer - 2. Valve - 3. Bottom internal spring cap - 4. Internal spring - 5. External spring - 6. Top cap - 7. Retainer cotters.


FIGURE 96



Cylinder head bottom view.


1. Exhaust valve housing
2. Intake valve housing.

FIGURE 97




Check for leakages using the proper tool (1, 2, 3). With a pump let in water heated to about 90°C and to a 4 to 5 kg/cm² pressure. No leakage should be detected; if so, replace cylinder block.

FIGURE 98




Cylinder head face (1) check is carried out with a straightedge (2) and a feeler gauge (3). If distortions greater than 0.15 mm are observed, dress head using suitable grinder.

FIGURE 99



With magnetic base dial gauge (2) check for maladjustment and clearance between valve stem (1) and its seat. If clearance is excessive, replace valve and, in case, valve guide.

FIGURE 100



Valve guide insertion/removal.

With reamer 99395723 measure valve guide diameters, which should be 11.025 to 11.045 mm. If not, replace valve guides.

Guides are supplied as spares with oversized diameters (0.04 - 0.20 - 0.24 mm).

Valve guide (3) assembly is carried out with remover/installer tool 99360143 (1) complete with component 99360299 (2).

FIGURE 101





Diagram for correct fitting of exhaust and intake valve guides.

FIGURE 102




SCARICO = EXHAUST
ASPIRAZIONE = INTAKE

Valve and valve guide details.


* Dimension to be obtained after valve guide fitting.

FIGURE 103



After valve guide fitting, rebore valve guide (2) hole using reamer 99390331 (1).


FIGURE 104



If valve seats have to be replaced, proceed as follows:


- Use tool (1).
- On cutter (3) adjust stop (2).
- Use cutter to remove valve seat.
- Clean seat with compressed air.

FIGURE 105



Cylinder head and valve seat details.


FIGURE 106



Valve seat (1) fitting is carried out with a suitable installer/remover tool (2), heating to about 50°C the cylinder head and cooling to -180° valve seats (for instance, in a liquid nitrogen tank).


Fitting interference	{	intake	0.150 to 0.205 mm
		exhaust	0.145 to 0.190 mm

FIGURE 107



If valve seats (2) are replaced or they are damaged, dress seats using HUNGER tool 99360419 (1).


FIGURE 108



Detection of valve contact line in its seat.


If contact (see arrows) is offset as to valve head seat, dress seat.

To dress valve faces, insert valve stem in the self centering chuck of grinder 99301014 and adjust the support to operate at $45^\circ 30' \pm 5'$ for exhaust valves, and at $60^\circ 30' \pm 5'$ for intake valves. After dressing, check that stand-in is 1.4 to 1.8 mm for intake valves, and 1.3 to 1.9 mm for exhaust valves.




16587

Valve spring rate (external and internal) must be checked using tester 99305049, comparing load and elastic strain with data of figs. 110 and 111 relating to new springs.




Details for the test of external intake and exhaust valve springs



Details for the test of internal intake and exhaust valve springs

CYLINDER HEADS


FIGURE 93



16573

Removal/installation of valves is carried out with tool 99360138 (1).

FIGURE 94




16574

VALVE ASSEMBLY COMPONENTS

1. External spring washer - 2. Valve - 3. Bottom internal spring cap - 4. Internal spring - 5. External spring - 6. Top cap - 7. Retainer cotters.

FIGURE 95




16575

CYLINDER HEAD BOTTOM VIEW.


1. Exhaust valve housing.
2. Intake valve housing.

FIGURE 96



16576


Check for leakages using the proper tool (1, 2, 3). With a pump let in water heated to about 90° C and to a 4 to 5 bar pressure. No leakage should be detected; if so, replace cylinder block.



16577

Cylinder head face check is carried out with a straight-edge (2) and a feeler gauge (3). If distortions greater than 0.15 mm are observed, dress head using a suitable grinder.


FIGURE 98



16578

With magnetic base dial gauge (1) check for maladjustment and clearance between valve stem (2) and its seat. If clearance is excessive, replace valve and, in case, valve guide.

FIGURE 99




23471

Valve guide insertion/removal.

Using a reamer, measure valve guide diameters which should be 11.025 to 11.045 mm.

If not, replace valve guides.


Guides are supplied as spares with oversized diameters (0.04-0.20-0.24 mm). Valve guide (3) assembly is carried out with drift 99360143 (1) complete with component 99360299 (2).



27265

DIAGRAM FOR CORRECT FITTING OF EXHAUST AND INTAKE VALVE GUIDES.


FIGURE 101



27014


VALVE AND VALVE GUIDE DETAILS.

FIGURE 102



16582


After valve guide fitting, rebores valve guide hole (2) using reamer 99390331 (1).



If valve seats have to be replaced, proceed as follows:


- ☐ use tool (3).
- ☐ on cutter (2) adjust stop (1);
- ☐ use cutter to remove valve seat;
- ☐ clean seat with compressed air.

FIGURE 104



CYLINDER HEAD AND VALVE SEAT DETAILS.


27015



Valve seat (1) fitting is carried out with a suitable installer/remover tool (2), heating to about 50°C the cylinder head and cooling to -180°C valve seats (for instance, in a liquid nitrogen tank).


Fitting interference: 0.150 to 0.205 mm

FIGURE 106



If valve seats (2) are replaced, or they are damaged, dress them using HUNGER tool 99360419 (1).

FIGURE 107




Detection of valve beat line on its seat.

If contact (see arrows) is offset as to valve seat, dress seat.

To dress valve faces, insert valve stem in the self-centering chuck of grinder 99301014 and adjust the support to operate at $45^{\circ}30' \pm 5'$ for both intake and exhaust valves. After dressing, check that stand-in is 1.4 to 1.8 mm for intake valves and 1.3 to 1.9 for exhaust valves.


FIGURE 108



16587


Valve spring rate (external and internal) must be checked using tester 99305049 (1), comparing load and elastic strain with data of figures 109 and 110.

FIGURE 109



DETAILS FOR TESTING EXTERNAL INTAKE AND EXHAUST VALVE SPRINGS.


FIGURE 110



DETAILS FOR TESTING INTERNAL INTAKE AND EXHAUST VALVE SPRINGS.

CYLINDER HEAD ASSEMBLY


FIGURE 112



To assemble and tighten cylinder heads (1) proceed as follows:

- On engine block position gasket with word "ALTO" (TOP) towards the operator.
- Assemble cylinder head and check their alignment using a straightline.
- After lubricating screws with UTM, tighten them following the diagram in fig. 114, to a torque of 200 Nm (20.5 kgm) **8210SRM36**.
- Repeat tightening to that same torque.

FIGURE 113



Using tool 99395202 (1) tighten screws by 120°.

For the engine 8210M22 the tightening torque is 294 Nm (30 kgm).

NOTE - The screws can be reused as long as thread external dia. is not lower than 17.5 mm.

FIGURE 114





Diagram of tightening sequence for cylinder head cap-screws.

ROCKER SHAFTS - PUSHRODS

FIGURE 115



23473

ROCKER SHAFT ASSEMBLY


1. Retainer split ring - 2. Thrust washer - 3. Rocker - 4. Bracket - 5. Rocker spacer spring - 6. Shaft.

Check for scores or seizure in contact surfaces. If detected, replace worn out components.

Check clearance between valve rocker and rocker shaft, and between bracket and rocker shaft. It should be 0.020 to 0.062 mm and 0 to 0.054 mm respectively. Parts causing oversize to prescribed clearance must be replaced.

Verify seal of caps at the end of each shaft.

FIGURE 117




2232

Details for checking rocker spacer springs.

8210SRM36

FIGURE 118




16593

Rocker bushing (2) assembly, using suitable remover/installer tool (1).

When inserting new bushings take care they do not protrude from rocker sides.

8210 SRM 36


FIGURE 116



Bracket, rocker shaft, rocker and inherent bushing details.


8210 M 22

FIGURE 116



BRACKET, ROCKER SHAFT, ROCKER AND INHERENT BUSHING DETAILS.

FIGURE 119



Rocker and valve clearance adjustment using wrench 99350108 (1), box wrench (2) and feeler gauge (3). Running clearance is 0.30 mm for intake, and 0.40 mm for exhaust. Position to firing stroke the cylinder on which clearance must be adjusted; the valves of this cylinder are closed when those of the symmetrical cylinder are in balance condition.

Symmetric cylinders are 1-6, 2-5, 3-4.

NOTE - To adjust valve-rocker clearance more quickly during engine re-assembly, proceed as follows:


- Rotate crankshaft, have cylinder 1 valves in balance condition and adjust the valves marked with an asterisk, as indicated in the following scheme:

Cylinder No.	1	2	3	4	5	6
Intake	—	—	*	—	*	*
Exhaust	—	*	—	*	—	*

- Rotate crankshaft, have cylinder 6 valves in balance condition and adjust the valves marked with an asterisk, as indicated in the following scheme:

Cylinder No.	1	2	3	4	5	6
Intake	*	*	—	*	—	—
Exhaust	*	—	*	—	*	—


FIGURE 120



Pushrods should be free from distorsion; the spherical seats in contact with rocker adjusting screw and with tappet (see the arrows) should not show signs of pick-up or wear. If so, replace them. Intake and exhaust pushrods are identical, and, therefore, interchangeable.

LUBRICATION

FIGURE 121




ENGINE WITHOUT OIL SUMP - BOTTOM VIEW

1. Oil suction scoop - 2. Relief valve - 3. Oil pump - 4. Oil delivery line to heat exchanger - 5. Delivery line.


NOTE - Replacement of an oil pump gear requires the replacement of mating gear. This will restore the pump to its initial efficiency.

FIGURE 122



With feeler gauge (1) check clearance between gears and cover face. Clearance should be 0.015 to 0.067 mm.


FIGURE 124



16597

With feeler gauge (1) check gap between gear O.D. and pump casing. It should be 0.130 to 0.210 mm.

FIGURE 126




2391

LONGITUDINAL SECTION THROUGH OIL PRESSURE RELIEF VALVE

1. Split pin - 2. Threaded cap - 3. Spring - 4. Valve body - 5. Valve.

FIGURE 127




2257

LONGITUDINAL SECTION THROUGH BY-PASS VALVE

1. Cap - 2. Gasket - 3. Valve body - 4. Spring - 5. Valve.


FIGURE 125



16598

With installer/remover tool (1) insert bushing on oil pump cover.


FIGURE 129



2231

Details for testing filter by-pass spring valve.


FIGURE 128



2233


Details for oil pressure check valve spring.

FIGURE 131



2137

FIGURE 130



13790

LONGITUDINAL SECTION THROUGH OIL PUMP


1. Driving gear - 2. Driven gear - 3. Top control shaft - 4. Front cover - 5. Gear - 6. Body - 7. Bushings - 8. Driven gear bottom shaft - 9. Valve - 10. Rear bushing - 11. Rear cap.

INSTRUCTION FOR INSTALLING OIL SUMP ON ENGINE BLOCK

To re-assembly oil sump (if previously disassembled) carefully follow this procedure and the diagram in the figure, so as to avoid oil seeping from oil sump:

- Use jointing compound on the sections of the sealing gasket, taking care that the holes in the sump exactly correspond to those in the gasket. Also, the gasket should protrude at least 1 mm as to the rear flange face.
- With sealing compound, coat connection areas of gasket elements.
- When compound is dried, check that the protruding portion of the gasket is between 0.5 and 1.5 mm. If these values are exceeded the surplus portion must be trimmed.
- Sump assembly must be carried out with the engine block complete with its valve system cover and rear support.
- Install sump on engine block bottom, and slide it until it contacts the rear support.
- Screw down screws from No. 3 to No. 36.
- Tighten screws 1 and 2 (to have vertical clamp).
- Screw down (about 3/4 of total tightening) screws from No. 37 to No. 41.
- Loosen screws 1 and 2.
- Tighten screws 37 to 41.
- Alternately tighten screws 3 to 36.
- Again check screws 37 to 41, (in case they are loose), and tighten screws 1 and 2.


FIGURE 132



2204

COOLING SYSTEM WATER PUMP DISASSEMBLY

FIGURE 135




23474

LONGITUDINAL SECTION THROUGH WATER PUMP

1. Impeller - 2. Retainer ring - 3. Seal gasket - 4. Water pump body - 5. Control shaft with bearing - 6. Driving gear.

ENGINE ASSEMBLY


FIGURE 255



Using brackets 99361015 and 99361014 install engine block on revolving stand 99322230. Tighten screws (1) and nuts (2) of front plate (3) to a torque of 78 Nm (8 kgm).


Fit cylinder liners as indicated

FIGURE 256




Insert camshaft bushings using an appropriate tool. Lubricate bushings and fit camshaft (1) fixing it to the front plate of the engine block with a suitable plate. Lock screws to a torque of 78 Nm (8 kgm).

FIGURE 257




Insert oil spray nozzles (1).

FIGURE 258




Place half-bearings (1) on main bearings.

FIGURE 259



Lubricate half-bearings (3), then insert crankshaft (2) using a hoist with hook 99360500 (1).


FIGURE 260



Insert thrust washers (1) in central main bearing.


NOTE - Thrust washers must be installed with the anti-friction alloy towards the crankshaft block. Top thrust washers are not interchangeable with the bottom ones.

FIGURE 261




Position main bearing caps and relevant lubricated half-bearings on central cap (1) of thrust washers (2). All caps are marked with a number corresponding to the relevant bearing on engine block.

FIGURE 262



On main bearing cap No. 1 install oil pump (2). Using torque wrench (1) tighten cap set screws to a torque of 412 Nm (42 kgm).


FIGURE 263



23478

Position seal ring (1) on camshaft.


FIGURE 264



23479

On housing fit seal ring (1) and seal (2).


FIGURE 265



16737

Insert the complete flywheel housing on engine block and tighten screws (1) with a torque wrench (2) to the prescribed value.


FIGURE 266



16738

Insert guide pins (1) and engine flywheels (2); lock rotation with tool 99360351 and tighten screws to 95 Nm torque.


FIGURE 267



23480

Using tool 99395202 (2) lock screws (1) to a 60° angle.


FIGURE 268



23481


Rotate engine block positioning it vertically. Place connecting rod half-bearings in their seats, then insert connecting rod-piston-ring assemblies in the cylinder sleeves using piston ring clamp 99360603 (1) as described

FIGURE 269




Connect connecting rods to crankpins, insert caps (1) complete with their half-bearings, tighten lock nuts to 275 Nm (28 kgm).

FIGURE 270




Fit oil delivery pipings (3 and 2) (interposing relevant gaskets) and oil suction scoop (1).

FIGURE 271




Install housing with injection pump drive shaft (2) and position oil line (1) for gear system lubrication.

FIGURE 272




Have pistons 1 and 6 to T.D.C. and key valve system gears, taking care that numbers 1-2-3 marked on intermediate gear coincide with the same numbers on drive gears of crankshaft, camshaft and injection pump.

FIGURE 273




Install power steering pump (1).

FIGURE 274



Install valve system cover (1) with seal. Insert seal and install oil pump as indicated. Install starter and rotate engine by 180°.


FIGURE 275



Install damper wheel hub (1) and using torque wrench (3) and torque multiplier (2) tighten nut 931 Nm (95 kgm).


NOTE - Lubricate nut with minium dispersion in engine oil.

FIGURE 276




Lubricate tappets (1) with engine oil and insert them in their seats.

FIGURE 277




On engine block position cylinder head gaskets (1) with the word "ALTO", (TOP) towards cylinder heads.

FIGURE 278




With a hoist lift up cylinder heads (1) one at a time, and fit them on engine block.

FIGURE 279




With straightedge (2) check alignment of cylinder heads (1) from exhaust manifold end.

FIGURE 280




Screw down cylinder head securing screws (1) previously lubricated) and tighten them as described

FIGURE 281




Insert rocker pushrods (1) in their housings.

FIGURE 282




Insert caps (1) on valves (2).

FIGURE 283




Insert rocker shaft assemblies (1) on heads (2).

FIGURE 284




With a torque wrench (1) lock nuts to a 59 Nm (6 kgm) torque.

FIGURE 285



As indicated at page 136, adjust clearance between rockers and valves using wrench 99350108 (1) and feeler gauge (2).

FIGURE 286



Insert water lines (1 and 2) on engine block and cylinder heads. Fit the complete fuel housing.

TIGHTENING TORQUES (TEMPORARY DATA)

DESCRIPTION	TORQUE Nm (kgm)
Self-capscrew, main bearing caps (crankshaft and oil pump)	▲ 412 (42)
Capscrew, sump to engine block	14 (1.4)
Capscrew, sump to front cover	14 (1.4)
Capscrew, sump to rear cover	14 (1.4)
Nut, front cover to plate and front engine mounting	59 (6)
Stud, front plate to engine block	59 (6)
Capscrew, front cover to engine block plate	49 (5)
Capscrew, front plate to engine block	▲ 78 (8)
Capscrew, rear engine mounting to engine block	▲ 98 (10)
Capscrew, rear engine mounting to engine block	▲ 78 (8)
Capscrew, rear engine mounting to engine block	▲ 137 (14)
Capscrew, front cover to plate	▲ 29 (3)
Capscrew, head to engine block with cylinders	▲ 200 (20.5) + 120° 8210SRM36 - 294 (30) 8210M22
Stud, intake manifold to cylinder heads	39 (4)
Capscrew, exhaust manifold to cylinder heads	• 32.5 (3.3)
Capscrew nut, connecting rod cap	▲ 275 (28)
Self-locking capscrew, engine flywheel	▲ 95. +60°
Nut, damper hub	* 931 (95)
Self-locking capscrew, pin, driven gear to engine block	▲ 78 (8)
Capscrew, thrust plate to camshaft	▲ 78 (8)
Self-locking capscrew, camshaft driven gear	▲ 59 (6)
Cap, oil filter valve	68 (6.9)
Capscrew, heat exchanger to casing	24 (2.5)
Nut, cover to heat exchanger	24 (2.5)
Nut, heat exchanger to bracket	49 (5)
Nut, heat exchanger to filters	49 (5)
Capscrew, heat exchanger to engine block	59 (6)

▲ Wet lubrication UTDM oil.

• Lubricate with graphite oil W.

* Lubricate with minium dispersion in engine oil.

DESCRIPTION	TORQUE Nm (kgm)
Capscrew, engine block water inlet elbow	24 (2.5)
Nut, heat exchanger water outlet	24 (2.5)
Capscrew, water inlet pipe to engine block	24 (2.5)
Capscrew, water outlet pipe to engine block	49 (5)
Stud, elbow to front engine block water outlet	49 (5)
Stud, upper water delivery to front engine block water outlet	24 (2.5)
Capscrew, bottom delivery water pipe to pump	24 (2.5)
Nut, rocker holder shaft	59 (6)
Self-locking capscrew, injection pump housing to engine block	98 (10)
Self-locking capscrew, laminations to injection pump union	59 (6)
Nut, manifold capscrew for injection pump connection shaft	47 (4.8)
Stud, injector bracket to cylinder head	49 (5)
Self-locking capscrew, front and rear cover to oil pump casing	▲ 29 (3)
Nut, turbocharger capscrew to rear exhaust manifold	62 (6.3)
Collar, air inlet sleeve to turbocharger	11 (1.1)
Capscrew, oil delivery pipe to turbocharger	45 (4.6)
Capscrew, drain oil pipe to turbocharger	45 (4.6)
Nipple, oil delivery pipe to turbocharger	136 (13.9)
Pipe union, filter to injection pump	33 (3.4)
Pipe union, piston cooling oil nozzle	49 (5)
Capscrew, oil pump suction pipe to cover	49 (5)

▲ Wet lubrication, UTDM oil.

DESCRIPTION	TORQUE Nm (kgm)
Capscrew, oil pump intake pipe to front interior intermediate cap	49 (5)
Capscrew, oil filter body to engine block	49 (5)
Pipe union, oil delivery pipe to turbocharger	77 (7.8)
Valve, oil pressure check	78 (7.9)
Valve, oil filter safety	136 (13.8)
Capscrew, front cover and housing to plate	29 (3)
Capscrew, housing to front cover	29 (3)
Stud alternator housing to front engine block cover	29 (3)
Nut, alternator capscrew to housing	88 (8.9)
Nut, pulley to alternator fan	52 (5.3)

SPECIAL TOOLS

TOOL NO.	DESCRIPTION
ENGINE	
99315067	Base, engine.
99340035	Puller, pulley hub/water pump impeller.
99340205	Puller, slide hammer.
99340215	Tool part for removing clutch shaft guide bush, or bearing, in crankshaft (use with 99340205).
99342145	Remover, injector sleeve.
99350108	Wrench, tappet adjustment.
99355039	Retainer, nut, damper flywheel.
99360138	Remover/installer engine valves.
99360143	Remover/installer valve guide.
99360183	Pliers, compressor piston rings.
99360184	Pliers, engine piston rings.
99360299	Remover/installer, valve guide (use with 99360143).
99360314	Remover/installer cartridge filters.
99360320	Rotator, crankshaft, tappet adjustment and valve gear timing.
99360351	Retainer, engine flywheel.
99360423	Installer, crankshaft rear seal (use with 99370006).
99360460	Connection, engine cylinder compression test (use with 993956682).
99360500	Lifter, crankshaft.
99360502	Set of eyes, lift, cylinder heads.
99360503	Set of eyes, lift, engine block.
99360545	Bracket, engine flywheel assembly/disassembly (use with 99360551).
99360551	Bracket, engine flywheel assembly/disassembly.
99360585	Rocking sling, engine removal/installation.
99360603	Compressor, standard and oversize piston installation in cylinders.
99360605	Compressor, standard and oversize piston installation in cylinder.
99360772	Plate, threaded.
99360773	Ring.
99360774	Ring.
99360778	Screw, forcing.
99360788	Set of studs.
99360790	Set of adapters.
99361014	Brackets, engine to swinging stand 99322220.
99361015	Brackets, engine to swinging stand 99322220.
99365010	Burnisher, injector sleeve.
99365063	Spreader, injector sleeve.
99370005	Handle, driver, interchangeable.
99370006	Handle, driver, interchangeable.
99374218	Remover/installer, crankshaft rear seal (use with 99370005).
99386010	Remover/installer crankshaft core plugs.
99390331	Reamer, valve guide.
99390789	Set of taps, to thread injectors sleeves to be extracted.
99394017	Dresser, lower injector sleeve portion (use with 99394019).
99394019	Bushing, pilot.
99394031	Cutter, injector housing (use with 99394019).

