NEF SERIES STAGE IIIA

G_Drive application

NEF45

NEF45 SMIF NEF45 TEIF NEF45 TE2F

NEF67

NEF67 TMIF NEF67 TEIF NEF67 TE2F

Technical repair manual

This document provides data, specifications, instructions and methods to perform repair interventions on the assembly and its components.

Anyhow, this document is addressed to qualified and specialised personnel.

Before performing any intervention, check that the document relating to the vehicle model on which the intervention is being performed is available and also make sure that all accident prevention devices, including but not limited to, goggles, helmet, gloves, shoes, as well as work equipment, lifting and transport equipment, etc., are available and efficient, and also make sure that the vehicle is in safety conditions for intervention.

Making interventions strictly observing the indications given here, as well as using specific equipment indicated, assures a correct repair intervention, execution timing observance and operators' safety.

Each repair intervention must be finalised to the recovery of functionality, efficiency and safety conditions that are provided by lveco.

Each intervention on the vehicle that is finalised to a modification, alteration or anything else which has not been authorised by FPT relieves FPT of any liability, and, in particular, where the assembly is covered by a warranty, each intervention will immediately invalidate the warranty.

FPT declines any liability for repair work.

FPT is available to provide any information necessary for the implementation of the interventions and to provide instructions for any cases and situations not covered in this publication.

The data contained in this issue may not be up-to-date due to possible modifications made by the Manufacturer for technical or commercial reasons, or to adaptations required by laws in force in different countries.

In the event of discordance between the information in this publication and the actual assembly, please contact the FPT network before performing any interventions."

The complete or partial reproduction of the text or illustrations herein is forbidden.

Publication edited by: **FPT Industrial** S.p.A. Via Puglia 15, 10156 Turin, Italy www.fptindustrial.com Print **P4D32N009 E** - 1st Edition 03.2014

Premise	
	Page
GENERAL INFORMATION	3
symbols	3
🔲 Warnings	3
Service operations	3
GENERAL WARNINGS	5
GENERAL WARNINGS REGARDING THE ELECTRICAL SYSTEM	7
Grounding and screening	8
OPTIONAL ELECTRICAL AND MECHANICAL PARTS INSTALLATIONS	9
CONVERSIONS BETWEEN THE MAIN UNITS OF MEASUREMENT OF THE INTERNATIONAL SYSTEM AND THE MOST COMMONLY USED DERIVED SIZES	9
PAGE HEADER AND FOOTER INTERPRETATION	10

NEF G-Drive Stage IIIA SERIES

NEF F4GE Series

NEF F4HE Series

Part I Part 2

GENERAL INFORMATION

Manuals for repairs are split into Parts and Sections, each one of which is marked by a number; the contents of these sections are indicated in the general table of contents.

Sections with mechanical contents include technical data, tightening torque collections, tool lists, assembly connections - disconnections, overhauls at the bench, troubleshooting and scheduled maintenance.

The sections or parts on the electrical/electronic system contain descriptions of the electrical network and the unit's electronic systems, the wiring diagrams, the electrical features of the components and the component codes.

Sections I and 2 describe the engines with regard to their features and general operation.

Section 3 describes the electrical part, regarding wiring, electrical and electronic equipment which vary depending on the specific use.

Section 4 covers scheduled maintenance.

Sections 5 and 6 address the removal/refitting of the main components and general overhaul operations on the engine mounted on the rotating stand.

Sections 7 and 8 contain the technical features of the engine, such as mounting clearance, tightening torque and specific tools.

The appendix provides a list of the general safety regulations which all operators, whether installers or maintenance technicians, must comply with to prevent any serious injury.

The manual uses proper symbols in its descriptions; the purpose of these symbols is to classify information.

In particular, a set of symbols has been defined to classify warnings, while another set has been specified for service operations.

SYMBOLS - Warnings





Risk of serious damage to the assembly

The partial or total non-observance of these instructions could cause serious damage to the assembly and may nullify the warranty.



General danger

Includes the dangers of both above described signals.




Environmental protection

Indicates correct behaviour in order for the assembly use to be as environmentally friendly as possible.



Service operations

Example:



Ø I = Housing for connecting rod small end bush.

Ø 2 = Housing for connecting

rod bearings ings.



Tighten to torque Tighten to torque + angle value

	Removal Disconnect		Intake
	Refitting Connect	×	Exhaust
==	Disassembly Dismantling	$\langle \uparrow \rangle$	Operation
	Assembly Assemble	Q	Compression ratio
	Tighten to the specified torque	<u>▲</u>	Tolerance Weight difference
$\widehat{\mathbb{Q}}_a$	Tighten to the specified torque + angle value		Rolling torque
	Press or caulk		Rotation
84	Registration Adjustment	\triangleleft	Angle Angle value
	Visual check Fitting position check		Revolutions per time unit
	Measuring Value to be found Check		Temperature
Ð	Equipment	bar	Pressure
4	Surface for machining Finished workpiece	>	Oversized Oversized by no more than Max
Ś	Interference Forced assembly	<	Undersized Undersized by no more than Min.
	Clearance Shim	A	Selection of oversizing class
Г	Lubricate Moisten Grease		Temperature < 0 °C Cold Winter
	Coolant Sealant	\$	Temperature > 0 °C Hot Summer
	Bleeding air		Preload

GENERAL WARNINGS



The warnings shown may not be representative of all the dangerous situations that may occur. Therefore, supervisors should be contacted whenever a dangerous situation that has not been described occurs.

Use the specific and generic tools according to the indications in the respective use and maintenance manuals. Check the working condition and suitability of tools not subject to periodic review.

The manual handling of loads must be assessed in advance since it also depends not only on weight but also on its size and on the path.

Handling by mechanical means must be with hoisters proper as for weight as well as for shape and volume. Hoisters, ropes and hooks used must show clear indications regarding maximum acceptable carrying capacity. The use of such tools is strictly permitted by authorised personnel only. Stay at a safe distance from the load and never below it.

In disassembly operations, always observe the provided prescriptions and prevent any mechanical parts being taken out from accidentally striking workshop personnel.

Shop activities performed by two technicians must always been executed with caution; avoid operations that may be dangerous for any collaborators due to lack of field of vision or incorrect position.

Keep any personnel not assigned to the operations clear of working area.

Learn the necessary concepts of operation and safety relating to the vehicle prior to working on it. Scrupulously observe all safety warnings on the assembly.

Do not leave the assembly in motion unattended during repair work.

When working on an assembly off the ground, make sure that it is resting firmly on the appropriate supporting stands and that the manual/automatic safety devices are activated in the event of lifting with a hydraulic ramp.


When working on assemblies fuelled with natural gas, in addition to the instructions given in the document, also observe all the specific safety regulations provided.

Only remove radiator cap when the engine is cold by cautiously unscrewing it in order to let system residual pressure out.

Flammable fuels and all fluids and liquids must be handled with care, according to the indications provided in the 16 point cards of harmful materials. Refuelling must be performed outdoors with the engine off, avoiding lit cigarettes, free flames or sparks, in order to prevent sudden fires/explosions. Adequately store inflammable, corrosive and polluting fluids and liquids according to what provided by regulations in force. Strictly avoid using containers for food to store harmful liquids. Avoid drilling or burning pressurised containers and discard cloths impregnated with inflammable substances into suitable containers.

Worn out, damaged or consumable parts must be replaced with original spare parts.

During workshop activities, always keep the workplace clean; promptly free or clean floors of any accidental spills and stains of liquids and oils. Electric sockets and electrical equipment necessary to perform repair operations must meet safety rules.



GENERAL WARNINGS REGARDING THE ELECTRICAL SYSTEM



When having to operate on the electrical/electronic circuit, disconnect the batteries from the circuit, disconnecting the chassis ground cable first of all from the negative terminal of the battery.

Before connecting the batteries to the system, make sure that the system is suitably insulated.

Disconnect the external recharging apparatus from the public utility network before removing the apparatus pins from the battery terminals.

Do not cause sparks to verify the presence of voltage in a circuit.

Do not use a test lamp to verify circuit continuity, but proper control equipment only.

Make sure that the wirings of electronic devices (length, type of cable, location, strapping, connection of screen braiding, grounding, etc.) conform with the FPT system and that they are carefully restored after repair or maintenance work.

Measurements on the ECUs, jack connections and electrical connections of components must be done only on regular test lines, with special jacks and jack bushings. Never use improvised equipment like metal wires, screwdrivers, pins or similar. This may not only cause short circuits, but also damage the jack connectors, resulting in poor contact.



Do not use fast chargers to start up the engine. Start up must only be performed with either separate batteries or special truck.

Incorrect polarisation of voltage supply to the electronic control units (for example, incorrect polarization of batteries) may lead to their destruction.

Disconnect the batteries from the system during their recharging with an external apparatus.

On connecting, only screw connector (temperature sensors, pressure sensors, etc.) nuts to the prescribed tightening torque.

Isolate the circuit prior to disconnecting the junction connector from an electronic control unit.

Do not directly supply current to components served by electronic control units with nominal vehicle voltage.

The cables must be routed in such a way as to be parallel to the reference plane, as close as possible to the chassis/body.


Upon completing work on the electrical circuit, restore the electrical connectors and wiring as originally provided.

Grounding and screening

The negative conductors connected to circuit ground point must be as short as possible and connected in "star" form, ensuring that their tightening is done neatly and sufficiently (Figure 1 ref. M).

The following precautions must be observed regarding the electronic components:

- electronic control units must be connected to the system ground when equipped with metal housings.
- The negative cables of the electronic control units must be connected at a circuit ground point, such as dashboard compartment ground (avoiding "serial" or "chain" connections), as well as to the negative terminal of the battery or batteries.
- Even if not connected to the circuit ground/battery negative terminal, analogue ground (sensors) should have optimal insulation.
 Consequently, particular care should be given to terminal parasitic resistances: oxidation, clinching defects, etc.
- The metal braid of shielded circuits must be in contact only at the ECU side to which the signal is to be sent (Figure 2).
- In the case of junction connectors, the unshielded section **d** near to them must be as short as possible (Figure 2).
- The cables must be routed in such a way as to be parallel to the reference plane, as close as possible to the chassis/body.



OPTIONAL ELECTRICAL AND MECHANICAL PARTS INSTALLATIONS

Accessory installation, additions and changes on the assembly must be carried out in compliance with the FPT assembly directives. It is reminded that, especially with regard to the electric system, several electric sockets are provided for as standard (or optional) sockets in order to simplify and normalise the electrical intervention by vehicle manufacturers.




It is strictly forbidden to carry out any modifications or connections to the electronic control unit wiring. In particular, the data line between the control units (CAN line) is to be considered untouchable.

CONVERSIONS THE MAIN UNITS OF MEASUREMENT OF THE BETWEEN INTERNATIONAL SYSTEM AND THE MOST COMMONLY USED DERIVED SIZES

F

Power
$\begin{array}{l} kW = 1.36 \text{ CV} \\ kW = 1.34 \text{ hp} \\ CV = 0.735 \text{ kW} \\ CV = 0.986 \text{ hp} \\ \text{ hp} = 0.746 \text{ kW} \\ \text{ hp} = 1,014 \text{ CV} \end{array}$
NOTE the unit CV is converted into hp for simplicity according to a 1:1 ratio 1 hp = 1 CV.
Torque
Nm = 0.1019 kgm kgm = 9.81 Nm
Revolutions per time unit
I rpm = 0.1047 rad/s
l rad/s = 9.55 rpm
Pressure
bar = 1.02 kg/cm ² kg/cm ² = 0.981 bar
$1 \text{ bar} = 10^5 \text{ Pa}$
NOTE Where accuracy is not particularly required:
the unit Nm is converted into kgm for simplicity according to a ratio of 10:1
l kgm = 10 Nm;
 the unit bar is converted into kg/cm² for simplicity according to a ratio of 1:1 kg/cm² = 1 bar.
Temperature
0 °C = 273.15 K
0 °F = 255.37 K 0 °C = 32°F (the conversion factor between Celsius and Fahrenheit is 1:1.8)



UPDATE DATA

Section	Section name	Description of modification	Page	Revision date

12

NEF 45 SERIES Section I General information 2 Operating diagrams 3 Electric / electronic equipment 4 Scheduled maintenance 5 Removal/refitting of the main components of the engine 6 General mechanical overhaul 7 Technical specifications 8 Tools

Part I

2


SECTION I

General information

	Page
APPROVAL PLATE	3
CORRESPONDENCE BETWEEN TECHNICAL CO AND COMMERCIAL CODES	DES 4
TECHNICAL CODES	5
COMMERCIAL CODES	6
ISO VIEW	7
ENGINE VIEWS (NEF45 SM1F)	8
ISO VIEW (NEF45 TE1F/TE2F)	
ENGINE VIEWS (NEF45 TE1F/TE2F)	12
GENERAL FEATURES	15


Base - March 2014


Print P4D32N009 E




CORRESPONDENCE BETWEEN TECHNICAL CODES AND COMMERCIAL CODES

Technical codes	Commercial Codes
F4GE9455E*J601	NEF45 SMIF
F4HE0485C*J101	NEF45 TEIF
F4HE0485B*J101	NEF45 TE2F





ISO VIEW Figure 2



202358

NEF45 SMIF


They are characterised by a 4 time diesel cycle, sucked in or supercharged with 4 cylinders with 2 or 4 valves per cylinder.


They are powered with a mechanical rotary pump or an in-line pump, depending on the application.


NOTE The data, specifications and performance figures are only valid if the vehicle manufacturer complies with all the installation regulations provided by FPT.


Furthermore, the fitted appliances must always be in compliance with the torque, power and engine speed for which the engine was designed. This section consists of four parts:


- ☐ the part covering specific mechanical overhaul based on use, describing the operations necessary to remove and install the engine components including the cylinder head, timing gear housing and the front cover;
- ☐ the electric part, describing the connections of the various components, the pre-post heating control unit (only for some versions) and the sensors located on the engine;
- diagnostics;
- preventive or routine maintenance operations, with indications regarding the main operations.

















GENERAL FEATURES ับบบบบบ F4GE9455E* F4HE0485C* F4HE0485B* type J101 J601 J101 Diesel 4-stroke Cycle Turbocharged Turbocharged Power supply with turbocharger without intercooler and intercooler Direct Injection Number and arrangement of 4 in line cylinders Ø 104 Bore mm 132 Stroke mm cm³ Total displacement 4485 +.. = 0 17.5 : 1 Compression ratio Prime Power 54.5 72.5 89 kWm 1500 1500 1500 rpm Stand-by Power kWm 60 80 98 1500 1500 1500 rpm Low idle speed rpm (A1) High idle speed rpm Turbocharger with Waste gate TURBOCHARGING intercooler Turbocharger type: Holsett GARRETT HX25W WG HTT Supercharger type: LUBRICATION Oil pressure with hot engine Forced by gear pump, pressure relief valve, oil filter (100 °C ± 5 °C): 3 SAE 15W40 at idle speed bar API CI-4 ACEA E7 5 at max speed bar

	type		F4GE9455E* J601	F4HE0485C* J101	F4HE0485B* JI01
	COOLING Water pump drive: Thermostat: initial opening maximum opening	°C °C		Liquid Belt driven 79 ± 2 96	1
	DISTRIBUTION Start before T.D.C. Until after B.D.C. Start before B.D.C. Until after T.D.C For timing check	A B D C mm		96 17° 31° 48° 9° 0.25 ± 0.05 0.50 ± 0.05	
	POWER SUPPLY Pump type:		Mechanical pump rotating STANADYNE DB 4		ure pump 1 CP3.3
	Nozzle type		STANADYNE XNHM882224	CRIN2 D	LLI37PV3
	Firing order		- 3 - 4 - 2		
bar	Injection pressure	bar	1,800	١,6	.00

	type		F4GE9455E* J601	F4HE0485C* JI0I	F4HE0485B* JI0I	
REFUELLING						
	engine ⁽⁴⁾	litres	8.5			
Cooling circuit ⁽¹⁾	G-Drive ⁽⁵⁾	litres	18.5			
Lubrication circuit ^{(2) (3})		litres (kg)	2.8 (.8)			
Periodic replacement:						
Sump at minimum level		litres (kg)		5.5 (4.95)		
Sump at maximum level		litres (kg)		8.5 (7.65)		
Fuel tank ⁽⁴⁾		litres (kg)		- (-)		

(1). Use a 50% mixture of water and PARAFLU 11 or the equivalent corresponding to the specification SAE J1034.

(2). Use lubricants that comply with international specifications ACEA E5/E7 The consumption of oil is considered acceptable up to a quantity of 0.1% of fuel consumption.

(3). The quantities indicated refer to the first refuel only and are relative to the engine, oil sump and filter refilling.

(4). The quantities indicated only refer to the engine in its standard configuration.

(5). The quantities shown are relative to the total capacity of the G-Drive including engine capacity.

Refuelling from drums or tanks can cause contamination of the diesel, with the consequent risk of damaging the injection system; if necessary, perform suitable filtration or sedimentation of the impurities before refuelling.



The data, specifications and performance figures are only valid if the vehicle manufacturer complies with all the installation instructions provided by FPT.

Furthermore, the fitted appliances must always be in compliance with the torque, power and engine speed for which the engine was designed.

Base - March 2014

Print P4D32N009 E


SECTION 2


Operating diagrams

		Page
SUF	PPLY SYSTEM	3
	Principles	3
ELE	CTRICAL SYSTEM	3
SEN	ISORS	4
	Oil pressure sensor	4
	Water pressure sensor	4
	Pressure regulator valve	4
	Fuel heater on filter	4
	Fuel temperature sensor	4
	Pressure Sensor on Rail	4
HY	DRAULIC SYSTEM	5
SUF	PPLY DIAGRAM	7
SUF	PPLY SYSTEM COMPONENTS	9
	Priming pump	9
	Mechanical supply pump	10
	Normal operating condition	10
	Output overpressure condition	10
	Air bleeding conditions	10
	Fuel filter	11
	Feed pump	12
	Operation description	12
	High pressure pump CP3	13
	High-pressure pump internal structure	14
	Operating principle	15
	Operation	17
	Rail (pressure accumulator)	17
	Overpressure valve	17

		Page
	Electro-injector	18
	Injector in resting position	18
	Beginning of injection	18
	End of injection	18
LUBF	RICATION CIRCUIT	19
	Principles	19
LUBF	RICATION DIAGRAM	21
LUBF	RICATION CIRCUIT COMPONENTS	22
	Oil pump	22
	Heat exchanger	23
	Oil pressure regulating valve	24
	Engine oil filter	25
	Oil sump	26
	Cooling nozzles	27
OIL	VAPOUR RECYCLING SYSTEM	28
	Principles	28
OIL	VAPOUR RECYCLING DIAGRAM	30
0.5	VAPOUR RECYCLING 'STEM COMPONENTS (BLOW-BY)	32
	Blow-by filter (NEF45 SMTF)	32
	Blow-by filter (NEF45 TETF/TE2F)	33
COC	DLING CIRCUIT	34
	Principles	34
COC	DLING DIAGRAM	36
COC	DLING CIRCUIT COMPONENTS	37
	Water pump	37
	Thermostat	37
	Heat exchanger	38
	ake and exhaust system	39
	Principles	39

	Page
INTAKE AND EXHAUST DIAGRAM	40
INTAKE AND EXHAUST SYSTEM COMPONENTS	41
Intake and exhaust manifolds	41
Exhaust manifolds	42
HOLSET HX25W turbocharger	43
EGR SYSTEM (ONLY FOR NEF 45 SMIF)	44





Pressure regulation valve on Rail - 2. Pressure sensor on Rail Fuel temperature sensor - 4. Fuel heater on filter

SENSORS

(NEF45 SMIF)

Oil pressure sensor

Mounted on the right side of the crankcase, measure the engine oil pressure.

Water pressure sensor

The same as the oil pressure sensor, it is fitted on the head on the right of the crankcase.

(NEF45 TE1F/TE2F)

Pressure regulator valve

The pressure regulator valve is fixed to the Rail and has the function of regulating and maintaining the pressure according to the engine load condition.

If the pressure is too high, the valve opens to make part of the fuel flow from the Rail to the tank; if the pressure is too low in the Rail, the valve closes and separates the high pressure side from the low pressure side.

This is a solenoid valve electronically controlled by the control unit (EDC module). Pressure variation is carried out by regulating the return flow of diesel to the tank

Fuel heater on filter

This resistor ensures that the fuel remains liquid even if temperatures fall below the freezing point. When temperatures are too low, the fuel tends to form clots that can cause clogging of electro-injectors and problems with cylinder ignition.


Fuel temperature sensor


This sensor is just like the coolant temperature sensor. It detects the fuel temperature to provide the control unit with an index of the fuel's thermal state.


Pressure Sensor on Rail


Assembled on one end of the rail, measures the existing fuel pressure and informs the control unit (feed - back).

The value of injection pressure is used to keep the pressure level under control and to determine the time duration of the injection electronic command.









Print P4D32N009 E

This CP3 Common Rail injection pump system is shown in the 4-cylinder version.

The pressure regulator, placed upstream of the high-pressure pump, adjusts the fuel flow that is necessary on the low-pressure system.

Afterwards, the high-pressure pump takes care of supplying the rail properly.

This solution, only pressurising the necessary fuel, improves the energy efficiency and limits heating the fuel in the system.

The pressure relief valve (2), mounted on the high pressure pump, has the function of keeping the pressure at the entrance of the pressure regulator constant at 5 bar, regardless of the efficiency of the fuel filter and the system upstream.

The pressure relief valve (2) intervention brings about a fuel flow increase in the high-pressure pump cooling circuit, through inlet and drain piping (16) from piping (8).

The pressure relief valve seated on the cylinder head, mounted on the back of the electro-injectors (3), restricts the return flow of fuel by the electro-injectors at a pressure of $1.3 \div 2$ bar.

Two by-pass valves are placed in parallel with the mechanical supply pump.


The by-pass valve (18) allows fuel to flow from mechanical pump outlet to its inlet, when the fuel filter inlet pressure exceeds the allowed threshold value.

The by-pass valve (17) allows filling the supply system through the manual priming pump (10).

SUPPLY SYSTEM COMPONENTS

Priming pump

The pump has the function of priming the fuel in the tank and conveying it to the fuel supply pump. This is located on the engine crankcase and is activated by the camshaft.




I. Pump - 2. Control lever - 3. Camshaft.

2

72594

B




Fuel filter

The filter is positioned near the feed pump and the priming pump, and has the function of retaining impurities and separating the water contained in the fuel.

At the base of the filter cartridge, there is a water bleed screw through which it is possible to drain it from time to time; a heater and temperature sensor can be placed on the support for the uses that require it (use in cold climates). On some versions, there is a water presence sensor at the base of the filtering cartridge.


(NEF45 SMIF)


Figure II



I. Fuel filter support - 2. Filtering cartridge - 3. Water bleed screw.

106515





Metering valve - 3. Pressure regulator unit Hydraulic head - 5. Automatic advance - 6. Seat 7. Propeller shaft

Operation description

The main rotation components are the propeller shaft (7), the distribution rotor, the transfer pump vanes and the regulator (3). Referring to Figure 12, the propeller shaft engages the distribution rotor inside the hydraulic head.

The four pistons are engaged towards each other simultaneously by the cam inner ring through the rollers and the sliding blocks that are transported into the holes located on the end of the rotor.

The number of cam lobes is equal to the number of engine cylinders.

The transfer pump positioned no the rear part of the rotor is positive cylinder type and is closed within the end plug. The end plug also contains the screen of the inlet filter and the pressure regulator of the transfer pump. The upper part of the regulator unit is pressed against the distribution rotor and forms a final seal for the transfer pump.

The distribution rotor contains two loading ports, a single axial hole and an exhaust port serving all outputs to the injection lines.

The hydraulic head contains the hole in which the rotor turns, the hole of the metering, opening and loading valves, and the fittings for the discharge outlet. The high pressure injection lines connected to the injectors are fixed to the above mentioned exhaust couplings.

9

8

7

6


5


4


High pressure pump CP3 Pump with 3 radial plungers, controlled by distribution The mechanical supply pump controlled by the high presgears, requires no timing. sure pump shaft is mounted on the rear side of the high pressure pump. The high pressure pump - feed pump assembly cannot be overhauled and therefore should not be removed and the fastening screws should not be tampered with. The only operation that can be carried out is the replacement of the drive gear and pressure regulator. (NEF45 TEIF/TE2F) Figure 14 2 3

I. Connection between fuel outlet and rail - 2. High pressure pump - 3. Pressure regulator - 4. Drive gear 5. Filter fuel inlet union - 6. Connection between fuel outlet and filter bracket - 7. Connection for fuel inlet from heat exchanger ECU -8. Connection between fuel outlet from mechanical pump and filter - 9. Mechanical supply pump.

72595








 Plunger inlet - 2. Pump lubrication pipes - 3. Plunger inlet - 4. Main plunger supply pipe - 5. Pressure regulator -6. Plunger inlet - 7. Regulator drainpipe - 8. Pressure limiting valve 5 bar - 9. Fuel discharge from regulator inlet.

Figure 17 shows the routes of the fuel at low pressure inside the pump; it shows the main supply pipe of the pumping elements (4), the pumping element supply pipes (1 - 3 - 6), the pipes used to lubricate the pump (2), the pressure regulator (5), the 5-bar pressure relief valve (8) and the fuel discharge (7).

Pump shaft is lubricated by fuel through delivery and return ducts (2).

The pressure regulator (5) establishes the quantity of fuel to be supplied to the plungers; The excess fuel flows off through the pipe (9).

The 5 bar relief valve, in addition to functioning as a collector for fuel discharge, has the function of keeping the pressure constant at 5 bar at the entrance of the regulator.



Operation

The cylinder is filled through the plate intake valve only if the supply pressure can open the delivery valves on the plungers (approx. 2 bar).

The amount of fuel that supplies the high pressure pump is metered by the pressure regulator, positioned on the low pressure system; the pressure regulator is controlled by the EDC 7 control unit through a PWM signal.

If the fuel is sent to the plunger, its piston is moving down (intake stroke). When the piston stroke inverts, the intake valve closes and the fuel remaining in the plunger chamber, which cannot exit, is compressed beyond the existing supply pressure in the rail.

The pressure generated this way causes the discharge valve to open and the compressed fuel reaches the high pressure circuit.

The plunger compresses the fuel till the top dead centre (delivery stroke) is reached. Then the pressure decreases so that the discharge valve closes.

The plunger piston returns to the bottom dead centre and the residual fuel is decompressed.

When the pressure in the plunger chamber is lower than the supply pressure, the intake valve opens again and the cycle is repeated.

The delivery valves must always be free in their movement, with no impurities or oxidation.


The rail delivery pressure is modulated between 250 and 1,600 bar by the electronic control unit through the solenoid valve of the pressure regulator.

The pump is lubricated and cooled by the same fuel.

The removal - refitting time of the radial jet pump on the engine is significantly reduced compared to traditional injection pumps because no timing is necessary.

In the event of removal - refitting of the fuel filter pipe and high pressure pump, make sure hands and components are as clean as possible.

Rail (pressure accumulator)



 Rail. - 2. High pressure overpressure valve. -3 Entrance of fuel from the pump -4. Pressure sensor.

The rail volume is of reduced size to allow a quick pressurisation at start-up, at idle and in case of high flow-rates.

It anyway has enough volume as to minimise pulsations caused by injectors openings and closings and by the high-pressure pump operation. This function is further enabled by a calibrated hole being set downstream of the high-pressure pump.


A fuel pressure sensor (4) is screwed to the rail. The signal sent by this sensor to the electronic control unit is a feed-back information, depending on which the rail pressure value is checked and, if necessary, corrected.

Overpressure valve


Once the valve has been mounted at one rail end, the valve task is to protect system components in the case where a fault in either rail pressure sensor or pump pressure regulator CP3 causes pressure excessive increment in high pressure system.

When pressure reaches 1800 bars in the rail, initially valve intervenes to drain fuel and therefore reduce pressure to safe values, then it mechanically adjusts pressure in rail at approx. 800 bars.

This valve enables to have the engine operated for long time with limited performance and inhibits fuel excessive overheating, so preserving the pipings returning from the tank.



 Pressure rod - 2. Needle - 3. Nozzle -4. Coil - 5. Pilot valve - 6. Ball shutter Control area - 8. Pressure chamber - 9. Control volume 10. Control duct - 11. Supply pipe - 12. Control fuel outlet -13. Power connection - 14. Spring -15. High pressure fuel inlet.



When coil (4) is energised, it makes shutter (6) move upwards. The control volume (9) fuel flows towards flow duct (12) making a pressure drop occur in control volume (9). Simultaneously the fuel pressure into pressure chamber (8) makes plunger (2) lift, with following fuel injection into the cylinder.

End of injection

When coil (4) is de-energised, shutter (6) goes back to its closing position, in order to re-create such a force balance as to make plunger (2) go back to its closing position and end the injection.


NOTE The electro-injector cannot be overhauled and therefore it must not be disassembled.


LUBRICATION CIRCUIT


Principles


The lubrication system includes components such as the heat exchanger, the turbocharger, for the turbocharged versions, and the compressor to the compressed air system if necessary.

All these components often vary depending on use and are therefore dealt with in the specific part of the manual.













Primary gear - 2. Secondary gear - 3. Pump body - 4. Control shaft - 5. Layshaft
 Cover - 7. Internal rotor - 8. External rotor - 9. Bushing.






Engine oil filter		
Figure 29		
		2017
	C. Filtration	U.F.I.
Explosion pressure:	20 bar (ISO 4548/3)	U.F.I. 20 bar (ISO 4548/3)
		U.F.I.
	20 bar (ISO 4548/3) 0-15 bar (1Hz) > 50,000 cycles	U.F.I. 20 bar (ISO 4548/3)
Button pressure:	20 bar (ISO 4548/3)	U.F.I. 20 bar (ISO 4548/3) 0- 15 bar (1Hz) > 50,000 cycles
Button pressure: Operating temperature:	20 bar (ISO 4548/3) 0-15 bar (1Hz) > 50,000 cycles (ISO 4548/5)	U.F.I. 20 bar (ISO 4548/3) 0- 15 bar (1Hz) > 50,000 cycles (ISO 4548/5)
Button pressure: Operating temperature: Tightening torque:	20 bar (ISO 4548/3) 0-15 bar (1Hz) > 50,000 cycles (ISO 4548/5) -40 / +140 °C	U.F.I. 20 bar (ISO 4548/3) 0- 15 bar (1Hz) > 50,000 cycles (ISO 4548/5) -40 / + 140 °C
Button pressure: Dperating temperature: Tightening torque: Maximum flow rate:	20 bar (ISO 4548/3) 0-15 bar (1Hz) > 50,000 cycles (ISO 4548/5) -40 / +140 °C 20 0/+5 Nm	U.F.I. 20 bar (ISO 4548/3) 0- 15 bar (1Hz) > 50,000 cycles (ISO 4548/5) -40 / + 140 °C 18 ± 2 Nm
Button pressure: Dperating temperature: Tightening torque: Maximum flow rate: Loss of load at end of life:	20 bar (ISO 4548/3) 0-15 bar (1Hz) > 50,000 cycles (ISO 4548/5) -40 / +140 °C 20 0/+5 Nm 100 I/mn	U.F.I. 20 bar (ISO 4548/3) 0- 15 bar (1Hz) > 50,000 cycles (ISO 4548/5) -40 / + 140 °C 18 ± 2 Nm 100 l/mn
Explosion pressure: Button pressure: Operating temperature: Tightening torque: Maximum flow rate: Loss of load at end of life: Accumulation power:	20 bar (ISO 4548/3) 0-15 bar (1Hz) > 50,000 cycles (ISO 4548/5) -40 / +140 °C 20 0/+5 Nm 100 l/mn 2.5 bar	U.F.I. 20 bar (ISO 4548/3) 0- 15 bar (1Hz) > 50,000 cycles (ISO 4548/5) -40 / + 140 °C 18 ± 2 Nm 100 l/mn 2.5 bar








201799



The system requires the presence of a valve that allows the oil to condense and fall by gravity into the underlying tappet cover.

By means of the appropriate breather, any vapours which have not condensed can be conveyed into ducts where lubrication is required such as the intake or exhaust manifolds.





I. Pre-separator - 2. Discharge to the outside (provisional) - 3. Filter - 4. Return to the engine.


The tappet cover houses the pre-separator (1), whose shape and position determines an increase in oil vapour outlet speed and condenses a part of the vapours at the same time.


Condensate oil returns to the oil sump whereas the residual vapours are ducted, collected and filtered in the blow-by (3).


In the blow-by (3), part of the vapours condense and return to the oil sump whereas the remaining part is put into cycle again through pipe (2).

















The heat exchange between the lubricant oil and the coolant (water), designed to keep the temperature within the established and control values, takes place inside of the heat exchanger. The coolant is sucked by a pump from the expansion tank, the position of which varies depending on the set-up of the engine; the fluid moves into the radiator through the conveyor and then into the flow regulator. The pump then sends the coolant to the heat exchanger (inside

of which it moves in the skirt). Upon leaving the heat exchanger, it is conveyed into the engine and then the thermostat, whose task is to regulate the circulation of the coolant. The coolant circuit ends with the return back into the radiator. The radiator dissipates the heat taken from the engine by the coolant. The dissipating power of the radiator is increased by the viscous fan which is present depending on the engine outfitting.








The water pump is of the vane centrifugal type. The pump bearing (2) forms a single piece with the spindle of the impeller. The water seal between the pump body (3) and the spindle (2) is obtained by the gasket (4).

Thermostat



THERMOSTAT DIAGRAM


operation

When the engine is cold the water comes out from the front of the cylinder head entering a union where the thermostat is located, which excludes the movement of the water in the radiator. This way water circulation will take place only between the pump and the engine, allowing its rapid heating.

The thermostat valve starts to open at about 80° C, allowing water circulation through the radiator and simultaneously blocking the direct return to the engine.

Check that the thermostat works properly, replace it if there is any doubt.

- I. Start stroke at approximately $79^{\circ} \pm 2 {\circ}C$
- 2. Stroke of 7.5 mm at 96 °C




I. Gaskets - 2. Internal heat exchanger element (7 elements) - 3. Heat exchanger body -4. Pressure regulator valve

The heat exchanger, installed in the engine cooling system, has the task of regulating the oil temperature by subtracting heat through the use of coolant.


Pressure range	0 2.5 MPa	
Frequency	0.5 ÷ 3 Hz	
Trend	Sinusoidal	
No. of cycles	>500000	
Explosion pressure	> 10 MPa	

Piping	
Engine	5W30
Internal oil temperature	115.6 °C
Capacity	51 dm ³ /min

Skirt	
Refrigerant	glycol
Internal coolant temperature	82.2 °C
External flow rate	230 dm ³ /min



INTAKE AND EXHAUST DIAGRAM	
Figure 45	
3	
5	
Air intake	
Uncooled compressed air	
Exhaust gas	
- Intercooled compressed air	
	202372
I. Exhaust - 2. Exhaust manifold - 3. EGR - 4. Intake manifold - 5. Intercooler - 6. Air filter	




Exhaust manifolds


The exhaust manifold however conveys the combusted gas from the cylinder chambers to the turbine.

Its internal structure allows the six flows from the chambers to come together in two distinct flows conveyed to the turbine impeller.

Figure 48 (NEF4

(NEF45 SMIF)





EGR SYSTEM (ONLY FOR NEF 45 SMIF)

In the STAGE IIIA version, the profile of the exhaust cam has been modified to allow the partial opening of the corresponding valve during the suction phase (EGR exhaust gas recirculation) with the consequent re-entry of a part of the exhaust gas into the engine cylinders.

The exhaust gases can be brought partially into the cylinders to reduce the maximum combustion temperature values responsible for the production of nitrogen oxides (NO_x) .


The exhaust gas recirculation (EGR) system, by reducing the combustion temperature through the decrease in the concentration of oxygen in the combustion chamber, thus represents an effective system for controlling the emission of NO_x .

The internal EGR system does not come with any electronically controlled elements: the system is always active.

Its configuration does not need additional elements such as control valves, pipes or heat exchangers.

The exhaust cam (B) presents an addition lobe to the main lobe (see Sec. A-A of the figure) compared to the configuration without EGR.

The additional lobe, during the suction phase of the cylinder in question, allows a quick opening of the exhaust valve by generating a recirculation due to the recall of the exhaust gas caused by the vacuum that is created inside the cylinder in the suction phase.




A. Intake valve control - B. Exhaust valve control.


SECTION 3

Electric / electronic equipment

		Page
(NERAL INFORMATION ON THE LOCATION DF ELECTRICAL COMPONENTS ON THE ENGINE	3
	Coolant temperature sensor	4
	Starter motor	4
	Water temperature sensor for KSB	4
	Oil pressure sensor	5
	Alternator	5
	Pre-post heating (if present)	5
	EDC7 UC31 electronic control unit	8
	Sensor connector (A)	10
	Injector connector (B)	10
	KSB connection cable - Stanadyne pump	
	Crankshaft sensor	12
	Timing sensor	12
	Turbocharged air pressure/temperature sensor	13
	Engine oil temperature/pressure sensor;	13
	Fuel pressure sensor	14
	Electro-injectors	15
	Resistor and contactor for pre-post heating	16
	Coolant temperature sensor	17
	Fuel temperature sensor	18
	High pressure pump - pressure regulator	19




75717





30±3 °C Opening of contacts with temperature rising

-0

20±3 °C Closer of contacts with temperature lowering








The NEF F4HE engines are entirely managed by the electronic control unit. This is mounted directly on the engine by means of a heat exchanger that allows the cooling, using the elastic plugs which reduce the vibrations transmitted from the engine.

With the electronic control unit you can verify the correct operation of the engine. (see the third part of this manual, specifically dedicated to diagnostics). Listed below are the electrical and electronic components on the engine:


- I. Coolant temperature sensor.
- 2. Electro-injector.
- 3. RAIL Pressure sensor.
- 4. Air pressure/temperature sensor.
- 5. Starter motor
- 6. Timing sensor.
- 7. Pressure regulator solenoid valve.
- 8. Fuel temperature sensor.
- 9. EDC electronic control unit.
- 10. Crankshaft sensor.
- 11. Engine oil temperature/pressure sensor.
- 12. Resistor for pre-post heating.

EDC7 UC31 electronic control unit

Figure 10



A. Sensor connector - B. Injector connector - C. Chassis side connector




Print P4D32N009 E

Sensor connector (A)

ECU PIN	FUNCTION
I	-
2	-
3	-
4	-
5	-
6	-
7	-
8	-
9	Timing sensor
10	Timing sensor
	-
12	Negative for Rail pressure and temperature sensor
13	Positive for Rail pressure and temperature sensor
14	Signal from Rail pressure and temperature sensor
15	Coolant temperature sensor
16	-
17	-
18	Fuel temperature sensor signal
19	Engine speed sensor
20	-
21	-
22	-
23	Engine speed sensor
24	Negative for engine oil pressure and temperature sensor
25	Negative for air pressure and temperature sensor
26	Coolant temperature sensor
27	Signal from engine oil pressure sensor
28	Signal from engine oil temperature sensor
29	-
30	-
31	-
32	Positive for engine oil pressure and temperature sensor
33	Positive for air pressure and temperature sensor
34	Signal from air pressure sensor
35	Negative for fuel temperature sensor
36	Signal from air temperature sensor

Injector connector (B)


ecu Pin	FUNCTION
	Cylinder 5 injector
2	Cylinder 6 injector
3	Cylinder 4 injector
4	Cylinder I injector
5	Cylinder 3 injector
6	Cylinder 2 injector
7	-
8	-
9	Pressure regulator
10	Pressure regulator
	Cylinder 2 injector
12	Cylinder 3 injector
13	Cylinder I injector
14	Cylinder 4 injector
15	Cylinder 6 injector
16	Cylinder 5 injector



Crankshaft sensor

This inductive sensor is located on the left front of the engine. It generates signals obtained from changes in magnetic flux created by spaces between the teeth on the phonic wheel fitted to the crankshaft.


It is connected to the control unit at pins 19A - 23A. The sensor resistance value is ~900 Ω .



Timing sensor

This inductive type sensor is located on the rear left part of the engine. It generates the signals obtained from the magnetic flux lines that close through the holes keyed

on the gear of the camshaft. The signal generated by this sensor is used by the control unit as the injection timing signal. Although similar to the flywheel sensor, they are NOT interchangeable since it has a different outer shape. It is connected to the control unit at pins 9A - 10A. The sensor resistance value is \sim 900 Ω .



Turbocharged air pressure/temperature sensor; This component incorporates a temperature sensor and a pressure sensor. It is fitted to the intake manifold so that, by measuring the maximum quantity of air taken in, it makes it possible to determine the exact amount of fuel to be injected at each cycle. It is connected to the control unit at pins 25A - 36A - 33A - 34A. It is powered at 5 volt The voltage present at output is proportional to the pressure or temperature detected by the sensor. Pins 25A - 36A Temperature Pins 33A - 34A Pressure Engine oil temperature/pressure sensor; This component is identical to the air temperature/pressure sensor. It measures the temperature and pressure of the engine oil. It measures the engine oil temperature and pressure. It is connected to the control unit at pins 24A - 28A - 32A - 27A. It runs on 5 Volts. The detected signal is sent to the EDC control unit which in turn controls the indicator tool in the dashboard (indicator + low pressure light). The oil temperature is not shown by any of the instruments- it can only be used by the Control Unit. Pins 24A - 28A Temperature Pins 32A - 27A Pressure Figure 15 NC: ŝ বা P SENSOR Ø> PRESSURE 50324 50344 Wiring Diagram Control unit pin Ref. Description Engine Air 25A 1 Ground 24A 2 28A NTC signal (temperature) 36A 3 32A 33A Power supply +5 V 4 27A 34A Signal (pressure)

Fuel pressure sensor

Assembled on one end of the rail, measures the existing fuel pressure and informs the control unit (feed - back). The value of injection pressure is used to keep the pressure level under control and to determine the time duration of the injection electronic command.

It is connected to the control unit at pins 12A - 14A - 13A. It runs on 5 Volts.

Figure 16	<image/>	
Ref.	Description	Control unit pin
I	Ground	12A
2	Signal	14A
2		10.4

3

Power supply


13A

Electro-injectors

This is an N.O. solenoid valve. They are individually connected to the EDC control unit on connector B. The coil resistance of each individual injector is 0.56 \div 0.57 Ω .


Ref.		Description	Control unit pin
CONNECTOR I		Cylinder injector 2	15 B
	2	Cylinder injector 2	2 B
	3	Cylinder injector 1	13 B
	4	Cylinder injector 1	4 B
CONNECTOR 2		Cylinder injector 4	5 B
	2	Cylinder injector 4	I 2 B
	3	Cylinder injector 3	I B
	4	Cylinder injector 3	I 6 B


Figure 17



202382








Coolant temperature sensor


This is a variable resistance sensor that is able to measure coolant temperature and transmit a signal to the control unit reflecting the thermal conditions of the engine.

The same signal is used by the control unit to drive a temperature device, if present, in the dashboard. It is connected to the control unit at pins 15A - 26A.

Its resistance at 20 °C is about 2.50 $\dot{\Omega}$.

Figure 21





High pressure pump - pressure regulator
Figure 23
000912t
A. Pressure regulator
 The amount of fuel that supplies the high pressure pump is metered by the pressure regulator, positioned on the low pressure system; the pressure regulator is managed by the EDC7 control unit. The delivery pressure to the rail is regulated between 250 and 1450 bar by the ECU acting on the pressure regulator solenoid valve. It is a N.O. solenoid valve. It is connected to the control unit at pins 9B - 10B. Its resistance is approximately 3.2 Ω.

SECTION 4

Scheduled maintenance

	Page
Principles	3
Checks and scheduled maintenance procedures	4
Periodical maintenance	7
Unscheduled maintenance	

Principles

To ensure best operating conditions, the checks, tests and adjustments which are to be carried out on the different parts at the established time are provided on the following pages.

The frequencies of the maintenance operations are indicative since the engine use and its characteristics are essential to evaluate replacements and checks.

Not only it is permitted, but it is recommended that the staff in charge of maintenance should also perform those checking and maintenance operations which are not included in the list below, but are recommended by good-practices and particular conditions of use of the engine.


Checks and scheduled maintenance procedures	Intervals (hours)
Check the engine lubricant oil level	daily
Check engine coolant level	daily
Check cleanliness of the heat exchanger	daily
Check cleanliness of the air filter	300 hours ⁽²⁾
Check belt condition and tension	Six-months
Checking/topping-up the level of the electrolytic solution in the batteries and cleaning the terminals	Six-months
Check the condition of the exhaust duct(s)	Six-months
Periodical maintenance	
Engine lubricant oil change	600 hours ⁽³⁾⁽⁴⁾
Oil filter change	600 hours ⁽³⁾⁽⁴⁾⁽⁵⁾
•••••••••••••••••••••••••••••••••••••••	
Fuel filter replacement	600 hours ⁽¹⁾⁽³⁾⁽⁵⁾
Fuel pre-filter change	600 hours ⁽¹⁾⁽³⁾
Change oil vapour filters	900 hours ⁽³⁾⁽⁴⁾
Drain water from the fuel filter	150 hours ⁽¹⁾
Drainage/suction of water, condensation and impurities from the fuel tank/s	150 hours ⁽¹⁾
Change air filter	1200 hours ⁽⁶⁾
Change the engine coolant	1200 hours / 3 year
Unscheduled maintenance	
Visually inspect turbocharger	1200 hours
Ancillary belt replacement	1200 hours
Clean the heat exchanger (radiator)	1200 hours
Injector calibration (Mechanical engines)	1800 hours
Checking and setting the valve clearance	3000 hours
 Maximum period relating to the use of high quality fuel, (specification EN 590); it decreases depending and the alarm signals for filter clogging and/or the presence of water in the pre-filter. The filter clogging signal indicates that the filter must be replaced. If the alarm signalling water in the off, the pre-filter must be replaced. 	
2) Refers to engines with conventional and automatic tensioners	
3) Must be performed annually even if the intended operating hours are not reached	
4) Intervals valid for lubricants as specified in the REFUELLING table.	
 5) Only use filters with the following specifications: degree of filtering < 12 μm filtering efficiency β > 200. 	

6) The frequency depends on the ambient conditions and product efficiency/wear.

NOTE Checks, inspections and changes are indicative and must integrate those specifications foreseen for vehicles equipped with an NEF engine.

The data are only valid if the vehicle manufacturer observes all the installation regulations provided by FPT.

Checks and scheduled maintenance procedu-The engine oil is highly pollutant and noxious. res Check the engine lubricant oil level Given the high temperatures which are reached Only proceed when the engine is not turning and is at low inside the system, do not carry out operations immetemperature in order not to run the risk of burns. diately after the engine has stopped but wait until the temperature has fallen. Figure I (For all engines) Protect your eyes and skin from any high pressure spray of coolant. The density of the coolant should still be checked every year before the winter season and replaced at least every two years. In case of new refilling proceed with the de-aeration of the system by means of the breathers on the engine. 202110 Failure to vent the system could cause serious damage to the engine due to the presence of air poc-Use the oil dipstick to check that the lubricant oil level is between the "Min" and "Max" limits. kets in the cylinder head of the engine. If the level is insufficient, it is necessary to top up with lubricant oil which meets the international specifications ACEA E7 (high power engines): remove the lubricant oil Make sure that when the engine is cold the fluid level in plug and pour engine lubricant oil through the hole. the exchanger covers the internal elements of the exchanger. Use the oil dipstick to check that the oil level lubricant oil level does not exceed the "Max" limit. Top up if necessary, using water free of impurities. Do not use distilled water. **NOTE** if frequent top-ups are necessary, the cooling circuit must be diagnosed. The engine oil is highly pollutant and noxious. In case of contact with skin, wash thoroughly with water and detergent. If set-up requires the presence of the level indicator external 尒 Suitably protect skin and eyes; proceed in accorto the heat exchangers, refill it if necessary, taking care that dance with accident prevention standards. the fluid does not saturate the internal volume of the heat exchanger to allow the temperature increase to cause the Suitably dispose of the residuals and in accordance increase of the liquid volume. with regulations. Check cleanliness of the heat exchanger Check that the air intake surfaces of the radiators are free of impurities. Check engine coolant level The verification should be performed both when the engine is stopped and during operation. Check the pipes from the engine to the radiator, from the The use of compressed air requires the use of suitaexpansion chamber and vice versa; identify any leakage, the ble protective equipment for the hands, face and ľ. state of the pipes, particularly near the junction clamps. eyes. Check the cleanliness of the radiator, the integrity of the ventilation flaps, any leakage from the clamps, sleeves and radiating body.



Inspection of the exhaust duct

Visually check that the exhaust gas / exhaust system is not obstructed or damaged.

☐ Make sure that there is no risk of harmful fumes in the environment where the engine is being worked on. Contact the manufacturer if necessary.

Check tightening and cleanliness of battery terminals

Check that the battery terminals and cable clamps are clean, well tightened and protected by Vaseline.

In the event of dirty cable clamps and battery terminals:

- Loosen the nut and remove the terminal from the negative terminal (marked with a "-").
- Loosen the nut and remove the terminal from the positive terminal (marked with a "+").
- Use a metal brush or fine grade sand paper to clean the cable terminals and the battery terminals until they are shiny.
- □ Smear the cable terminals with Vaseline and insert them onto the battery terminals making sure that the positive pole is connected first, followed by the negative pole, and then tighten each terminal.

Check the cables and clamps for signs of wear and corrosion; if there is any deterioration, replace them.

Visually check the condition of the battery: the terminals must not show signs of deterioration and the body must not be damaged, otherwise they should be replaced.



Wear protective glasses and gloves

Check electrolyte level of the batteries

The batteries used are of reduced maintenance type. Therefore, under normal conditions of use, no top up of the electrolyte is required.


However, the routine checking of the electrolyte level is recommended.


Proceed after positioning the batteries on a horizontal surface.

- ❑ Visually check that the electrolyte level is between the "Min" and "Max" reference marks on the batteries; in the absence of any reference marks, make sure the liquid covers the lead plates contained in the elements by approx. 5 mm.
- Only use distilled water to top up the elements whose level is below the minimum.
- If the battery has to be recharged, contact a specialised workshop.

Contact the staff of a specialized workshop if all ele- ments of the battery need to be topped off with a large amount of distilled water and diagnose the state of efficiency of the system and battery.		the cc <mark>gure 4</mark>	NEF45 SMIF eng	
The batteries contain sulphuric acid, which is highly caustic and corrosive; while topping up, wear gloves and safety glasses and an apron to protect clothing. If possible, have this check performed by qualified personnel.				
During the checks do not smoke or allow naked fla- mes near the batteries. Ensure that the work area is suitably ventilated.	tempe	rature s emove ⁻	l when the engine is no so as not to run the risk the oil vapour filter (2) nders 3 - 4, acting on th	k of burns. from the tappet cover
	ot D Re	herwise epositio et cover	Screw - e the oil vapour filter e replace. n the oil vapour filter (2) (3) of cylinders 3 - 4 a Screws description) in the seat on the tap-
	(1)	3	Screw -	-
Some batteries have a single cover for the inspection plugs. To access the elements, use a lever as shown in the figure.		conta dance The F	ose of consumable mat act with them (for exal with the law. PT Technical Service N ped for this purpose.	mple filters) in accor-

Figure 5 NEF45 TE I F/TE2F engines	Periodical maintenance Engine lubricant oil change Due to the high operating temperature of the engine
	it is recommended to wear suitable protection.
	The oil reaches very high temperatures: always wear protective gloves.
	It is recommended that the oil is drained while hot. Place an appropriate container for the oil collection under the sump in correspondence with the drain plug.
Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns.	Unscrew the plug and then remove the oil level dipstick and the filler plug to facilitate the lubricant oil flow.
Remove the oil vapour filter (1), acting on the retaining	
screws (2).	The engine oil is highly pollutant and noxious.
Ref. No. Screws description (2) 3 Screw -	In case of contact with skin, wash thoroughly with water and detergent.
Make sure the oil vapour filter (1) is free from scale,	Suitably protect skin and eyes; proceed in accor- dance with accident prevention standards.
 otherwise replace. Reposition the oil vapour filter (1) in its seat on the fly- wheel and tighten the screws (2). 	Suitably dispose of the residuals and in accordance with regulations.
Ref. No. Screws description Tightening torques (2) 3 Screw - -	When draining has been completed, screw in the plug and then fill with clean oil.
Dispose of consumable materials and the parts in contact with them (for example filters) in accordance with the law.	Use only the recommended oils or oils with the characteristics required for the proper functioning of the engine. If topping up, do not mix oils with different properties.
The FPT Technical Service Network workshops are equipped for this purpose.	Failure to comply with these rules will result in the loss of guarantee assistance.
 Check the condition of the exhaust duct(s) Visually check that the exhaust gas / exhaust system is not obstructed or damaged. Make sure that there is no the risk of dangerous fumes inside the car. Contact the manufacturer if necessary. 	 Check the level using the dipstick up to obtain a filling close to the maximum level mark on the dipstick itself. Oil filter change
	NOTE The replacement of the oil filter must take place in conjunction with the changing of the lubricant oil.






- Tighten the previously loosened fitting to the specified torque.
- Dispose of the diesel that leaked during the operation according to specifications.
- Start the engine and run it at idle for a few minutes to remove any residual air.


NOTE If it is necessary to accelerate the bleeding of residual air, proceed by acting on the hand pump, even during start-up.

Change oil vapour filters







Dispose of consumable materials and the parts in contact with them (for example filters) in accordance with the law. The FPT Technical Service Network workshops are equipped for this purpose.




3

137359





Reposition the fan together with spacer in its seat and the protective grilles and tighten the relative fasteners.



Visually inspect turbocharger

Only proceed when the engine is not turning over. Visually check that the impellers of the turbine and the compressor and their relative inlets and outlets are not blocked or damaged; in this case, proceed with replacement.

Clean the heat exchanger (radiator)

Check that the air intake surfaces of the radiators are free of impurities.

Clean them using compressed air or steam.



The use of compressed air requires the use of suitable protective equipment for the hands, face and eyes.


Injector calibration (Mechanical engines)

The injectors require periodic cleaning and calibration of the exact injection pressure, through the addition or replacement of shims inserted under the spring; check the injection pressure by using a hand operated pump equipped with a pressure gauge which, operated by the lever, enables the injector calibration pressure to be obtained and which is displayed on the pump pressure gauge at the moment in which diesel delivery occurs.

During testing it is also possible to see whether the flow direction is correct and whether the injector is leaking fuel.

Clean the injectors by removing carbon deposits from the top of the sprayer with a metallic brush.

Adjust valve/rocker arm clearance



Registration of the clearance between the rocker arms and crossbars which control the intake and exhaust valves must be carried out carefully using the hex key (1) box wrench (3) and feeler gauge (2).

The clearance is:

intake valves 0.25 ± 0.05 mm

 \Box exhaust valves 0.50 \pm 0.05 mm.

SECTION 5

Removal/refitting of the main components of the engine

Т


	Page
PROCEDURE FOR REMOVAL/REFITTING OF PROTECTION GRILLE	. 5
Removal	5
Refitting	5
PROCEDURE RADIATOR REMOVAL/REFITTING	. 6
🔲 Removal	6
Refitting	7
PROCEDURE FOR FAN REMOVAL/REFITTING	. 8
🔲 Removal	8
Refitting	9
PROCEDURE FOR ANCILLARY BELT REMOVAL/REFITTING	. 10
Removal NEF45 SM1F engines	10
Refitting	10
Removal NEF45 TETF/TE2F engine	11
Refitting	11
PROCEDURE FOR ENGINE CABLE REMOVAL/REFITTING	. 12
Removal NEF45 TE1F/TE2F engines	12
Refitting	13
PROCEDURE FOR AIR FILTER REMOVAL/REFITTING	. 13
Removal	13
Refitting	13
PROCEDURE FOR ALTERNATOR REMOVAL-REFITTING	. 4


	Page
Removal NEF45 SM1F engine	14
Refitting	
Removal NEF45 TE1F/TE2F engines	14
Refitting	14
PROCEDURE FOR WATER PUMP REMOVAL/REFITTING	15
Removal	15
Refitting	15
PROCEDURE FOR THERMOSTAT REMOVAL/REFITTING	15
Removal NEF45 SM1F engines	15
Refitting	16
Removal NEF45 TE1F/TE2F engines	16
Refitting	16
PROCEDURE FOR ELECTRIC STARTER MOTOR REMOVAL/REFITTING	17
🔲 Removal	17
Refitting	17
PROCEDURE FOR TURBOCHARGER REMOVAL/REFITTING	17
🔲 Removal	17
Refitting	18
PROCEDURE FOR OIL FILTER REMOVAL/REFITTING	19
🔲 Removal	19
Refitting	19
PROCEDURE FOR HEAT EXCHANGER REMOVAL/REFITTING	19
🔲 Removal	19
Refitting	20
PROCEDURE FOR OIL SUMP REMOVAL/REFITTING	20


	Page
Removal	20
Refitting	21
DCEDURE FOR OIL PUMP REMOVAL/REFITTING	21
Removal	21
Refitting	22
DCEDURE FOR OIL VAPOUR RECIRCULATION	J 23
Removal NEF45 SMTF engines	23
Refitting	23
Removal NEF45 TETF/TE2F engines	23
Refitting	23
DCEDURE FOR LOW PRESSURE FUEL PIPE REMOVAL/REFITTING	24
Removal NEF45 SMTF engines	24
Refitting	25
Removal NEF45 TETF/TE2F engines	26
Check mechanical pump power using tool 99305453	27
Refitting	28
DCEDURE FOR HIGH PRESSURE FUEL PIPE REMOVAL/REFITTING	28
Removal NEF45 SMTF engines	28
Refitting	29
Removal NEF45 TETF/TE2F engines	30
Refitting	30
DCEDURE FOR REMOVAL/REFITTING OF	31
Removal NEF45 TETF/TE2F engines	31
Refitting	31
	Refitting

	Page
PROCEDURE FOR FUEL FILTER REMOVAL/REFITTING	31
Removal NEF45 SM1F engines	31
Refitting	31
Removal NEF45 TE1F/TE2F engines	32
Refitting	32
PROCEDURE FOR TAPPET COVER REMOVAL/REFITTING	32
Removal NEF45 SM1F engines	32
Refitting	33
Removal NEF45 TE1F/TE2F engines	33
Refitting	33
PROCEDURE FOR ROCKER ARM ASSEMBLY REMOVAL/REFITTING	34
Removal NEF45 TE1F/TE2F engines	34
Refitting	34
PROCEDURE FOR INJECTOR REMOVAL/REFITTING	35
Removal NEF45 SM1F engines	35
Refitting	35
Removal NEF45 TETF/TE2F engines	36
🔲 Refitting	36
PROCEDURE FOR FEED PUMP REMOVAL/REFITTING	37
Removal NEF45 SM1F engines	37
🔲 Refitting	39
Removal NEF45 TE1F/TE2F engines	40
Refitting	40

		Page
	DCEDURE FOR PRIMING PUMP REMOVAL/REFITTING	41
	Removal	
	NEF45 SMIF engines	41
	Refitting	41
	DCEDURE FOR ROCKER ARM ASSEMBLY REMOVAL/REFITTING	42
	Removal NEF45 SM1F engines	42
	Refitting	42
	DCEDURE FOR INTAKE MANIFOLD REMOVAL/REFITTING	44
	Removal NEF45 SM1F engines	44
	Refitting	44
	Removal NEF45 TETF/TE2F engines	45
	Refitting	46
	DCEDURE FOR EXHAUST MANIFOLD REMOVAL/REFITTING	47
	Removal NEF45 SM1F engines	47
	Refitting	47
	Removal NEF45 TETF/TE2F engines	47
	Refitting	48
PRC F	DCEDURE FOR CYLINDER HEAD REMOVAL/REFITTING	48
	Removal NEF45 SM1F engine	48
	Refitting	50
	Removal NEF45 TETF/TE2F engine	52
	Refitting	53








65	- 3 - 4 [129291]
the pipe (1), complete	with
side, unscrewing the screv	vs on


- sleeves, from the engine s DN
- Disconnect and remove the pipe (2), unscrewing the screws on the relative clamp (3).
- Disconnect and remove the pipe (4), complete with sleeves, from the engine side, unscrewing the screws on
- Properly lock the radiator unit, then release it from the base by adjusting the hardware on both sides.
- Remove the radiator unit from its seat.

Ref.	No.	Screws description
(3)	2	Screw M6x1x16
(5)	2	Screw M8x1.25x16
(6)	2	Screw M6x1x16




Ref.	No.	Screws description	Tightening torques
(2)		Screw M6x1x16	43 ± 6 Nm
(3)		Screw M8x1.25x16	43 ± 6 Nm


NOTE Check the state of wear of the rubber sleeves.



Connect the air and water pipes to the radiator assembly using the clamps (1, 2, 3 and 4) and the mounting bracket (5).

Ref.	No.	Screws description	Tightening torques
(5)		Screw M6x1x16	43 ± 6 Nm





- Mount the pipe (1).
- Tighten the screws (2).


Fit the protection grille as described in the relative procedure.


Ref.	No.	Screws description	Tightening torques
(2)	4	Screw M8x1.25	24 ± 4 Nm


PROCEDURE FOR FAN REMOVAL/REFITTING Removal


Remove the protection grille as described in the relative procedure.

Remove the radiator as described in the relevant section.










PROCEDURE FOR ANCILLARY BELT REMOVAL/REFITTING

Removal NEF45 SM1F engines

Remove the protection grille as described in the relative procedure.

Remove the radiator as described in the relevant section.

Remove the fan as described in the relevant section.



Remove the protective grille and the fan together with spacer by acting on the relative fasteners.

Loosen the screws (2 and 4) anchoring the alternator (5) to its support and the screw (1) adjusting the position of the alternator.


\Box Remove the belt (3).

Ref.	No.	Screws description
(1)		Screw M8x1.25x100
(2)	I	Screw MI0x1.5x40
(4)		Screw MI0x1.5x110

Refitting

- Place the new belt (3) inside of the shoulders of all the pulleys.
- Tighten the screw (1) adjusting the alternator (5).
- Tighten the screws (2 and 4) anchoring the alternator to its support.

Ref.	No.	Screws description	Tightening torques
()	I	Screw M8x1.25x100	-
(2)		Screw MI0x1.5x40	43 ± 6 Nm
(4)	I	Screw MI0x1.5x110	43 ± 6 Nm




BELT ASSEMBLY DIAGRAM I. Fan pulley - 2. Idler pulley - 3. Crankshaft pulley -4. Water pump - 5. Alternator

Fit the fan as described in the relevant section.

Fit the radiator as described in the relevant section.

Fit the protection grille as described in the relative procedure.



lower support and the screw (2) fixing the alternator to the bracket.

Ref.	No.	Screws description
(1)	I	Screw MI0x1.5
(2)	2	Screw MI0x1.5


Use the special tool (3) to turn the automatic tensioner (4) in the direction of the arrow and remove the belt (5).

Refitting

- Use the special tool (3) to turn the automatic tensioner in the direction of the arrow (4) and reposition the belt (5) inside the shoulders of all the pulleys.
- Tighten the bolt (1) anchoring the alternator to its lower support and the screw (2) fixing the alternator to the bracket.

Ref.	No.	Screws description	Tightening torques
(I)		Screw MI0x1.5	43 ± 6 Nm
(2)	2	Screw MI0x1.5	43 ± 6 Nm

Figure 24



202112


BELT ASSEMBLY DIAGRAM

I. Fan pulley - 2. Idler pulley - 3. Crankshaft pulley 4. Water pump - 5. Alternator 6. Automatic belt tensioner


Fit the fan as described in the relevant section.

Fit the radiator as described in the relevant section.

Fit the protection grille as described in the relative procedure.



I. Connections for electro-injectors - 2. Engine coolant temperature sensor - 3. Fuel pressure sensor cable - 4. Engine oil temperature and pressure sensor - 5. Crankshaft sensor - 6. EDC control unit 7 - 7. Pressure regulator cable - 8. Fuel heater and fuel temperature sensor cable - 9. Timing phase sensor - 10. Air temperature and pressure sensor - 11. Electro-injector.




To disconnect lower pressure fuel pipes from their couplings, press clip (1) as shown in figure B.

After removing the pipe, move the clip (1) to the locked position (Figure A) to prevent possible deformations.

Disconnect the engine cable from the connectors: electro-injector wiring (1); (10) air pressure/temperature sensor; (3) fuel pressure sensor; (6) control unit; (9) timing gear phase sensor; (2) engine coolant temperature sensor on thermostat; (5) engine rpm sensor.

Remove the clamps that hold it to the crankcase and remove it completely.




To connect lower pressure fuel pipes from their couplings, press clip (1) as shown in figure B.

After removing the pipe, move the clip (1) to the locked position (Figure A).

Connect the engine cable from the connectors: electro-injector wiring (1); (10) air pressure/temperature sensor; (3) fuel pressure sensor; (6) control unit; (9) timing gear phase sensor; (2) engine coolant temperature sensor on thermostat; (5) engine rpm sensor.

Insert the clamps that hold it to the crankcase.

PROCEDURE FOR AIR FILTER REMOVAL/REFITTING



Unscrew the screws (3) and remove the air filter (2) from its support.

[Ref.	No.	Screws description
	(3)	2	Screw M8x1.25x100

Refitting

- Place the air filter (2) in the relative position.
- Tighten the screws (3) to the support clamp.
- Connect the clamp (1).

Ref.	No.	Screws description	Tightening torques
(3)	2	Screw	-
		M8x1.25x100	

PROCEDURE FOR ALTERNATOR REMOVAL-REFITTING


Removal NEF45 SM1F engine

Remove the protection grille as described in the relative procedure.

Remove the radiator as described in the relevant section.

Remove the fan as described in the relevant section.

Remove the belt as described in the relevant section.



Unscrew the screws (2 and 4) anchoring the alternator (5) to its support and the screw (1) adjusting the position of the alternator.

Ref.	No.	Screws description
(1)	I	Screw M8x1.25x100
(2)	I	Screw MI0x1.5x40
(4)	I	Screw MI0x1.5x110

Remove the alternator (5) from its housing.

Refitting

Position the alternator (5) in its housing.

- Place the new belt (3) inside of the shoulders of all the pulleys.
- Tighten the screw (1) adjusting the alternator (5).
- Tighten the screws (2 and 4) anchoring the alternator to its support.

Ref.	No.	Screws description	Tightening torques
(1)	I	Screw M8x1.25x100	-
(2)		Screw MI0x1.5x40	43 ± 6 Nm
(4)		Screw MI0xI.5xII0	43 ± 6 Nm

Fit the fan as described in the relevant section.

Fit the radiator as described in the relevant section.

Fit the protection grille as described in the relative procedure.


Removal NEF45 TE1F/TE2F engines

Remove the protection grille as described in the relative procedure.

Remove the radiator as described in the relevant section.

Remove the fan as described in the relevant section.

Remove the belt as described in the relevant section.



Unscrew the screw (1) anchoring the alternator to its lower support and the screw (2) securing the bracket.

Ref.	No.	Screws description
(1)		Screw MI0x1.5
(2)	2	Screw MI0x1.5

Remove the alternator from its housing.

Refitting

Position the alternator in its housing.

- Use the special tool (3) to turn the automatic tensioner in the direction of the arrow (4) and reposition the belt (5) inside the shoulders of all the pulleys.
- ☐ Tighten the bolt (1) anchoring the alternator to its lower support and the screw (2) fixing the alternator to the bracket.

Ref.	No.	Screws description	Tightening torques
(1)		Screw MI0x1.5	43 ± 6 Nm
(2)	2	Screw MI0x1.5	43 ± 6 Nm

Fit the fan as described in the relevant section.

Fit the radiator as described in the relevant section.

Fit the protection grille as described in the relative procedure.


PROCEDURE FOR WATER PUMP REMOVAL/REFITTING Removal

Remove the protection grille as described in the relative procedure.

Remove the radiator as described in the relevant section.

Remove the fan as described in the relevant section.

Remove the belt as described in the relevant section.



Recover the gasket (3	3).
-----------------------	-----

Refitting

Insert the gasket (3) into the seat on the crankcase.

Position the water pump (2) in its housing and tighten the screws (1).

Ref.	No.	Screws description	Tightening torques
()	2	Screw M8x1.25	24 ± 4 Nm

Fit the belt as described in the relevant section.

Fit the fan as described in the relevant section.

Fit the radiator as described in the relevant section.


Fit the protection grille as described in the relative procedure.


PROCEDURE FOR THERMOSTAT REMOVAL/REFITTING

Removal NEF45 SMIF engines

Remove the protection grille as described in the relative procedure.


Remove the radiator as described in the relevant section.






Remove the thermostat assembly (1).

Remove the gasket (2) of the cover.






Γ	Ref.	No.	Screws description
	(1)	3	Screw MI0x1.5

Refitting

- Insert the starter motor (2) in its seat at the flywheel housing (3).
- Tighten the screws (1).

Ref.	No.	Screws description	Tightening torques
()	3	Screw MI0x1.5	43 ± 6 Nm

PROCEDURE FOR TURBOCHARGER REMOVAL/REFITTING Removal



Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns.

Place a container for the oil recovery.

Unscrew the delivery pipe (2) fittings (1).

Ref.	No.	Screws description
(1)	2	Coupling M16




Figure 40	Figure 42
Unscrew the nuts (1) securing the turbocharger (2) to	Connect the oil return pipe (2) from the turbocharger.
the exhaust manifold (3). Recover the gasket (4).	Tighten the fastening screws (1).
	Tighten the screw (3) securing the pipe to the crankcase via the fastening collar (5).
Ref. No. Screws description (1) 4 Nut MI0x1.5	Tighten the fitting (4).
Refitting	Ref. No. Screws description Tightening torques (1) 2 Screw M8x1.25 24 ± 4 Nm (3) 1 Screw M8x16 24 ± 4 Nm (4) 1 Fitting M16 36 ± 5 Nm
Figure 41	Figure 43
 Position the gasket (4) on the exhaust manifold (3). Position the turbocharger (2) in correspondence to the specific seat. Tighten the nuts (1) securing the turbocharger (2) to the exhaust manifold (3). 	 Connect the oil delivery pipe (2) to the turbocharger. Tighten the fittings (1).
	Ref. No. Screws description Tightening torques
Ref.No.Screws descriptionTightening torques(1)4Nut MI0x1.543 ± 6 Nm	(1) 2 M16 nut 36 ± 5 Nm

Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns.

Place a container for the oil recovery.

Use tool 99360076 to unscrew the oil filter (1).

Ref.	No.	Screws description
(1)		Cartridge M27x2

Refitting


Tighten the oil filter (1) in correspondence to the slot on the heat exchanger (2).

Ref.	No.	Screws description	Tightening torques
()		Cartridge M27x2	20 ± 2 Nm

PROCEDURE FOR HEAT EXCHANGER REMOVAL/REFITTING Removal

Remove the oil filter as described in the relevant section.


Remove the alternator as described in the relevant section.





Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns.

Unscrew the delivery pipe (2) fittings (1).

Ref.	No.	Screws description
(1)	2	MI6 nut







PROCEDURE FOR OIL PUMP REMOVAL/REFITTING Removal


Remove the protection grille as described in the relative procedure.

Remove the radiator as described in the relevant section.


Remove the fan as described in the relevant section.

Remove the ancillary belt as described in the relevant section.


Remove the oil sump as described in the relevant section.



Ref.	No.	Screws description
(1)	8	Screw M8x1.25x30
(2)		Screw MI0x1.5x70
(4)	6	Screw MI2xI.25x78.5
(6)	5	Screw M8x1.25x45




PROCEDURE FOR OIL VAPOUR RECIRCULATION SYSTEM REMOVAL/REFITTING Removal NEF45 SMIF engines
Figure 57
 Unscrew the screws (1) securing the oil vapour filter (2). Take out the gasket (3).
Ref. No. Screws description (1) 3 Screw M6x1x20
 Refitting Insert the gasket (3) into its seat. Fit the oil vapour filter (2) and tighten the screws (1).
Ref. No. Screws description Tightening torques (1) 3 Screw M6x1x20 -
Removal NEF45 TE1F/TE2F engines Remove the air filter as described in the relevant section
Figure 58
202398
 Unscrew the screws (1) securing the oil vapour filter (2). Remove the filter (2).
Ref. No. Screws description
(1) 3 Screw M6x1x25




Ref.	No.	Screws description
(1)	I	Screw -
(2)	2	Coupling M12x1.5x11

Refitting




- Position the pipe (3) in its seat and tighten the threaded couplings (2).
- Insert the engine breather pipe (4) in its seat.
- Tighten the support screw (1) to the clamp.


Ref.	No.	Screws description	Tightening torques
()	I	Screw -	-
(2)	2	Coupling M12x1.5x11	-




1 2 214294 Unscrew the nut (1) connecting to the injection pump Take out the quick-fit couplings (4) on the fuel filter (3) and remove the pipe (5). No. Screws description Nut -Figure 64 1 ជ្រ 2 c 3 4 202160 Unscrew the fastening screws (1) and remove the cover Recover the sound-proofing elements (2). Remove the ring for the adjustable fitting (4) from the injection pump.

Ref.	No.	Screws description
()	2	Screw M8x1.25
		L







Technical dataPressure value at
pressure gauge6 ÷ 9 bar

- If measured value is below 6 bar replace the pump, and if the value is above 9 bar replace the diesel filter.
- ☐ The pressure gauge (1) must show a pressure above 5 bar; if the pressure is lower, replace the diesel fuel filter. If the problem is not cleared, check the seals of the high pressure pump inlet and fuel filter support unions.

NOTE In Spare a new mechanical supply pump has been introduced, that is interchangeable with the previous version.

The new pump has a new seal protecting against water entering the area where the two pumps are joined, thus preventing the formation of rust which could cause breakage of the shaft connecting the high and low pressure pumps.

The pump is equipped with seal, however the single seal is provided as a spare.


When replacing the low pressure pump, accurately clean the coupling area with the high-pressure pump CP.3.3

Remove tool 99305453.

4

5

202402





PROCEDURE FOR HIGH PRESSURE FUEL PIPE REMOVAL/REFITTING Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns. Place a container for the oil recovery. **Removal** NEF45 SMIF engines Figure 75 I 2

Unscrew the screws (3) securing the tappet cover (4). Unscrew the screws (6) securing the support plate.

Ref.	No.	Screws description
(1)	6	Screw M8x1.25x25
(2)	2	Screw
(6)	2	Screw M8x1.25x16


Figure 76 2 202130 Unscrew the fittings (1) connecting to the injectors (2). Ref. No. Screws description 4 Nut MI4x1.5 (|)





Tighten the fitting nuts (1).


	Ref.	No.	Screws description	Tightening torques
ſ	()	4	Nut M14x1.5	37 ± 3 Nm



Tighten the screws (6) securing the support plate.

- Position the support clamps (2) and tighten the screws (1) securing the intake manifold (5).
- \Box Position the tappet cover (4) and tighten the screws (3).

Ref.	No.	Screws description	Tightening torques
(1)	6	Screw M8x1.25x25	24 ± 4 Nm
(2)	2	Screw	-
(1)	2	Screw M8x1.25x16	24 ± 4 Nm



Refitting






Figure 83



- Position the high pressure pipes (3).
- Screw the screws (2) to the support clamps.
- Tighten the fittings (1 and 2).

Ref.	No.	Screws description	Tightening torques
(1)	4	Connector MI4xI.5	28 ± 2 Nm
(2)	4	Connector MI4xI.5	28 ± 2 Nm

Figure 84



- \Box Position the pipe (3).
- Screw the screws (2) to the support clamps.
- Tighten the fittings (1).


Ref.	No.	Screws description	Tightening torques
()	2	Connector MI4x1.5	28 ± 2 Nm
(2)	2	Screw M6x1.5x12	-

PROCEDURE FOR REMOVAL/REFITTING OF ELECTRONIC CONTROL UNIT

Removal NEF45 TE1F/TE2F engines

Remove the engine cable as described in the relevant section.

Remove the low pressure pipe as described in the relevant section.



- Unscrew the screws (3 and 6).
- Unscrew the nut (4) and the corresponding stud (5).
- Remove the control unit (2).
- Remove the support (1).

Ref.	No.	Screws description
(3)	7	Screw M6x1x30
(4)		Nut M6x1
(5)	I	Stud M6x1x25
(6)	3	Screw M8x1.25x45

Refitting

- \Box Place the support (1) in its seat.
- Position the control unit (2).
- Tighten the stud (5) and the corresponding nut (4).
- Tighten the screws (3 and 6).

Ref.	No.	Screws description	Tightening torques
(3)	7	Screw M6x1x30	10 ± 2 Nm
(4)		Nut M6x1	10 ± 2 Nm
(5)		Stud M6x1x25	10 ± 2 Nm
(6)	3	Screw M8x1.25x45	24 ± 4 Nm

Fit the low pressure pipes as described in the relevant section. Fit the engine cable as described in the relevant section.


PROCEDUREFORFUELFILTERREMOVAL/-REFITTING

Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns.

Place a container for the oil recovery.

Removal NEF45 SM1F engines

Remove the low pressure pipe as described in the relevant section.



Unscrew the screws (1) securing to the crankcase.

Remove the fuel filter (2) together with the support and the filtering cartridge.


Ref.	No.	Screws description
(1)	2	Screw M8x1.25x25


Refitting

Set the fuel filter (2) and tighten the screws (1) securing it to the crankcase.

Ref.	No.	Screws description	Tightening torques
(1)	2	Screw M8x1.25x25	80 ± 8 Nm
(2)	2	Screw M6x1.5x12	-

Fit the low pressure pipes as described in the relevant section.





- Unscrew the cartridge (4) of the filter using tool 99360076.
- Remove the clamp (3) for supporting the pipe (2) in low pressure.
- Unscrew the screws (5) and remove the filter support (1).

Ref.	No.	Screws description
(4)	I	Cartridge M20x1.5
(5)	2	Screw MI2xI.75x30

Refitting

- Position the support (1) in the relative seat and tighten the screws (5).
- Insert the clamp (3) for supporting the pipe (2) in low pressure.
- Tighten the cartridge (4) using tool 99360076.

Ref.	No.	Screws description	Tightening torques
(4)		Cartridge M20x1.5	20 0/+5 Nm
(5)	2	Screw MI2xI.75x30	80 ± 8 Nm


Fit the low pressure pipes as described in the relevant section.


Fit the engine cable as described in the relevant section.


PROCEDURE FOR TAPPET COVER REMOVAL/REFITTING

Removal NEF45 SM1F engines

Remove the oil vapour filter as described in the relevant section








Fit the oil vapour filter as described in the relevant section.

Removal NEF45 TE1F/TE2F engines

Remove the air filter as described in the relevant section.

Remove the oil vapour filter as described in the relevant section.



- Unscrew the flanged nuts (1) and remove the elastic plugs (2).
- Remove the tappet covers (6).
- Recover the oil vapour condensation sector (3).
- Recover the gasket (4).
- Unscrew the double stem screws (5).

Ref.	No.	Screws description
(1)	4	Nut M8x1.25
(5)	4	Screw M8x1.25x17

Refitting

- Tighten the double stem screws (5).
- Insert the gasket (4) into the relative seat.
- Insert the oil vapour condensation sector (3).
- Position the tappet cover (6) in the relative seat.
- Insert the elastic plugs and tighten the screws (1).

Ref.	No.	Screws description	Tightening torques
()	4	Nut M8x1.25	24 ± 4 Nm
(5)	4	Screw M8x1.25x17	24 ± 4 Nm

Fit the oil vapour filter as described in the relevant section. Fit the air filter as described in the relevant section

PROCEDURE FOR ROCKER ARM ASSEMBLY REMOVAL/REFITTING NEF45 TE1F/TE2F ENGINES


Removal


Remove the high pressure pipe as described in the relevant section.


Remove the air filter as described in the relevant section.

Remove the oil vapour filter as described in the relevant section.

Remove the tappet cover as described in the relevant section.









MAIN DATA FOR SHAFT-ROCKER ARMS

Check the coupling surfaces between the support and the shaft: there must be no sign of excessive wear or damage. Replace if necessary.




MAIN DATA FOR ROCKER ARM ADJUSTMENT SCREW

If disassembled, check the adjustment dimension. Tighten the nut (1).



Before assembly, check the rocker arm rods: there must be no sign of any deformation; the spherical seats for contact with the rocker arm adjusting screw and with the tappets (arrows) must show no trace of seizure or wear; if they do, replace them.


Intake and exhaust valve push rods are identical and are therefore interchangeable.



PROCEDURE FOR INJECTOR REMOVAL/-REFITTING

Removal NEF45 SM1F engines

Remove the high pressure pipe as described in the relevant section.



- Unscrew the unions (3).
- Remove the injector exhaust pipe (4).
- Unscrew the ring nut (2) and remove the injector (1).

Ref.	No.	Screws description
(2)	4	Ring nut M24x1.5
(3)	4	M6x1 union

Refitting

- Insert the injector (1) together with the ring nut (2) in the specific seat.
- Tighten the ring nut (2).
- Position the injector exhaust pipe (4) and tighten the fittings (3).

Ref.	No.	Screws description	Tightening torques
(2)	4	Ring nut M24x1.5	60 ± 5 Nm
(3)	4	M6x1 union	-

Connect the high pressure pipe as described in the relevant section.

Removal NEF45 TE1F/TE2F engines


Remove the high pressure pipe as described in the relevant section.

Remove the air filter as described in the relevant section.

Remove the oil vapour filter as described in the relevant section.

Remove the tappet cover as described in the relevant section.

Remove the rocker arm assembly as described in the relevant section.



Ref.	No.	Screws description
(1)	8	Screw M6x1x35
(6)	4	Nut M22x1.5

Refitting

- Insert the injector (3) together with the fastening bracket (4).
- \Box Tighten the screws (1).
- \Box Tighten the nuts (2) fixing the wiring on the injectors.
- \Box Position the union (5).
- Tighten the nut (6) connecting the head.

Ref.	No.	Screws description	Tightening torques
		Screw M6x1x35	
(1)	8	l st phase 2 nd phase angle	3.5 ± 0.35 Nm 7.5 ± 2.5 Nm 25°+25°+25°
(6)	4	Nut M22x1.5	60 ± 5 Nm

Fit the rocker arm assembly as described in the relevant section.

Fit the tappet cover as described in the relevant section.

Fit the oil vapour filter as described in the relevant section. Fit the air filter as described in the relevant section.

Connect the high pressure pipe as described in the relevant section.

PROCEDURE FOR FEED PUMP REMOVAL/REFITTING


Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns.

Place a container for the oil recovery.

Removal NEF45 SM1F engines

Remove the low pressure pipe as described in the relevant section.

Remove the high pressure pipe as described in the relevant section.



123031


Once the starter motor is removed, fit tool 99360339 (1) to rotate the flywheel.

If it is necessary to replace the feed pump, this spare is supplied preset.

If however the pump needs to be disassembled and refitted without having undergone any repair interventions, reset it while it is still fitted on the engine and only then remove it.

The following procedure refers to the second possibility as this is the more complex one.


Identifying top dead centre with tool (99395097) - False injector




To search for the position of 1st cylinder at top dead, end of compression stroke, remove the rocker arm cover of the 1st cylinder, remove the 1st injector and position the tool (1). pre-load the dial gauge.


NOTE For the removal of the 1st injector and the tappet cover refer to the relevant section.


The required condition is obtained by turning the crankshaft appropriately until the maximum value appears on the dial gauge and making sure that the intake and exhaust valves are both closed.





Make sure that the non-drilled part (1) of the phonic wheel is positioned at the top along its vertical axis.












When fitting the feed pump on the engine, the conditions of the T.D.C at the I^{st} cylinder at the end of the compression stroke must be met.


- Fit the preset pump into its seat on the engine, fitting the shaft into the hole of the gear (without key).
- Tighten the fastening nuts (1) locking the pump flange at the centre of the slot.

Ref.	No.	Screws description	Tightening torques
()	3	Nut M8x1.25	24 ± 4 Nm

NOTE The gasket removed during pump disassembly must not be reused.

Always use original spare parts.





- Undo but do not remove screw (1) locking the rotation of the pump spindle and move the spacer with slot into the small part of the hole.
- Screw in the screw (1) until flush locking the spacer: in this way, the feed pump spindle is free to rotate.
- Remove tool 99360339 or 99360330 for locking/rotation of flywheel.

Connect the high pressure pipe as described in the relevant section.


Connect the low pressure pipe as described in the relevant section.

Removal NEF45 TEIF/TE2F engines

Remove the engine cable as described in the relevant section.

Remove the low pressure pipe as described in the relevant section.

Remove the high pressure pipe as described in the relevant section.



Ref.	No.	Screws description
(2)	3	Stud M8x1.25x5
(3)	3	Nut M8x1.25

Refitting


- Tighten the studs (2).
- \Box Position the supply pump (1) in the relative seat.
- Tighten the nuts (3).


Ref.	No.	Screws description	Tightening torques
(2)	3	Stud M8x1.25x5	-
(3)	3	Nut M8x1.25	24 ± 4 Nm

Connect the high pressure pipe as described in the relevant section.

Connect the low pressure pipe as described in the relevant section.

Fit the engine cable as described in the relevant section.





Screw M8x1.25x25

24 ± 4 Nm

ARM

NFF45

PROCEDURE FOR ROCKER ASSEMBLY REMOVAL/REFITTING SMIF engines


Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns.

Place a container for the oil recovery.

Removal

Remove the oil vapour filter as described in the relevant section.

Remove the tappet cover as described in the relevant section.




Disassemble the rocker arm mounts:


unscrew the fastening screws (1 and 2) and disassemble the mount together with the rocker arms; remove the push rods.

Repeat the operation for the remaining rocker arm mounts.

Ref.	No.	Screws description
(1)	4	Screw M8x1.25x75
(2)	4	Screw MI2xI.75xI80


Refitting





MAIN DATA FOR SHAFT-ROCKER ARMS

Check the coupling surfaces between the support and the shaft: there must be no sign of excessive wear or damage. Replace if necessary.





116391

MAIN DATA FOR ROCKER ARM ADJUSTMENT SCREW

If disassembled, check the adjustment dimension. Tighten the nut (${\sf I}$).

Ref.	No.	Screws description	Tightening torques
()	6	Nut M8x1.25	24 ± 4 Nm






Tighten the screws (1 and 2).

Ref.	No.	Screws description	Tightening torques
(1)	4	Screw M8x1.25x75	24 ± 3 Nm
(2)	4	Screw MI2xI.75xI80	
		l st phase 2 nd phase	70 ± 5 Nm 90° + 90°


Fit the tappet cover as described in the relevant section.


Fit the oil vapour filter as described in the relevant section.



U	16	been removed during the removal of the engine air	
		intake pipe. (Ref 2, Figure 125)	
	fittir	-	
	Figure	e 127	
+			
¢ ¢			
	ħ	202417	
	Inser	t the smooth bushings (2).	
]		y LOCTITE 5999 between the intake manifold and der head.	
	Place	e the intake manifold (3) in the specific seat.	
]	Tight	ten the screws (1).	


Ref.	No.	Screws description	Tightening torques
()	6	Screw M8x1.25x80	24 ± 4 Nm






To disconnect lower pressure fuel pipes from their couplings, press clip (1) as shown in figure B.

After removing the pipe, move the clip (1) to the locked position (Figure A) to prevent possible deformations.




Remove the Common Rail (3).

Ref.	No.	Screws description
(2)	3	Screw M8x1.25x125




- Unscrew the screws (1 and 4).
- Remove the intake manifold (3), together with the air pressure and temperature sensor (2).

[Ref.	No.	Screws description
	(1)	6	Screw M8x1.25x25
	(4)		Screw M8x1.25x70



Base - March 2014

PROCEDURE FOR EXHAUST MANIFOLD Figure 136 **REMOVAL/REFITTING** Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns. 1 **Removal** NEF45 SM1F engines Place a container for the oil recovery. Remove the turbocharger as described in the relevant sec-5 tion. Figure 135 tion. 202420 Unscrew the screws (3) securing the exhaust manifold Figure 137 (2). 85 Remove the exhaust manifold (2). Recover the 4 gaskets (1). \vdash Ref. No. Screws description F P (3)8 Screw MI0x1.5x65 œ۳ Refitting Position the gaskets (1). 3 Place the exhaust manifold (2) in the specific seat. Tighten the screws (1). Ref. No. Screws description Tightening torques (|).(3) 8 Screw MI0x1.5x65 55 ± 3 Nm Ref. No. Screw MI0x1.5x65 (3)8




Refitting

- Place the exhaust manifold (1) in the specific seat.
- Insert the spacers (2).
- Tighten the screws (3).

Ref.	No.	Screws description	Tightening torques
(3)	8	Screw MI0x1.5x65	55 ± 3 Nm

Figure 138



202421 Tightening sequence: 2 - 7 - 3 - 6 - 1 - 8 - 4 - 5 TIGHTENING DIAGRAM FOR EXHAUST MANIFOLD FASTENING SCREWS AS SEEN FROM ENGINE SIDE

Fit the turbocharger as described in the relevant section.

PROCEDURE FOR CYLINDER HEAD REMOVAL/REFITTING

Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns.

Place a container for the oil recovery.

Removal NEF45 SM1F engine

Remove the protection grille as described in the relative procedure.

Remove the radiator as described in the relevant section.

Remove the fan as described in the relevant section.

Remove the belt as described in the relevant section.

Remove the turbocharger as described in the relevant section.

Remove the exhaust manifold as described in the relevant section.

Remove the low pressure pipe as described in the relevant section.

Remove the high pressure pipe as described in the relevant section.

Remove the fuel filter as described in the relevant section.

Remove the intake manifold as described in the relevant section.


Remove the air filter as described in the relevant section.


Remove the oil vapour filter as described in the relevant section.


Remove the tappet cover as described in the relevant section.


Remove the injectors as described in the relevant section.

Remove the rocker arm assembly as described in the relevant section.









- Position the fan support (2), together with the fan control pulley (3).
- Tighten the screws (1).

ſ	Ref.	No.	Screws description	Tightening torques
ſ	()	4	Screw M8x25	-

Fit the rocker arm assembly as described in the relevant section.

Fit the injectors as described in the relevant section.

Fit the tappet cover as described in the relevant section. Fit the oil vapour filter as described in the relevant section. Fit the air filter as described in the relevant section.

Fit the intake manifold as described in the relevant section. Fit the fuel filter as described in the relevant section.

Connect the high pressure pipe as described in the relevant section.

Connect the low pressure pipe as described in the relevant section.

Fit the exhaust manifold as described in the relevant section. Fit the turbocharger as described in the relevant section.

Fit the belt as described in the relevant section.

Fit the fan as described in the relevant section.

Fit the radiator as described in the relevant section.

Fit the protection grille as described in the relative procedure.

Removal NEF45 TEIF/TE2F engine

Remove the protection grille as described in the relative procedure.

Remove the radiator as described in the relevant section. Remove the fan as described in the relevant section.

Remove the engine cable as described in the relevant section. Remove the belt as described in the relevant section.

Remove the turbocharger as described in the relevant section.

Remove the exhaust manifold as described in the relevant section.

Remove the low pressure pipe as described in the relevant section.


Remove the high pressure pipe as described in the relevant section.


Remove the intake manifold as described in the relevant section.

Remove the air filter as described in the relevant section. Remove the oil vapour filter as described in the relevant section.

Remove the tappet cover as described in the relevant section.

Remove the injectors as described in the relevant section. Remove the rocker arm assembly as described in the relevant section.






Recover the gasket (3).

Ref.	No.	Screws description
(1)	10	Screw MI2xI.75xI50
(4)	9	Screw MI2xI.75xI30

Refitting Figure 152 Figure 151 L 4 \subset O 87759 Position the gasket (1) on the block. Ref. No. 14 Screw **NOTE** Check that the block contact surface is clean. (|)Do not grease the gasket. It is advisable to keep the gasket within its housing until the fitting of the head. The gasket is to be fitted in such a way that the writing on the gasket can be read as shown in the figure. Figure 153 NOTE With piston protrusion equal to or less than 0.4, install the gasket with a thickness of 1.15. With piston protrusion greater than 0.4, install the 110 gasket with a thickness of 1.25. 012 013 7 🛈 **NOTE** If the valves were removed from the head, they 140 need to be refitted before fitting the head itself onto the block. **NOTE** Before re-using retaining screws take two measurements of the diameter as shown in the figure to identify diameters D1 and D2: if D1 - D2 < 0.1 mm the screw can be reused if D1 - D2 > 0.1 mm the screw must be replaced. D2 DI 75703


 Position the cylinder head on the block.
 Tighten the screws (1 and 4).
 Ref. No. Screws description Tightening torques (1) 14 Screw M12×1.75×150

		l st phase 2 nd phase	55 ± 5 Nm 90° + 90°
(4)	4	Screw MI2xI.75xI30	
		l st phase 2 nd phase	35 ± 5 Nm 90° + 90°



202432

- Lubricate the bolts and fit them on the engine head.
- ☐ The bolts must be tightened according to a "spiral" pattern, starting with the central bolts and outward. Tighten the bolts in numerous phases until they have all been correctly tightened.



Ref.	No.	Screws description	Tightening torques
(2)	4	Screw	
		l st phase 2 nd phase	27 ± 3 Nm 90° + 90°
(5)	4	Screw MI0xI.5xII0	-
(6)	2	Screw M8x1.25x30	-

Fit the rocker arm assembly as described in the relevant section.

Fit the injectors as described in the relevant section.

Fit the tappet cover as described in the relevant section.

Fit the oil vapour filter as described in the relevant section.

Fit the air filter as described in the relevant section.

Fit the intake manifold as described in the relevant section.

Connect the high pressure pipe as described in the relevant section.

Connect the low pressure pipe as described in the relevant section.

Fit the exhaust manifold as described in the relevant section.

Fit the turbocharger as described in the relevant section.

Fit the belt as described in the relevant section.

Fit the engine cable as described in the relevant section.

Fit the fan as described in the relevant section.

Fit the radiator as described in the relevant section.

Fit the protection grille as described in the relative procedure.

SECTION 6

General mechanical overhaul

		Page
MO	UNTING ON ROTATING STAND	5
	Removal of radiator assembly pipes from engine	5
	Protection grille removal	5
	Removing the radiator	6
	Fan removal	7
	Removal of components hindering bracket assembly	8
	Removal of turbocharger lubricant return pipe	8
	Removal of oil filter	8
	Starter motor removal	8
	Mounting brackets on rotating stand	9
	Engine lubricant oil drainage	9
	Engine cable removal	10
	Removal of components hindering bracket assembly	
	Removal of fuel pipes	
	Fuel filter removal	
	Feed pump removal	
	Mounting brackets on rotating stand	12
	Starter motor removal	12
	Engine lubricant oil drainage	13
	ASSEMBLY OF ENGINE AT BENCH COMPONENTS AT THE FRONT)	13
	Alternator removal	13
	Alternator mount removal	14
	Removal of water pump	14
	Removal of automatic belt tensioner and fan mount	14
	Removal of crankshaft pulley	15

	Page
Alternator removal	15
Alternator mount removal	15
Removal of water pump	16
🔲 Fan mount removal	16
DISASSEMBLY OF ENGINE AT BENCH (SIDE COMPONENTS)	16
Thermostat removal	16
Turbocharger removal	17
Removal of heat exchanger	17
Exhaust manifold removal	18
DISASSEMBLY OF ENGINE AT BENCH (COMPONENTS ON UPPER SIDE)	19
Removal of oil vapour filter	19
Intake elbow removal	19
Tappet cover removal	19
High pressure fuel pipe removal	19
DISASSEMBLY OF ENGINE AT BENCH (COMPONENTS ON RIGHT SIDE)	20
Low pressure fuel pipe removal	20
Removal of fuel filter and priming pump	21
DISASSEMBLY OF ENGINE AT BENCH (COMPONENTS ON UPPER SIDE)	22
Rocker assembly removal	22
Intake manifold removal	22
Injector removal	23
Cylinder head removal	23
DISASSEMBLY OF ENGINE AT BENCH (COMPONENTS ON UPPER SIDE)	23
Removal of oil vapour filter	23
Common Rail removal	24
Intake manifold removal	24
Tappet cover removal	24

		Page
	Rocker assembly removal	24
	Electro-injector removal	25
	Thermostat unit removal	26
	Cylinder head removal	26
	ASSEMBLY OF ENGINE AT BENCH COMPONENTS ON RIGHT SIDE)	26
	Electronic Control Unit Removal	26
	ASSEMBLY OF ENGINE AT BENCH COMPONENTS AT THE BOTTOM)	27
	Oil sump removal	27
	Suction strainer removal	27
	Sound-proofing plate removal	28
	ASSEMBLY OF ENGINE AT BENCH COMPONENTS ON RIGHT SIDE)	28
	Injection pump removal	29
	DISASSEMBLY OF ENGINE AT BENCH (COMPONENTS AT THE REAR)	29
	Removal of engine flywheel	29
	Removal of flywheel cover housing sealing ring	30
	Removal of flywheel housing	32
	Removal of timing gear	32
	Timing gear case removal	32
REM (10VAL OF ENGINE AT BENCH COMPONENTS AT THE FRONT)	33
	Removal of crankshaft pulley	33
	ASSEMBLY OF ENGINE AT BENCH COMPONENTS AT THE REAR)	33
	Removal of engine flywheel	33
	Removal of flywheel cover housing sealing ring	34
	Removal of flywheel housing	34
	Removal of timing gear	34
	Removal of timing gear case	35
	ASSEMBLY OF ENGINE AT BENCH COMPONENTS AT THE FRONT)	35

		Page
	Removing the engine - front cover sealing ring	35
	Piston-connecting rod unit removal	36
	Removal of front cover	36
	Oil pump removal	36
	ASSEMBLY OF ENGINE AT BENCH COMPONENTS AT THE BOTTOM)	36
	Removal of crankshaft	37
	ASSEMBLY OF ENGINE AT BENCH COMPONENTS AT THE REAR)	38
	Camshaft removal	38
	Camshaft bushing removal	38
	Tappet removal	38
СН	ECKS	39
	Cylinder block	39
	Checking cylinder block head contact surface	40
	Timing system	40
	Measuring main journals and connecting rod .	45
	Connecting rod and piston assembly	54
	Valve unit removal	56
	Valve unit removal	59
	Lifting eyelet removal	59
	Refitting the second lifting eyelet	63
	Cylinder head assembly fitting	63
	Removal of valve seats	63
	Refitting valve assembly	63
	Refitting of valve seats	64
	Lifting eyelet refitting	64
	Refitting valve assembly	64
	GINE ASSEMBLY AT BENCH CRANKCASE COMPONENTS)	66
	Refitting tappets	66
	Refitting camshaft	66

		Page
	Refit the oil sprayers and main half bearings	66
	Crankshaft refitting	67
	Pisting-connecting rod refitting	67
	Main bearing caps refitting	68
	Connecting rod caps refitting	69
	Piston protrusion check	70
	EMBLY OF ENGINE AT BENCH COMPONENTS AT THE FRONT)	70
	Oil pump refitting	70
	Removing the front cover sealing ring	70
	Refitting front cover	71
	Refitting the engine - front cover sealing ring .	71
	EMBLY OF ENGINE AT BENCH COMPONENTS AT THE REAR)	72
	Timing gear case refitting	72
	Camshaft gear refitting	73
	Refitting engine flywheel housing	74
	Refitting flywheel cover housing sealing ring	75
	Refitting engine flywheel	75
ASS (EMBLY OF ENGINE AT BENCH COMPONENTS AT THE FRONT)	76
	Crankshaft pulley refitting	76
	EMBLY OF ENGINE AT BENCH COMPONENTS AT THE REAR)	77
	Timing gear case refitting	77
	Camshaft gear refitting	78
	Injection pump refitting	80
	Refitting engine flywheel housing	80
	Refitting engine flywheel	81
E	DCEDURE FOR MOUNTING THE "ADC100" LECTRONIC ACTUATOR ON STANADYNE ERIES "D" INJECTION PUMPS''	83
	ITCHING FROM 50 HZ FOR NEF ENGINES VITH STANADYNE PUMP	85

Print P4D32N009 E

ASSEMBLY OF ENGINE AT BENCH

(COMPONENTS ON RIGHT SIDE)

Refitting of fuel filter and priming pump

Refitting low pressure pipes

ASSEMBLY OF ENGINE AT BENCH (COMPONENTS AT THE TOP) 107

107

108

109

4	SECTION 6 - GENERAL MECHANICAL OVERHAUL	
		Page
	LACING ELECTROSTOP AND COLD ADVAN	NCE 88
	EMBLY OF ENGINE AT BENCH COMPONENTS AT THE BOTTOM)	92
	Sound-proofing plate refitting	92
	Suction strainer refitting	92
	Oil sump refitting	92
	EMBLY OF ENGINE AT BENCH COMPONENTS ON RIGHT SIDE)	93
	Electronic Control Unit Refitting	93
	EMBLY OF ENGINE AT BENCH COMPONENTS AT THE TOP)	94
	Cylinder head assembly refitting	94
	Thermostat unit refitting	95
	Refitting electro-injectors	95
	Refitting rocker assembly	96
	Refitting tappet covers	99
	Refitting intake manifold	100
	Common Rail Refitting	101
	Oil vapour filter refitting	101
	EMBLY OF ENGINE AT BENCH COMPONENTS AT THE FRONT)	102
	Cylinder head assembly refitting	102
	Injector refitting	103
	Refitting intake manifold	104
	Refitting rocker assembly	104
	Setting rocker free play	105

	Page
Refitting high pressure pipes	109
Refitting tappet covers	110
Intake elbow refitting	110
Oil vapour filter refitting	110
EMBLY OF ENGINE AT BENCH COMPONENTS ON THE LEFT SIDE)	
Refitting exhaust manifold;	
Refitting heat exchanger	
Turbocharger refitting	112
Thermostat unit refitting	112
EMBLY OF ENGINE AT BENCH COMPONENTS AT THE FRONT)	113
Fan support refitting	113
Refitting water pump	113
Fan support refitting	113
Refitting alternator	113
Crankshaft pulley refitting	4
Refitting of automatic belt tensioner and fan mount	115
Refitting water pump	115
Refitting alternator support	115
Refitting alternator	116
Refitting electric starter motor	116
Supply pump refitting	117
Fuel filter refitting	118
Refitting engine cable	119
Refitting electric starter motor	120
Refitting oil filter	120
Refitting lubricant oil return pipe from turbocharger	120
Refitting fan	121
Refitting radiator assembly	121

Print P4D32N009 E

MOUNTING ON ROTATING STAND

Part of the operations covered in this section can be carried out in relation to the set-up.


NOTE Overhaul operations must be performed by qualified personnel with the specific tools.

The following description covers the engine overhaul operation limited to components that differ according to the specific use.


NOTE For the needs dictated by application, some units may be placed on the motor in different positions.

The section "General mechanical overhaul" contains all the block overhaul operations.

Removal of radiator assembly pipes from engine




Protection grille removal




Open the clamps (2).


Ref.	No.	Screws description
(1)	6	Screw M6x1x16
(3)		Screw M8x1.25x16
(4)	ļ	Screw M6x1x16




Unscrew the screws (2) and remove the pipe (1) from the intake manifold.

Ref.	No.	Screws description
(2)	4	Screw M8x1.25








Attention, the oil filter contains approximately 1 kg of engine oil.

Collect and dispose of the engine oil according to applicable laws.

Ref.	No.	Screws description
(1)		Cartridge M27x2

Starter motor removal




Loosen the retaining nuts (1).

Remove the starter motor (3) and unscrew the studs (4).


Mount the support bracket 99361037 by inserting the screws (2) into the four threaded holes.

Ref.	No.	Screws description	Tightening torques
()	3	Nut MI0x1.5	-
(2)	4	Screw MI2x1.75	43 ± 6 Nm
(4)	3	Stud MI0xI.5x20	-

support.



Engine lubricant oil drainage




Drain the oil through the plug (1) located below the oil sump.


Ref.	No.	Screws description
(1)		Plug M18x1.5



The oil sump contains approximately 7.65 kg of engine oil.

Collect and dispose of the engine oil according to applicable laws.







Print P4D32N009 E

202446

202445






3


Stud MI0x1.5x20

-

(4)




DISASSEMBLY OF ENGINE AT BENCH (COMPONENTS AT THE FRONT) Alternator removal



Loosen the screw (3) anchoring the alternator to its lower support and the bolt (4) fixing the alternator to the bracket.

Ref.	No.	Screws description
(3)		Screw MI0x1.5
(4)		Screw MI0x1.5
(4)		Nut


Use the special tool (5) to turn the automatic tensioner (1) in the direction of the arrow and remove the belt (2).



Unscrew the screw (3) anchoring the alternator to its lower support and the screw (1) securing it to the bracket (2).

Ref.	No.	Screws description
(1)		Screw MI0x1.5
(3)		Screw MI0x1.5

Remove the alternator from its housing.



Screw M8x1.25x35

Removal of automatic belt tensioner and fan mount Figure 29 9 8 7 6 4 5 202151 Unscrew the screw (7) and remove the automatic belt tensioner (8). Unscrew the screws (1) and remove the belt tensioner mount (9). Unscrew the screws (5) and remove the spacer (4) for the fan coupling together with the drive pulley (3). Unscrew the screws (6) and remove the fan mount (2). Ref. Screws description No. (|)2 Screw M8x1.25x30 (5) Screw MI0xI.5xII0 4 (6) 4 Screw Screw MI0x1.5x70 (7)Figure 30 ব্বচ্যু Œ 4 2 0 θ


se	nsor (4).		
🗋 Ur	nscrew the	e screw (2) and remove the plug (3).	
Ref.	No.	Screws description	I
Ref. (1)	No.	Screws description Screw M6x1x20	Į

Unscrew the screw (1) and remove the crankshaft rpm


2

(|)

202456



Alternator removal



□ NEF45 TETF/TE2F engine Page 17

Loosen the screws (2 and 4) anchoring the alternator (5) to its support and the screw (1) adjusting the position of the alternator.


 \Box Remove the belt (3).


Completely loosen the screws (2 and 4) anchoring the alternator (5) to its support and the screw (1) adjusting the position of the alternator.


Ref.	No.	Screws description
(1)	l	Screw M8x1.25x100
(2)	2	Screw MI0x1.5x40
(4)		Screw MI0x1.5x110

Remove the alternator (5) from its housing.


Alternator mount removal








Removal of heat exchanger





Unscrew the screws (1) and remove the oil pressure/temperature sensor (2).


	Ref.	No.	Screws description
ſ	(1)	2	Screw M6x1x20





(3)

















L






Figure 69

Electro-injector removal





Unscrew the screws (5) and remove the brackets (4) fixing the injectors (6).

ſ	Ref.	No.	Screws description
	(1)	8	M4 nut
	(2)	4	Ring nut M22×1.5
	(5)	8	Screw M6x1x35




Extract the electro-injectors (2) from the cylinder head with tool 99342101 (1).






- Unscrew the screws (1 and 5).
- Remove the suction strainer (2) together with the support strap (4).
- Recover the gaskets (3).

Ref.	No.	Screws description
(1)	2	Screw M8x1.25x20
(5)		Screw MI0x1.5x25



The following procedure refers to the second possibility as this is the more complex one.


Identifying top dead centre with tool (99395097) - False injector




214328

To search for the position of Ist cylinder at top dead, end of compression stroke, remove the rocker arm cover of the Ist cylinder, remove the Ist injector and position the tool (99395097 (1). Pre-load the dial gauge 99395604.


The required condition is obtained by turning the crankshaft appropriately until the maximum value appears on the dial gauge and making sure that the intake and exhaust valves are both closed.




Make sure that the non-drilled part (1) of the phonic wheel is positioned at the top along its vertical axis.



3)







214351 On the timing gear side, remove the small cover (2) unscrewing the screws (1) so as to access the nut (3)

Unscrew the nut (3) and recover the relative washer.


Ref.	No.	Screws description
(1)	3	Screw M8x1.25x20
(3)		Nut M14x1.5



On the side of the timing gear, unscrew the nut (1) and recover the relative washer.



Check correct setting of rotating feed pump




I. Slot on hydraulic rotor hub - 2. Synchronisation pin 99365196 - 3. Plate.


The synchronisation pin 99365196(2) has been designed for use in the event that the rotor shaft has been accidentally released.


The correct pump/engine synchronisation is obtained when synchronisation pin 99365196 (2), inserted into the hole in the plate (3), engages in the slot (1) on the outside of the hydraulic rotor hub.

Therefore:

- Remove the screw plug (3) at the centre of the plate.
- □ Insert synchronisation pin (1) 99365196 into the hole in the plate (3). The synchronized position is obtained when the synchronisation pin (2) is inserted in the slot on the hydraulic rotor hub.
- Lock the drive shaft in the correct position using the screw (1, Figure 82).
- Remove the synchronisation pin and fit the screw plug of the plate (3). Tighten the plug to a torque of 2.3 ÷ 3.4 Nm.







Removal of flywheel cover housing sealing ring

with the help of the hoist.




Figure 99 L ¢ C C â 2 --0 10 ŝ 9 20 • 3 5 4 202485


- Unscrew the screws (1, 2, 3 and 4).
- Remove the flywheel housing (5).


Removal of flywheel housing


Ref.	No.	Screws description
(1)	2	Screw MI2x1.75
(2)	2	Screw MI0x1.5
(3)	10	Screw MI0x1.5
(4)	6	Screw M12x1.75


NOTE Note the assembly position of the screws since they are of different sizes.


Removal of timing gear













(2) 4 Screw M8x1.25	Ref.	No.	Screws description
	(2)	4	Screw M8x1.25



Base - March 2014



Once the engine is disassembled, thoroughly clean the cylinder-crankcase assembly.

Use the proper rings to handle the cylinder block.


Carefully inspect the crankcase for cracks.

Check the condition of casting hole plugs. If the caps are rusted, or if there is any doubt about the efficiency of the seal, replace them.


Inspect the surfaces of the cylinder liners; they should not be scored, seized, ovalised, conical or worn to excess.

The internal diameter of the cylinder liners is checked to ascertain the extent of ovalization, taper and wear, using the bore meter (1) fitted with a dial gauge previously reset on the ring gauge (2) of the diameter of the cylinder liner.

NOTE Should the ring gauge be not available, use a micrometer for zero-setting.



Measurements shall be performed on each cylinder, at three different heights in the bore and on two planes perpendicular with each other: one parallel to the longitudinal axis of the engine (A) and the other perpendicular to it (B); the greatest wear is usually found to be on this surface and during the first measurement. Should ovalization, taper or wear be found, bore and grind the cylinders. The refacing of the cylinder liners should be made in relation to the diameter of the pistons supplied as spare parts, which are oversized by 0.4 - 0.8 mm of the nominal value and to the prescribed assembly clearance.



NOTE In case of regrinding, all cylinders are to have the same oversize (0.4 - 0.8 mm).

Check main bearing housings as follows:

- fit the main bearings caps on the supports without bearings;
- tighten the fastening screws to the specified torque;
- use the proper internal gauge to check whether the housing diameter is falling within the specified value.

Replace if higher value is found.

Checking cylinder block head contact surface

After establishing the areas of deformation, correct the contact surface with a grinding machine.

Planarity error shall not exceed 0.075 mm.


Check the state of the cylinder assembly machining plugs; if they are rusty or there is any doubt at all about their seal, replace them.

Timing system


Camshaft

Figure 116


NEF45 SM1F engine




70172




Print P4D32N009 E







Lubricate the camshaft support bushing and fit the camshaft (1) taking care not to damage the shaft support seats or bushing during this operation.



Place the plate (1) retaining the camshaft (3) with the slot facing the top side of the crankcase and the marking facing you, tighten the screws (2).

Ref.	No.	Screws description	Tightening torques
(2)	2	Screw M8x1.25x16	24 ± 4 Nm








NOTE The hammering of the bushing into the gear must be carried out in the direction of the arrow by placing it at the point indicated inFigure 128.


NOTE During assembly, the bushing (1) must be oriented so that the lubrication holes match with the ones on the seats of the crankcase.


Rated assembling play between gear bushings and pins: 0.038 \div 0.152 mm

















The clearance control of the shoulder is carried out by placing a dial gauge (2) to the magnetic base on the crankshaft (3) as shown in the figure, the normal mounting clearance is $0.068 \div 0.410$ mm.


If a greater clearance is found, replace the main half bearings of the second last rear support (1) carrying the thrust bearings and repeat the clearance check between the main half bearings and crankshaft pins.




Make sure the pistons do not show any trace of seizing, scoring, cracking or excessive wear; otherwise, replace as necessary. disassembly Figure 141 2) 60608 Removal of the piston rings (2) using the pliers 99360183 (1). Pistons are equipped with three circlips: the first, a sealing ring, with trapezoidal section; the second, a sealing ring, with chamfer cut; a scraper ring. Pistons are grouped into classes A and B for diameter. Figure 142 2 (|). 2 49024 Removal of piston pin Seeger ring (2) using the round tipped pliers (1).








Measuring the diameter of the gudgeon pin (1) with a micrometer (2).



49026

Lubricate the pin (1) and the relevant housing on the piston hubs with engine oil; Pin must be inserted in the piston with a light finger pressure and it should not come out by gravity.





to obtain the diameter of 40.987 ÷ 41.013 mm.

106220

Using a micrometer (2), measure the piston diameter (1) to determine the assembly clearance; The diameter has to be

detected at the value indicated in figure.






202200


5

61696



Check the torsion of the connecting rod (5) by comparing two points (**A** and **B**) of the pin (3) on the horizontal plane of the axis of the connecting rod.

Position the dial gauge (2) support (1) to obtain a preload of ~ 0.5 mm on the pin (3) in point **A** and then set the dial gauge (2) to zero. Move the spindle (4) with the connecting rod (5) and compare any deviation on the opposite side **B** of the pin (3): the difference between **A** and **B** must be no greater than 0.08 mm.



Bending check


Check the bending of the connecting rod (5) by comparing two points C and D of the pin (3) on the vertical plane of the axis of the connecting rod.

Position the vertical support (1) of the dial gauge (2) so that it rests on the pin (3) at point C.

Swing the connecting rod forward and backward to find the highest position of the pin and when that is reached, reset the dial gauge (2).

Move the spindle (4) with the connecting rod (5) and repeat the check on the highest point on the opposite side D of the pin (3).

The difference between point C and point ${\rm D}$ should not be greater than 0.08 mm.





Box "I": month and year of registration;


Box "N": engine variant to be completed according to engine records (last three digits of the theoretical code);


Box "P": Serial number to be assigned in the manufacturing plant;

For the remaining data to be entered onto the plate, refer to the engine details of P.N. 504257007 (file in D.B. Matrix)











Valve descale, check and grind

Remove all carbon deposits from the valves using a wire brush.


Check that the valves show no signs of seizing, cracks or burns.

Regrind the valve seats, if required, removing as little material as possible.





Lifting eyelet removal




Ref.	No.	Screws description			
(1)	2	Screw MI2x1.75x25			
(5)	4	Screw MI2xI.25x25			

Surfaces on lower side of cylinder head


Distortion found along the whole cylinder head shall not exceed 0.20 mm.

If measurement results exceed this value, regrind the cylinder head according to the values and instructions provided in the figure below.




The rated thickness A for the cylinder head is 95 ± 0.25 mm, max. metal removal must not exceed thickness B by 0.13 mm.

NOTE After regrinding, check the valve recessing and if necessary regrind the valve seats to meet the prescribed valve recess.




Remove all carbon deposits from the valves using a wire brush. Check that the valves show no signs of seizing, cracks or burns.

Regrind the valve seats, if required, removing as little material as possible.




Use micrometer (2) to measure valve (1) stem: it must be 6.990 \div 7.01 mm



Checking clearance between valve stem, valve guide and valve centring

Use a magnetic-base dial gauge (1) set as shown, the assembling clearance must be 0.056 - 0.096 mm.

Making the valve (2) turn, check that the run out error is no greater than 0.03 mm.




If valve seats cannot be restored just by regrinding, it is possible to replace them with spare seats.


Using a specific tool and taking care not to nick the cylinder head, remove as much material as possible from the valve seats until they can be removed from the cylinder head with a punch.

Heat the cylinder head to 80 \div 100° C and use a suitable driver to install new pre-cooled valve seats in it.

Then use a suitable tool to go over the valve seats according to the values shown in Figure 185.



After regrinding, check that valve (3) recessing value is the specified one by using the stand 99370415 (2) and the dial gauge 99395603 (1).



KEY DATA FOR CHECKING INTAKE AND EXHAUST VALVE SPRINGS


Before assembling, check the flexibility of the valve springs using the specific tool. Compare the elastic deformation and load data with those of the new springs shown in the following table.


NEF45 SM1F engine

	Height	Under a load of
	mm	Ν
H (free)	63.50	0
HI	49.02	329
H2	38.20	641

NEF45 TE1F/TE2F engine


	Height	Under a load of
mm		N
H (free)	47.75	0
HI	35.53	339.8 ± 19
H2	25.2	741 ± 39






Ref.	No.	Screws description	Tightening torques
(2)		Plug	12 ± 2 Nm
(3)		Plug	36 ± 5 Nm
(5)		Sensor	36 ± 5 Nm
(6)		Plug 1/2''	

Refitting of valve seats





bottom of the cylinder head (3).




Ref.	No.	Screws description	Tightening torques
()	2	Screw MI2xI.75x25	77 ± 12 Nm
(5)	4	Screw MI2xI.25x25	36 ± 5 Nm


Refitting valve assembly










Ref.	No.	Screws description	Tightening torques
(1)		Union 1/4"	-
(2)	2	Plug	12 ± 2 Nm
(3)		Plug 3/4''	36 ± 5 Nm
(4)		Plug 3/4''	36 ± 5 Nm
















ASSEMBLY OF ENGINE AT BENCH (COMPONENTS AT THE FRONT) Oil pump refitting

Ref.	No.	Screws description	Tightening torques
(2)	4	Screw M8x1.25	
		l st step	8 ± 1 Nm
		2 nd step	24 ± 4 Nm

Removing the front cover sealing ring








70210


2

202487










	କ୍ଷ୍ପ	œ	₿ ₿
e e			م و محک 3
5/			4 202485

☐ Tighten the screws (1, 2, 3 e 4) fastening the flywheel housing (5).

Ref.	No.	Screws description	Tightening torques
(1)	2	Screw MI2x1.75	85 ± 10 Nm
(2)	2	Screw MI0x1.5	49 ± 5 Nm
(3)	10	Screw MI0x1.5	49 ± 5 Nm
(4)	6	Screw MI2xI.75	85 ± 10 Nm

NOTE Before each assembly operation, check that the thread on the holes and the screws shows no sign of wear or dirt.



		he screws (2) securing the tool 99360351 from the		(CO Crar Fig	MPOI ikshaf ure 232 5 5 4 EF45 T	Y OF ENGINE AT NENTS AT THE Filt t pulley refitting	RONT)
Ref.	No.	Screws description	Tightening torques			the idler pulley and tight	en the screw (2).
(1)	8	Screw MI2xI.25x30				the pulley (3) and the fro	.,
		l st phase 2 nd phase	30 ± 4 Nm 60°		ghten t	he screws (4).	
NOTI	thre	ore each assembly oper ead on the holes and the vear or dirt.		(2) (4)	16	Screw MI0x1.5 Screw MI0x1.25x40	Tightening torques43 ± 6 Nm68 ± 7 Nm

9

6 ò

10

8 Ô

Q

5 C 0

75711


1 CO

70

2

3

202192





Tightening torques

 24 ± 4 Nm


47 ± 5 Nm

77 ± 12 Nm





Check correct setting of rotating feed pump



The synchronisation pin 99365196 (2) has been designed for use in the event that the rotor shaft has been accidentally

The correct pump/engine synchronisation is obtained when synchronisation pin 99365196 (2), inserted into the hole in the plate (3), engages in the slot (1) on the outside of the hydraulic rotor hub.


Therefore:


released.

- Remove the screw plug (3) at the centre of the plate.
- Insert synchronisation pin (1) 99365196 into the hole in the plate (3).
 The synchronized position is obtained when the synchronisation pin (2) is inserted in the slot on the hydraulic rotor hub.
- Lock the drive shaft in the correct position using the screw (1, Figure 244).
- Remove the synchronisation pin and fit the screw plug of the plate (3).
- \Box Tighten the plug to a torque of 2.3 \div 3.4 Nm.

Ref.	No.	Screws description	Tightening torques	
(3)		Plug M14x1.5	2.9 ± 0.5 Nm	

NOTE Support the pump drive gear to prevent interference or sticking when the timing gears rotate.






Tighten the screw (1) locking the pump spindle.

Remove tool 99360339 of locking/rotation of flywheel.

Ref.	No.	Screws description	Tightening torques
()		Screw M14x1.5	12.15 ± 0.125 Nm

Refitting engine flywheel housing



Perfect seal is only obtained by cleaning accurately the surface to seal.

Smear the case with LOCTITE 5999 to obtain a bead of few mm diameter.

Application must be uniform (no lumps), without any air bubbles, thin areas or gaps.

Any flaws must be corrected in as short a time as possible.


Avoid using too much material to seal the joint. Excessive sealant could come out from joint sides and cause lubricant passage clogging.


The joints must be assembled within 10 minutes after applying the sealant.

(|)

Nut MI4xI.5


90 ± 5 Nm







Ref.	No.	Screws description	Tightening torques
(1)	2	Screw M6x1	24 ± 4 Nm

Refitting engine flywheel




- Apply the tool 99346253 part (5) to the rear crankshaft tang (6), secure it by screws (4) and fit the new sealing ring (3).
- Position part (1) on part (5), fit the nut (2) until the seal ring (3) has fitted completely into flywheel housing (7).







Ref.	No.	Screws description	Tightening torques
(2)	8	Screw M12x1.25x30	
		l st phase 2 nd phase	50 ± 5 Nm 60°


NOTE Before each assembly operation, check that the thread on the holes and the screws shows no sign of wear or dirt.





- Position the electronic actuator on the injection pump with the higher part inclined slightly upwards.
- Let the electronic actuator slide towards the rear of the pump (injector side) until the "U" hook (1) of the actuator engages with the injection pump lever (2).
- cause engine overspeed conditions.
- Tighten the ADC100 actuator to the injection pump using the screws supplied with the actuator.
- Reconnect the fuel return pipe at the fitting located on the actuator.





screw of the droopsetting (2) counter-clockwise until you reach the end - do not force further, to prevent damage to the control system.

> At this stage, and always with reference to the table in the figure, turn the droop setting screw (2) clockwise by the number of turns indicated for the 60 Hz setting from the end of stroke position.

the accelerator lever until it gets to an idle rotation speed of 62 Hz (1860 rpm).

Then adjust the minimum speed screw (4) to block the accelerator lever in the new position and block both adjustment screws using the specific counternuts (1 and 4) tightening torque 3.5 - 4 Nm).

NOTE The idling speed adjustment screw (4) does not allow achievement of the minimum in the "classic" sense of the term, as the injection pump regulator imposes a higher rotation speed since it is the injection pump for the generator unit.

Switching from 60 Hz to 50 Hz

To switch from a speed of 60 Hz to a speed of 50 Hz, operate similarly to what was seen above, remembering to turn the adjustment screw for the droopsetting (2, Figure 257), rotating it 3 turns counterclockwise from the position in which it is located for operation at 60 Hz.

Stabilisation of rotation speed

In case of instability of the engine rotation speed, turn the adjustment screw for the droopsetting (2, Figure 257) slightly rotating it clockwise/counterclockwise until the rotation speed of the engine is stabilised.

Identification plate

Figure 258

 \bigcirc




116976

 \bigcirc


If you do not find the FPT plate because it is an engine with the injection pump calibrated at 50 Hz, it is necessary to apply the plate to the area shown as in SENZA CODICE stamping it as shown in the figure.


Blank identification plates can be ordered through our Spare Parts Service.




116977

If the FPT plate is already present on the injection pump, mark the new identification suffix for the new calibration and cancel the identification of the previous calibration, as shown in the figure.








NOTE Since the terminals of the component are electrically insulated from the cover, keep in mind the order of assembly of the nuts, washers and the components for the electrical connection of the electrostop terminals; one end is grounded through an appropriate element (1).

Pay attention to the position of the isolating element (4).

Fit the new electrostop on the injection pump cover using the specific kit:

- l2V-ETR
- 24V-ETR
- l2V-ETSO
- 24V-ETSO


In addition to the electrostop indicated, the kit contains all that is required for its assembling. The nuts securing the electrostop (3) to the cover (2) must be tightened to a torque of $1.1 \div 1.7$ Nm.




3

116991

Print P4D32N009 E



Remove the fastening nut (3) from the solenoid and remove the component from its seat.




L

3


202480


ത




Ref.	No.	Screws description	Tightening torques
(1)		Stud M6x1x30	10 ± 2 Nm
(4)		Nut M6x1	10 ± 2 Nm
(5)	2	Screw. M12x25	65 ± 10 Nm


Ref.	No.	Screws description	Tightening torques
(3)	7	Screw M6x1x30	10 ± 2 Nm
(4)		Nut M6x1	10 ± 2 Nm
(5)		Stud M6x1x25	10 ± 2 Nm
(6)	3	Screw M8x1.25x45	24 ± 4 Nm
(7)		Connector MI2xI.25	12 ± 2 Nm











Fit injectors (1) on the cylinder head seats, directed so that the fuel inlet hole (2) is facing the fuel manifold seat (3) side.













- Tighten the nuts (1) on the electro-injectors using torque wrench 99389834.
- Position the connectors (3) on the electro-injectors and tighten the screws (2).

Ref.	No.	Screws description	Tightening torques
(1)	8	M4 nut	1.5 ± 0.25 Nm
(2)	2	Screw M6x1x16	10 ± 2 Nm



- Apply the tools 99360221 (1) and 99360222 (2) to the flywheel housing to stop the flywheel (3) rotation.
- □ Bring the 1st cylinder to the condition of TDC (top dead centre) at the end of compression by acting with an adjustable wrench on the tool 99360222 (2) and a pin (4).




FIRING ORDER: 1 - 3 - 4 - 2

Start and rotation crankshaft	Adjust clearance intake and exhaust valves - cylinder No.
l° at PMS	I
180°	3
180°	4
180°	2

[Ref.	No.	Screws description	Tightening torques
	(2)	8	Nut M8x1.25	24 ± 4 Nm


Remove tools 99360221 and 99360222, used to block flywheel rotation.

Refitting tappet covers




by cutting the support (2) clamps and removing the screws (4) that secure it to the connections (3).

 \Box Fit a new gasket (1) on the support (2).




Ref.	No.	Screws description	Tightening torques
()	4	Nut M8x1.25	24 ± 4 Nm
(5)	4	Screw M8x1.25x17	24 ± 4 Nm

Refitting intake manifold




- Tighten the screws (1 and 8).
- Fit a new gasket (6).
- Position the cover (5) and tighten the screws (4).
- Position the air pressure sensor (3), insert a new gasket and tighten the screw (2).

Ref.	No.	Screws description	Tightening torques
(1)	6	Screw M8x1.25x25	24 ± 4 Nm
(2)		Screw M6x1x20	10 ± 2 Nm
(4)	6	Screw M6x1x20	10 ± 2 Nm
(8)		Screw M8x1.25x70	24 ± 4 Nm




SECTION 6 - GENERAL MECHANICAL OVERHAUL

Oil vapour filter refitting





- Position the pipe (3) and the threaded fittings (2).
- Insert the engine breather pipe (4).
- $\hfill\square$ Tighten the support screw (1) to the clamp.


Ref.	No.	Screws description	Tightening torques
(1)		Screw M6x1	10 ± 2 Nm
(2)	2	Coupling M12x1.5x11	20 ± 2 Nm



Ref.	No.	Screws description	Tightening torques
()	3	Screw M6x1x25	10 ± 2 Nm









Ref.	No.	Screws description	Tightening torques
(2)	4	Ring nut M24x1.5	60 ± 5 Nm


Procedure for checking compression in the cylinders using tool 99360344




- Manually actuate the engine flywheel in order to turn the engine.
- □ Tool 99395382 (2) traces the pressure trend inside the cylinder according to the combustion chamber.

Ref.	No.	Screws description	Tightening torques
()		Tool M24x1.5	60 ± 5 Nm









Repeat the operation for the remaining rocker arm units.


Ref.	No.	Screws description	Tightening torques
()	4	Screw M8x1.25x75	24 ± 3 Nm
(2)	4	Screw MI2xI.75xI80	
		l st phase 2 nd phase	70 ± 5 Nm 90° + 90°

Setting rocker free play Preliminary operations




Fit tool 99360339 (1) to rotate the flywheel with the help of a wrench.





Refitting of fuel filter and priming pump





Do not smoke or use open flames during this operation.

Do not inhale the vapours that exit the filter.

When replacing the filters, the feed system must then always be deaerated.

The filter must be previously filled with fuel to facil-NOTE itate supply system bleeding operations.


- Fit the new gasket (2).
- Position the priming pump (3) in the relative seat.
- Tighten the screws (4).
- Position the filter mount to the crankcase.
- Tighten the screws (5).
- Clean the gasket seat on the fuel filter support (1) and lightly oil the gasket on the new filtering cartridge.
- Manually tighten the new filtering cartridge until the gasket rests completely on its seat.
- Tighten further with the help of the tool 99360076 to the torque of 12.5 \pm 2.5 Nm.


Ref.	No.	Screws description	Tightening torques
(4)	2	Screw M8x1.25x25	24 ± 4 Nm
(5)	2	Screw M8x1.25x25	80 ± 8 Nm


(7)

Plug M10x1

24 ± 4 Nm








Tighten the fittings (2) connecting to the injectors.


Ref.	No.	Screws description	Tightening torques
(2)	4	M6x1x9 fitting	80 ± 8 Nm





202465

- **Tighten the screw** (2) securing the support plate.
- Tighten the support bracket fastening screws (1) at the intake manifold (3).


Ref.	No.	Screws description	Tightening torques
()	2	Screw M8x1.25x16	24 ± 4 Nm
(2)	ļ	Screw M8x1.25x25	24 ± 4 Nm







Fit the pressure control valve (4) in the relative seat.



NOTE	Before each assembly operation, check that the
	thread on the holes and the screws shows no sign
	of wear or dirt.


Screw M8x1.25x35


(2)


15


(**)NEF45 TEIF/TE2F engines

26 ± 4 Nm









Ref.	No.	Screws description	Tightening torques
(1)	2	Screw M8x1.25x30	43 ± 6 Nm
(5)	4	Screw MI0xI.5xII0	43 ± 6 Nm
(6)	4	Screw	43 ± 6 Nm
(7)	ļ	Screw MI0xI.5x70	43 ± 6 Nm


(5)

(6)

2


Screw MI0x1.5x135

MI0x1.5x70




43 ± 6 Nm

43 ± 6 Nm



Engine completion

To complete the engine assembly operations, remove the rotating stand.




From the left side:

- Lift the engine with arm 99360595 and remove it from the rotating stand 99322205.
- Unscrew the screws (1) and remove the bracket 99361037.

Ref.	No.	Screws description	Tightening torques
()	3	Screw MI2x1.75	-

Refitting electric starter motor

Figure 356




- Unscrew the screws (2) and remove the support bracket 99361037.
- Tighten the studs (4) and position the starter motor (3).
- Tighten the retaining nuts (2).

Ref.	No.	Screws description	Tightening torques
(1)	3	Nut M10x1.5	43 ± 6 Nm
(2)	4	Screw MI2x1.75	-
(4)	3	Stud MI0xI.5x20	43 ± 6 Nm


(4)

Nut MI0x1.5

43 ± 6 Nm





SECTION 6 - GENERAL MECHANICAL OVERHAUL



Tighten the fittings (1).

ſ	Ref.	No.	Screws description	Tightening torques
	()	2	Connector MI4x1.5	24 ± 4 Nm
	(3)	2	Screw M6x1x12	40 ± 5 Nm






I. Connections for electro-injectors - 2. Engine coolant temperature sensor - 3. Fuel pressure sensor cable - 4. Engine oil temperature and pressure sensor - 5. Crankshaft sensor - 6. EDC control unit 7 - 7. Pressure regulator cable - 8. Fuel heater and fuel temperature sensor cable - 9. Timing phase sensor - 10. Air temperature and pressure sensor - 11. Electro-injector.


Connect the engine cable from the connectors: electroinjector wiring (1); (10) air pressure/temperature sensor; (3) fuel pressure sensor; (6) control unit; (9) timing gear phase sensor; (2) engine coolant temperature sensor on thermostat; (5) engine rpm sensor.


Insert the clamps that hold it to the crankcase.



To connect lower pressure fuel pipes from their couplings, press clip (1) as shown in figure B.

After removing the pipe, move the clip (1) to the locked position (Figure A).





Ref.	No.	Screws description	Tightening torques
()	2	Screw M6x1x16	10 ± 2 Nm
(3)		Screw M8x1.25x16	43 ± 6 Nm

(2)

(4)


4


3

Screw MI2x1.75

Stud MI0x1.5x20


43 ± 6 Nm





Ref.	No.	Screws description	Tightening torques
(2)		Screw M7x1	13 ± 2 Nm


Refitting radiator assembly




129293

- If present, refit the turbine protection grille (2), restoring the relative mounting brackets.
- Replace the radiator unit on the crankcase, making sure to interference with the fan.
- Tighten the fastening screws (1 and 3) on both sides.

Ref.	No.	Screws description	Tightening torques
(1)	2	Screw M6x1x16	43 ± 6 Nm
(3)	l	Screw M8x1.25x16	43 ± 6 Nm





SECTION 7

technical specifications

Page

DATA - INSTALLATION CLEARANCES	3
	J

TIGHTENING TORQUES (NEF45 SM1F) 9

TIGHTENING TORQUES (NEF45 TE1F/TE2F) .

DATA - INSTALLATI	ON CLEARANC	CES		
	Туре		NEF45 SM1F	NEF45 TE1F/TE2F
CYLINDER ASSEMBLY AN	D CRANK GEARS		n	nm
	Cylinder liners	<u>⊅</u> © ØI >Ø I		÷104.024).4
	Pistons Measuring point Outer diameter Seat for pin	X Ø I Ø 3	55.9 103.714 ÷ 103.732 38.010 ÷ 38.016	49.5 103.739 ÷ 103.757 38.010 ÷ 38.016
	Piston - cylinder lir	ners	0.268 ÷ 0.310	0.243 ÷ 0.285
昌 >	Piston diameter	ØI	0.4	
×	Piston position from crankcase	×	0.28 ÷ 0.52	
Ø 3	Piston pin	Ø 3	37.994	÷ 38.000
	Piston pin - pin sea	at	0.010 ÷ 0.022	

	Туре	NEF45 SM1F	NEF45 TEIF/TE2F	
		m	m	
	Circlip slots XI X 2 X 3	2.705 ÷ 2.735 2.440 ÷ 2.460 4.030 ÷ 4.050	2.705 ÷ 2.735 2.420 ÷ 2.440 4.030 ÷ 4.050	
$\square \blacksquare \blacksquare$	Circlips S I S 2 S 3	2.560 ÷ 2.350 ÷ 3.970 ÷	- 2.380	
	Circlips - slots	0.100 ÷ 0.175 0.060 ÷ 0.110 0.040 ÷ 0.080	0.100 ÷ 0.175 0.040 ÷ 0.09 0.040 ÷ 0.080	
昌 >	Piston rings	0.4		
$\int_{x_3}^{x_1} \left\{ \begin{array}{c} x \\ x \\ x \\ x \end{array} \right\}$	Piston ring end gap in cylinder liner: X I X 2 X 3	0.30 ÷ 0.40 0.60 ÷ 0.80 0.30 ÷ 0.55		
ØI ØZ ØZ	Connecting rod small end bush seat Ø 1 Connecting rod bearings seat Ø 2	40.987 ÷ 41.013 72.987 ÷ 73.013		
	Connecting rod small end bush diameter Internal 単ム Ø3 Connecting rod half-bearings S	38.019 ÷ 38.033 1.955 ÷ 1.968		
	Piston pin - bushing	0.019 ÷	- 0.039	
直 >	Connecting rod half-bearings	0.250;	0.500	

	Туре	NEF45 SMIF	NEF45 TE1F/TE2F
CYLINDER ASSEMBLY AN	D CRANK GEARS	m	m
	Measuring point Maximum error on parallelism of connecting rod axles	-	
	Main journals Ø I Crankpins Ø 2	82.99 - 68.987 -	
S S 2	Main half-bearings S I Connecting rod half-bearings S 2	2.456 - 1.955 -	
Ø 3	Main journals No. 1-5 Ø3 No. 2-3-4 Ø 3	87.982 - 87.977 -	
	Half bearing - Main journals n° 1-5 n° 2-3-4	0.058 ÷ 0.121	
	Half bearings - crankpins	0.038 ÷ 0.116	
昌 >	Main half-bearings Connecting rod half-bearings	0.250; 0.500	
	Thrust main journal X I	37.475 ÷ 37.550	37.475 ÷ 37.545
X 2	Main journal support for thrust X 2	32.180 =	- 32.280
X3	Thrust half rings X 3	37.28 :	- 37.38
	Crankshaft thrust	0.095 ÷ 0.270	0.095 ÷ 0.265

	Туре		NEF45 SMIF	NEF45 TE1F/TE2F
YLINDER HEAD - TIMIN	IG SYSTEM		m	Im
	Valve guide seats on cylinder head	ØI	8.019 ÷ 8.039	7.042 ÷ 7.062
	Valve guide	Ø 2 Ø 3	-	-
	Valves:	Ø 4 α	7.960 ÷ 7.980 60°± 0° 7' 30''	6.990 ÷ 7.01 60°± 0° 7' 30''
		$\bigotimes 4 \alpha$	7.960 ÷ 7.980 45°± 0° 10'	6.990 ÷ 7.01 45°± 0° 10'
	Valve stem and relate	ed guide	0.039 ÷ 0.079	0.032 ÷ 0.072
	Housing on head for valve seat:	ØI ØI	46.987 ÷ 47.013 43.637 ÷ 43.663	34.837 ÷ 34.863 34.837 ÷ 34.863
	Valve seat outside o valve housing inclina cylinder head:	ation on Ø2 α Ø2	47.063 ÷ 47.089 60°± 0.5° 43.713 ÷ 43.739	34.917 ÷ 34.931 60°± 0° 7' 30'' 34.917 ÷ 34.931
×	Recessing X		45°± 0.5° 1.000 ÷ 1.520 1.000 ÷ 1.520	45°± 0.5° 0.390 ÷ 0.910 0.760 ÷ 1.280
Ś	Between valve seat and cylinder head		0.050 ÷ 0.102 0.050 ÷ 0.102	0.054 ÷ 0.094 0.054 ÷ 0.094
昌 >	Valve seats			-

	Туре		NEF45 SMIF	NEF45 TE1F/TE2F
CYLINDER HEAD - TIMING	SYSTEM			mm
	Valve spring height:			
Û _	free spring	Н	63.50	47.75
	under a load of: 329 N 641 N	HI H2	49.02 38.20	
	339.8 ± 19 N 741 ± 39 N	HI H2		35.33 25.2
×	Injector protrusion	×	It cannot be adjusted	
	Seat for camshaft bush timing system No. I (flywheel side) Camshaft seats	nings	59.222 ÷ 59.248	
$\left \begin{array}{c} \emptyset \\ 1 \\ 2 \\ 3 \\ 4 \\ 5 \end{array} \right $	n° 2-3-4-5		54.089	9 ÷ 54.139
	Camshaft journal diameter: I ⇒ 5		53.995 ÷ 54.045	
Ø	Outer diameter of bus	shings Ø		-
Ø	Inner diameter of bushings	Ø	54.08	3÷ 54.147
	Bushings and supporti	ng pins	0.038	3 ÷ 0.152

	Туре		NEF45 SM1F	NEF45 TEIF/TE2F
YLINDER HEAD - TIMIN	NG SYSTEM		m	<u>ا</u> ۱۳
	Useful cam height:			
H		Н		-
	<u> </u>	Н		-
	Tappet washer seat in crankcase	ØI	16.000 -	÷ 16.030
$\bigotimes_{j=1}^{j=1} 2^{j=1} \bigotimes_{j=1}^{j=1} 3^{j=1} \sum_{j=1}^{j=1} 3^{j=1} 3^{j=1} \sum_{j=1}^{j=1} 3^{j=1} 3^{j=1} 3^{j=1} \sum_{j=1}^{j=1} 3^{j=1} 3^{j$	Tappet outside diame	eter: Ø2 Ø3	5.929 ÷ 5.959 5.965 ÷ 5.980	15.924 ÷ 15.954 15.960 ÷ 15.975
	Between tappets and	seats		-
昌 >	Tappets			-
	Rocker-arm shaft	ØI	8.963 ÷ 8.975	21.965 ÷ 21.977
Ø 2	Rocker arms	Ø 2	19.000 ÷ 19.026	22.001 ÷ 22.027
	Between rockers and	shaft	0.025 ÷ 0.063	0.024 ÷ 0.062

TIGHTENING TORQUES (NEF45 SMIF)

	,		TORQUE	
DETAIL		Quantity	Nm	Kgm
Cooling nozzles	M8	4	15 ± 3	1.5 ± 0.3
Screws for camshaft shoulder plate	M8x1.25	2	24 ± 4	2.4 ± 0.4
Screws for main bearing caps	MI2x1.75	10	80 ± 6 9	8.0 ± 0.6 0 °
Screw for timing gear case	MI2x1.75		77 ± 12	7.7 ± 1.2
Screws for timing gear case	M8×1.25	4	24 ± 4	2.4 ± 0.4
Screws for timing gear case	M10x1.5	5	47 ± 5	4.7 ± 0.5
Screws for timing gear	M8x1.25	6	36 ± 2	3.6 ± 0.2
Screws for connecting rod caps	MI0x1.25	8	60 ± 5 6	6.0 ± 0.5 0°
Nut for injection pump gear	MI4x1.5		90 ± 5	9.0 ± 0.5
Nuts for securing injection pump	M8x1.25	3	24 ± 4	2.4 ± 0.4
Plug for heat exchanger valve	M22x1.5		80 ± 8	8.0 ± 0.8
Screws securing heat exchanger	M8×1.25	15	26 ± 4	2.6 ± 0.4
	L = 70		60 ± 5 9	6.0 ± 0.5 0 °
Screws securing cylinder head	MI2xI.75 L = 140	18	40 ± 5 (90°	4.0 ± 0.5 + 90°)
	L = 180	,	70 ± 5 (90°	7.0 ± 0.5 + 90°)
Screws securing rocker arms	M8x1.25	4	24 ± 3	2.4 ± 0.3
Nuts for tappet adjuster	M8x1.25	8	24 ± 4	2.4 ± 0.4
Screws securing tappet cover	M8x1.25	4	24 ± 4	2.4 ± 0.4
Screws for sound-proofing plate	M10x1.5	10	43 ± 5	4.3 ± 0.5
Screws securing suction strainer	M8x1.25	2	24 ± 4	2.4 ± 0.4
Screws securing suction strainer bracket	MI0x1.5	2	43 ± 5	4.3 ± 0.5
Screws fixing the oil pump	M8×1.25	4	8 ± 1 24 ± 4	0.8 ± 0.1 2.4 ± 0.4
Screws securing front cover	M8x1.25	13	24 ± 4	2.4 ± 0.4
Screws securing flywheel housing	M12x1.75	8	85 ± 10	8.5 ± 1.0
Screws securing flywheel housing	M10x1.5	12	49 ± 5	4.9 ± 0.5
Screws securing oil sump	M8x1.25	14	24 ± 4	2.4 ± 0.4
Plug on oil sump	M18x1.5		65 ± 10	6.5 ± 1.0
Screws securing front hub	MI2xI.25	6	50 ± 5	5.0 ± 0.5
Screws for pulley on front hub	M10x1.25	6	68 ± 7	6.8 ± 0.7
Plugs on cylinder head	1/2''	3	24 ± 4	2.4 ± 0.4
Plugs on cylinder head	3/1"	2	36 ± 5	3.6 ± 0.5
Plug on cylinder head	1/4''		2 ± 2	1.2 ± 0.2
Ring nut securing injectors	M24×1.5	4	60 ± 5	6.0 ± 0.5
Screws securing intake manifold	M8×1.25	8	24 ± 4	2.4 ± 0.4
Screws securing sling hook	MI2x1.75	2	77 ± 12	7.7 ± 1.2
Screws securing sling hook	M8×1.25	4	36 ± 5	3.6 ± 0.5
Screws securing alternator	M10x1.5	3	43 ± 6	4.3 ± 0.6

			TORQUE	
DETAIL		Quantity	Nm	Kgm
Nut for compressor gear control	M18x1.5 lh		165 ± 10	16.5 ± 1.0
Nut securing compressor	M12x1.75	2	77 ± 12	7.7 ± 1.2
Screws securing compressor support bracket	M8×1.25	4	24 ± 4	2.4 ± 0.4
Screws securing thermostat cover	M6x1	3	10 ± 2	1.0 ± 0.2
Nuts securing starter motor	M10x1.5	3	43 ± 6	4.3 ± 0.6
Nuts securing turbocharger	M8×1.25	4	43 ± 6	4.3 ± 0.6
Screws securing exhaust manifold	M10x1.5	8	55 ± 3	5.5 ± 0.3
Screws for alternator mount	M10x1.5	3	43 ± 6	4.3 ± 0.6
Screws for oil pressure sensor	M6x1	2	10 ± 2	1.0 ± 0.2
Plugs to crankcase	M18x1.5	3	24 ± 4	2.4 ± 0.4
Screws for plate 4896952	M6x1	2	24 ± 4	2.4 ± 0.4
Screws for water pump	M8×1.25	2	24 ± 4	2.4 ± 0.4
Screws for power steering pump	M10x1.5	2	43 ± 6	4.3 ± 0.6
Fitting for turbocharger oil delivery pipe	MI6	2	36 ± 5	3.6 ± 0.5
Screws for turbocharger oil drain pipe	M6x1	2	24 ± 4	2.4 ± 0.4
Oil level sensor	MI2xI.5	I	10 ± 2	1.0 ± 0.2
Screws securing oil level dipstick bracket	M8×1.25	2	24 ± 4	2.4 ± 0.4
Screw for oil dipstick fastening clamp	M6x1		10 ± 2	1.0 ± 0.2
Oil filter	M27x2	I	20 ± 2	2.0 ± 0.2
Screw for crankshaft speed sensor	M6x1		10 ± 2	1.0 ± 0.2
Screws for fuel filter bracket	MI2xI.75	2	80 ± 8	8.0 ± 0.8
Intake elbow clam	M7x1		13 ± 2	1.3 ± 0.2
Suction strainer mounting bracket nuts	M10x1.5	2	24 ± 4	2.4 ± 0.4
Screw for belt tensioner	M10x1.5	I	43 ± 6	4.3 ± 0.6
Screw for idler pulley 4898548	M10x1.5	1	43 ± 6	4.3 ± 0.6
Screw for idler pulley 4892356	M10x1.5	I	43 ± 6	4.3 ± 0.6
Flywheel screws	MI2xI.25	8	50 ± 5	5.0 ± 0.5 0°
Plug	MI0x1		24 ± 4	2.4 ± 0.4


TIGHTENING TORQUES (NEF45 TEIF/TE2F)

DETAIL				TORQUE	
			Quantity	Nm	Kgm
Cooling nozzles	M8		4	15 ± 3	1.5 ± 0.3
Screws for camshaft shoulder plate	M8×1.25		2	24 ± 4	2.4 ± 0.4
Screws for main bearing caps	MI2xI.75		10	80 ± 6	8.0 ± 0.6
Screw for timing gear case	MI2x1.75			77 ± 12	7.7 ± 1.2
Screws for timing gear case	M8x1.25		4	24 ± 4	2.4 ± 0.4
Screws for timing gear case	MI0x1.5		5	47 ± 5	4.7 ± 0.1
Screws for timing gear	M8x1.25		6	36 ± 2	3.6 ± 0.2
				50 ± 2	5.0 ± 0.5
Screws for connecting rod caps	M10x1.25		8	6	0°
Nut for injection pump gear	M18x1.5			105 ± 5	10.5 ± 0.5
Nuts for securing injection pump	M8×1.25		3	24 ± 4	2.4 ± 0.4
Plug for heat exchanger valve	M22x1.5			80 ± 8	8.0 ± 0.8
Screws securing heat exchanger	M8×1.25		15	26 ± 4	2.6 ± 0.4
		L = 130		35 ± 5	3.5 ± 0.5
	M12x1.75	L - 130	- 18	(90° -	+ 90°)
Screws securing cylinder head	I*II 2X1.75	L = 150	18	55 ± 5	5.5 ± 0.5
		L - 150		(90° -	+ 90°)
Screws securing rocker arms	M8x1.25		8	36 ± 5	3.6 ± 0.5
Nuts for tappet adjuster	M8×1.25		8	24 ± 4	2.4 ± 0.4
Housing securing screws	M8×1.25		3	24 ± 4	2.4 ± 0.4
Nuts securing tappet cover	MI0x1.5		4	24 ± 4	2.4 ± 0.4
Screws for sound-proofing plate	MI0x1.5		10	43 ± 5	4.3 ± 0.5
Nuts fixing wiring on injectors	M4		8	1.5 ± 0.25	0.2 ± 0.03
Screws securing suction strainer	M8×1.5		2	24 ± 4	2.4 ± 0.4
Screws securing suction strainer bracket	MI0x1.5		2	43 ± 5	4.3 ± 0.5
Screws fixing the oil pump	M8x1.25		4	8 ± 1	0.8 ± 0.1
	11021.25		Т	24 ± 4	2.4 ± 0.4
Screws securing front cover	M8×1.25		13	24 ± 4	2.4 ± 0.4
Screws securing flywheel housing	MI2xI.75		8	85 ± 10	8.5 ± 1.0
Screws securing flywheel housing	M10x1.5		12	49 ± 5	4.9 ± 0.5
Screws securing oil sump	M8×1.25		4	24 ± 4	2.4 ± 0.4
Plug on oil sump	M18x1.5			60 ± 9	6.0 ± 0.9
Screws securing front hub	MI2xI.25		6	50 ± 5 90	5.0 ± 0.5
Screws for pulley on front hub	M10x1.25		6	68 ± 7	6.8 ± 0.7
Plugs on cylinder head	1/2''		3	24 ± 4	2.4 ± 0.4
Plugs on cylinder head	3/4"		2	36 ± 5	3.6 ± 0.5
Plug on cylinder head	1/4"			12 ± 2	1.2 ± 0.2
Injector retaining screws	M6x1		8	3.5 ± 0.35	0.4 ± 0.04
				7.5 ± 2.5	0.8 ± 0.3
Connectors on cylinder head	M22x1.5		4	55 ± 5	5.5 ± 0.5
Screws securing intake manifold	M8x1.25		7	24 ± 4	2.4 ± 0.4
Screws securing sling hook	MI2x1.75		2	77 ± 12	7.7 ± 1.2
Screws securing sling hook	M8×1.25		4	36 ± 5	3.6 ± 0.5

DETAIL			TORQUE	
		Quantity	Nm	Kgm
Screws securing rail to intake manifold	M8×1.25	3	36 ± 5	3.6 ± 0.5
Screws securing alternator	MI0x1.5	3	43 ± 6	4.3 ± 0.6
Nut for compressor gear control	MI8xI.5 lh		65 ± 0	6.5 ± .0
Nut securing compressor	MI2xI.75	2	77 ± 12	7.7 ± 1.2
Screws securing compressor support bracket	M8×1.25	4	24 ± 4	2.4 ± 0.4
Screws securing thermostat cover	M6x1	3	10 ± 2	1.0 ± 0.2
Nuts securing starter motor	MI0xI.5	3	43 ± 6	4.3 ± 0.6
Nuts securing turbocharger	M8×1.25	4	43 ± 6	4.3 ± 0.6
Screws securing exhaust manifold	MI0x1.5	8	53 ± 5	5.3 ± 0.5
Screws for alternator mount	MI0x1.5	3	43 ± 6	4.3 ± 0.6
Screws for oil pressure sensor	M6x1	2	10 ± 2	1.0 ± 0.2
Plugs to crankcase	MI8x1.5	3	24 ± 4	2.4 ± 0.4
High pressure pipe fittings	MI4xI.5	2	24 ± 4	2.4 ± 0.4
Rail pipe bracket screw	MI0x1.5		40 ± 5	4.0 ± 0.5
Fittings 4896491 and 4897881	M16x1.5	4	24 ± 4	2.4 ± 0.4
Screws for plate 4896952	M6x1	2	24 ± 4	2.4 ± 0.4
Screws for water pump	M8×1.25	2	24 ± 4	2.4 ± 0.4
Screw for camshaft rpm sensor	M6x1		10 ± 2	1.0 ± 0.2
Screws for power steering pump	MI0x1.5	2	43 ± 6	4.3 ± 0.6
Sensor on cylinder heads (temperature)	MI4x1.5		24 ± 4	2.4 ± 0.4
Union 4891285	3⁄4'' - 14		36 ± 4	3.6 ± 0.4
Screws for turbocharger oil drain pipe	M6x1	2	10 ± 2	1.0 ± 0.2
Suction strainer mounting bracket nuts	M10x1.5	2	36 ± 5	3.6 ± 0.5
Breather plate screws	M6x1	3	10 ± 2	1.0 ± 0.2
Plate screw fixing breather on tappet cover	M6x1	3	10 ± 2	1.0 ± 0.2
Fittings securing breather 4899219	MI2x1.5	3	20 ± 4	2.0 ± 0.4
Oil level sensor	MI2x1.5		10 ± 2	1.0 ± 0.2
Screws securing oil level dipstick bracket	M8x1.25	2	24 ± 4	2.4 ± 0.4
Screw for oil dipstick fastening clamp	M6x1		10 ± 2	1.0 ± 0.2
Voss fitting 4896329 on cylinder head	MI2x1.5		22 ± 2	2.2 ± 0.2
Oil filter	M27x2		20 ± 2	2.0 ± 0.2
Screw for crankshaft speed sensor	M6x1		10 ± 2	1.0 ± 0.2
Screws for fuel filter bracket	MI2x1.75	2	$\frac{10 \pm 2}{80 \pm 8}$	1.0 ± 0.2 8.0 ± 0.8
Intake elbow clam	M7x1		13 ± 2	1.3 ± 0.2
Suction strainer mounting bracket nuts	MI0x1.5	2	36 ± 5	1.5 ± 0.2 3.6 ± 0.5
Plugs securing the control unit	M8x1.25	3	24 ± 4	2.4 ± 0.4
Screw for belt tensioner 4898548	MI0x1.5		27 ± 7 43 ± 6	2.4 ± 0.4 4.3 ± 0.6
Screw for idler pulley 4897031	MI0x1.5		43 ± 6 43 ± 6	4.3 ± 0.6 4.3 ± 0.6
Screw for idler pulley 4892356	MI0x1.5		43 ± 6 43 ± 6	4.3 ± 0.6 4.3 ± 0.6
	CITXUTT	1	43 ± 6 30 ± 4	4.3 ± 0.6 3.0 ± 0.4
Flywheel screws	MI2xI.25	8		3.0 ± 0.4 0°
Plug 4899009	MI0×I		24 ± 4	2.4 ± 0.4
Screws securing control unit to support	M6x1	8	10 ± 2	1.0 ± 0.2
Nuts securing heater	M8x1.25	8	13 ± 3	I.3 ± 0.3
Voss fitting 4896542 on control unit supp.	M12x1.25		12 ± 2	1.2 ± 0.2
Screws securing sensor on intake manifold.	M6x1	2	10 ± 2	1.0 ± 0.2

SECTION 8	
Tools	
	Page
EQUIPMENT	3

EQUIPMENT				
TOOL No.	k. "	NAME	F4GE	F4HE
99305453		Tool for checking diesel fuel system and common rail injection system		\checkmark
99317915		Set of five 9x12 spintite wrenches (14 - 15 - 17 - 18 - 19)		\checkmark
99322205		Revolving stand for overhauling units (capacity 1000 daN, torque 120 daNm)	~	\checkmark
99340035		Extractor for engine injection pump gear	\checkmark	
99340055		Extraction tool for crankshaft front ring seal	\checkmark	\checkmark
99340056		Extraction tool for crankshaft rear gasket	~	~



TOOL No.		NAME	F4GE	F4HE
99346253		Key to fit crankshaft rear gasket	~	✓
99360076		Tool to remove oil filter (engine)	\checkmark	\checkmark
99360183		Tool for piston ring removal and assembly (65-110mm)	\checkmark	\checkmark
99360221		Engine flywheel rotation tool (use with 99360222)		\checkmark
99360222		Pinion (use with 99360221)		\checkmark
99360268	Constant of the second s	Tool to take down and fit back engine valves	✓	\checkmark

TOOL No.	NAME	F4GE	F4HE
99360339	Tool to retain and rotate engine flywheel	\checkmark	
99360344	Coupling for compression control in cylinders (use with 99395682)	\checkmark	
99360351	Tool to retain flywheel	\checkmark	\checkmark
99360362	Drift tool for removing/fitting camshaft bushings (to be used with 99370006)	\checkmark	\checkmark
99360500	Tool for lifting the crankshaft	\checkmark	\checkmark
99360595	Arm for removing and refitting engine	\checkmark	\checkmark

TOOL No.		NAME	F4GE	F4HE
99360605		Clamp for fitting piston into cylinder liners (60 ÷ 125 mm)	\checkmark	~
99360616		Tool for engine T.D.C. positioning	\checkmark	
99361037		Brackets for fastening engine to 99322205 rotary stand	\checkmark	\checkmark
99363204	Jan State St	Tool to remove gaskets	\checkmark	\checkmark
99365196		Tool for positioning injection pump at delivery start	\checkmark	
99367121		Manual pump for measuring pressure and vacuum	✓	~

TOOL No.		NAME	F4GE	F4HE
99370006		Handgrip for interchangeable drift tools	✓	✓
99370415		Base of dial gauge for various measurements (use with 99395603)	\checkmark	\checkmark
99389829	Contraction of the second	9x12 coupling torque wrench (5-60 Nm)		\checkmark
99389834		Torque screwdriver for connector retention nut adjustment injector solenoid valve (1 - 6 Nm)		\checkmark
99395097		Tool for top dead centre control (use with 99395604)	\checkmark	
99395216		Pair of gauges for angular tightening with 1/2" and 3/4" square heads	\checkmark	\checkmark

TOOL No.	 NAME	F4GE	F4HE
99395603	Dial gauge (0 ÷ 5 mm)	\checkmark	✓
99395604	Comparator gauge (0 ÷ 10 mm)	\checkmark	
99395682	Diesel engine cylinder compression test device	\checkmark	

.

Part 2	
NEF 67 SERIES	
Sec	tion
General information	I
	C
Operating diagrams	2
Electric / electronic equipment	3
Scheduled maintenance	4
Demoval/enfitting of the main generation of the engine	5
Removal/refitting of the main components of the engine	
General mechanical overhaul	6
Technical specifications	7
Table	8
	0
Safety regulations Append	dix

2


SECTION I

General information

	Page
APPROVAL PLATE	3
CORRESPONDENCE BETWEEN TECHNICAL CODES AND COMMERCIAL CODES	4
TECHNICAL CODES	5
COMMERCIAL CODES	6
ISO VIEW	7
ENGINE VIEWS (NEF67 TM1F)	8
ISO VIEW (NEF67 TE1F/TE2F)	
ENGINE VIEWS (NEF67 TETF/TE2F)	12
GENERAL FEATURES	15


Base - March 2014


Print P4D32N009 E




CORRESPONDENCE BETWEEN TECHNICAL CODES AND COMMERCIAL CODES

Technical codes	Commercial Codes
F4GE9685C*J600	(NEF67 TMIF)
F4HE0685G*J100	NEF67 TEIF
F4HE0685F*J100	NEF67 TE2F





ISO VIEW Figure 2



(NEF67 TMIF)

They are characterised by a 4 time diesel cycle, sucked in or supercharged with 6 cylinders with 2 or 4 valves per cylinder.

They are powered with a mechanical rotary pump or an in-line pump, depending on the application.

NOTE The data, specifications and performance figures are only valid if the vehicle manufacturer complies with all the installation regulations provided by FPT.


Furthermore, the fitted appliances must always be in compliance with the torque, power and engine speed for which the engine was designed. This section consists of four parts:


☐ the part covering specific mechanical overhaul based on use, describing the operations necessary to remove and install the engine components including the cylinder head, timing gear housing and the front cover,

☐ the electric part, describing the connections of the various components, the pre-post heating control unit (only for some versions) and the sensors located on the engine;


- diagnostics;
- preventive or routine maintenance operations, with indications regarding the main operations.


199377







REAR VIEW










Print P4D32N009 E



214268



	type		F4GE9685C* J600	F4HE0685G* J100	F4HE0685F* J100
•	Cycle			Diesel 4-stroke	I
	Power supply		Turbocharged	d with turbocharger ar	nd intercooler
	Injection			Direct	
	Number and arrange cylinders	ement of		6 in line	
	Bore	mm		104	
	Stroke	mm		132	
	Total displacement	cm ³		6726	
Q	Compression ratio			17.5 : 1	
	Prime Power	kWm rpm	3.5 500	3 .5 500	50 500
	Stand-by Power	kWm rpm	25 500	45 500	165 1500
	Low idle speed	rpm		-	<u> </u>
	High idle speed	rpm		-	
	TURBOCHARGING	i	Turbocharger with Waste gate intercooler		gate
UH	Turbocharger type: Supercharger type:			Holsett HX35W	
	LUBRICATION				
bar	Oil pressure with hot (100 °C \pm 5 °C):	engine	Forced by gear pum	p, pressure relief valve	e, oil filter
SAE 15W40	at idle speed	bar		3	
API CI-4 ACEA E7	at max speed	bar		5	

	type	F4GE9685C* J600	F4HE0685C* J100	F4HE0685F* J100
	1 0	C C	Liquid Belt driven 79 ± 2 96	I
	DISTRIBUTION Start before T.D.C. Until after B.D.C. Start before B.D.C. Until after T.D.C For timing check X { m m		17° 31° 48° 9° 0.25 ± 0.05 0.50 ± 0.05	
	POWER SUPPLY Pump type:	Mechanical pump rotating STANADYNE		ure pump H CP3.3
	Nozzle type	DB 4 STANADYNE XNHM882224	CRIN2 D	LL I 37PV3
	Firing order		- 5 - 3 - 6 - 2 - 4	
bar	Injection pressure b	ar 1,800	1,6	600

	type		F4GE9685C* J600	F4HE0685C* J100	F4HE0685F* J100
REFUELLING					
	engine ⁽⁴⁾	litres		10.5	
Cooling circuit ⁽¹⁾	G-Drive ⁽⁵⁾	litres		25.5	
Lubrication circuit ^{(2) (3)}		litres (kg)	ا7 (15	7.2 48)	17.2 (15.3)
Periodic replacement:					
Sump at minimum level		litres (kg)	8 (7.		8 (7.2)
Sump at maximum level		litres (kg)	ا (۱۵	2 0.8)	5 (3.5)
Fuel tank ⁽⁴⁾		litres (kg)		- (-)	

(1). Use a 50% mixture of water and PARAFLU 11 or the equivalent corresponding to the specification SAE J1034.

(2). Use lubricants that comply with international specifications ACEA E5/E7 The consumption of oil is considered acceptable up to a quantity of 0.1% of fuel consumption.

- (3). The quantities indicated refer to the first refuel only and are relative to the engine, oil sump and filter refilling.
- (4). The quantities indicated only refer to the engine in its standard configuration.
- (5). The quantities shown are relative to the total capacity of the G-Drive including engine capacity.

<u>.</u>

Refuelling from drums or tanks can cause contamination of the diesel, with the consequent risk of damaging the injection system; if necessary, perform suitable filtration or sedimentation of the impurities before refuelling.



The data, specifications and performance figures are only valid if the vehicle manufacturer complies with all the installation instructions provided by FPT.

Furthermore, the fitted appliances must always be in compliance with the torque, power and engine speed for which the engine was designed.

Т

c

SECTION 2

OF	perating diagrams	Page
SUF	PLY SYSTEM	3
	Principles	3
	CTRICAL SYSTEM	3
	JSORS	4
		4
	Oil pressure sensor	
	Water pressure sensor	4
SEN	ISORS	4
	Pressure regulator valve	4
	Fuel heater on filter	4
	Fuel temperature sensor	4
	Pressure Sensor on Rail	4
HYI	DRAULIC SYSTEM	5
SUF	PPLY DIAGRAM	7
SUF	PPLY SYSTEM COMPONENTS	9
	Priming pump	9
	Mechanical supply pump (NEF67 TE1F/TE2F)	10
	Normal operating condition	10
	Output overpressure condition	10
	Air bleeding conditions	10
	Fuel filter	
	Feed pump	12
	Operation description	12
	High pressure pump CP3	13
	High-pressure pump internal structure	4
	Operating principle	15
	Operation	17
RAI	L (PRESSURE ACCUMULATOR)	17

NEF 67 SERIES

	Page
OVERPRESSURE VALVE	17
ELECTRO-INJECTOR	18
Injector in resting position	18
Beginning of injection	18
End of injection	18
LUBRICATION CIRCUIT	19
Principles	19
LUBRICATION DIAGRAM	21
LUBRICATION CIRCUIT COMPONENTS	22
Oil pump	22
Heat exchanger	23
Oil pressure regulating valve	24
Engine oil filter	25
Oil sump	26
Cooling nozzles	27
OIL VAPOUR RECYCLING SYSTEM	28
Principles	28
Oil vapour recycling	29
OIL VAPOUR RECYCLING DIAGRAM	30
OIL VAPOUR RECYCLING SYSTEM COMPONEN (BLOW-BY)	rs 32
Blow-by filter	32
Blow-by filter	33
COOLING CIRCUIT	34
Principles	34
COOLING DIAGRAM	36
COOLING CIRCUIT COMPONENTS	37
U Water pump	37
Thermostat	37
Heat exchanger	38

	Page
INTAKE AND EXHAUST SYSTEM	39
Principles	39
INTAKE AND EXHAUST DIAGRAM	40
INTAKE AND EXHAUST	
SYSTEM COMPONENTS	41
Intake manifolds	41
Exhaust manifolds	42
HOLSET HX35W turbocharger	43
EGR SYSTEM (ONLY FOR NEF67 TMIF)	44


SUPPLY SYSTEM

Principles


The fuel supply system is composed of:

- 🔲 Fuel tank
- Fuel delivery and return pipes
- Priming pump, mounted on the engine and controlled by the camshaft
- 🗋 Fuel filter
- Rotating feed pump
- Injector supply pipes
- lnjectors

ELECTRICAL SYSTEM



I. Water temperature sensor - 2. Oil pressure sensor



 Pressure regulation valve on Rail - 2. Fuel heater on filter -3. Fuel temperature sensor - 4. Pressure sensor on Rail

(NEF67 TMIF)

SENSORS

Oil pressure sensor

Mounted on the right side of the crankcase, measure the engine oil pressure.

Water pressure sensor

The same as the oil pressure sensor, it is fitted on the head on the right of the crankcase.

(NEF67 TEIF/TE2F)

SENSORS

Pressure regulator valve

The pressure regulator valve is fixed to the Rail and has the function of regulating and maintaining the pressure according to the engine load condition.

If the pressure is too high, the valve opens to make part of the fuel flow from the Rail to the tank; if the pressure is too low in the Rail, the valve closes and separates the high pressure side from the low pressure side.

This is a solenoid valve electronically controlled by the control unit (EDC module). Pressure variation is carried out by regulating the return flow of diesel to the tank

Fuel heater on filter


This resistor ensures that the fuel remains liquid even if temperatures fall below the freezing point. When temperatures are too low, the fuel tends to form clots that can cause clogging of electro-injectors and problems with cylinder ignition.


Fuel temperature sensor


This sensor is just like the coolant temperature sensor. It detects the fuel temperature to provide the control unit with an index of the fuel's thermal state.

Pressure Sensor on Rail


Assembled on one end of the rail, measures the existing fuel pressure and informs the control unit (feed - back). The value of injection pressure is used to keep the pressure level under control and to determine the time duration of the injection electronic command.











Print P4D32N009 E

This CP3 Common Rail injection pump system is shown in the 6-cylinder version.

The pressure regulator, placed upstream of the high-pressure pump, adjusts the fuel flow that is necessary on the low-pressure system.

Afterwards, the high-pressure pump takes care of supplying the rail properly.

This solution, only pressurising the necessary fuel, improves the energy efficiency and limits heating the fuel in the system.

The pressure relief valve (2), mounted on the high pressure pump, has the function of keeping the pressure at the entrance of the pressure regulator constant at 5 bar, regardless of the efficiency of the fuel filter and the system upstream.

The pressure relief valve (2) intervention brings about a fuel flow increase in the high-pressure pump cooling circuit, through inlet and drain piping (16) from piping (8).

The pressure relief valve seated on the cylinder head, mounted on the back of the electro-injectors (3), restricts the return flow of fuel by the electro-injectors at a pressure of $1.3 \div 2$ bar.

Two by-pass valves are placed in parallel with the mechanical supply pump.

The by-pass valve (18) allows fuel to flow from mechanical pump outlet to its inlet, when the fuel filter inlet pressure exceeds the allowed threshold value.


The by-pass valve (17) allows filling the supply system through the manual priming pump (10).

SUPPLY SYSTEM COMPONENTS

Priming pump

The pump has the function of priming the fuel in the tank and conveying it to the fuel supply pump.


This is located on the engine crankcase and is activated by the camshaft.



I. Pump - 2. Control lever - 3. Camshaft.

2


72594





Fuel filter


The filter is positioned near the feed pump and the priming pump, and has the function of retaining impurities and separating the water contained in the fuel.

At the base of the filter cartridge, there is a water bleed screw through which it is possible to drain it from time to time; a heater and temperature sensor can be placed on the support for the uses that require it (use in cold climates). On some versions, there is a water presence sensor at the base of the filtering cartridge.









Operation description

The main rotation components are the propeller shaft (1), the distribution rotor (2), the transfer pump vanes (3) and the regulator (8). Referring to Figure 12, the propeller shaft engages the distribution rotor inside the hydraulic head.

The four pistons are engaged towards each other simultaneously by the cam inner ring through the rollers and the sliding blocks that are transported into the holes located on the end of the rotor.

The number of cam lobes is equal to the number of engine cylinders.

The transfer pump positioned no the rear part of the rotor is positive cylinder type and is closed within the end plug. The end plug also contains the screen of the inlet filter and the pressure regulator of the transfer pump. The upper part of the regulator unit is pressed against the distribution rotor and forms a final seal for the transfer pump.


The distribution rotor contains two loading ports, a single axial hole and an exhaust port serving all outputs to the injection lines.


The hydraulic head contains the hole in which the rotor turns, the hole of the metering, opening and loading valves, and the fittings for the discharge outlet. The high pressure injection lines connected to the injectors are fixed to the above mentioned exhaust couplings.


High pressure pump CP3 (NEF67 TE1F/TE2F) Pump with 3 radial plungers, controlled by distribution The mechanical supply pump controlled by the high presgears, requires no timing. sure pump shaft is mounted on the rear side of the high pressure pump. The high pressure pump - feed pump assembly cannot be overhauled and therefore should not be removed and the fastening screws should not be tampered with. The only operation that can be carried out is the replacement of the drive gear and pressure regulator. Figure 14 9 8 7 2 6 3 5 4

72595

 Connection between fuel outlet and rail - 2. High pressure pump - 3. Pressure regulator - 4. Drive gear 5. Filter fuel inlet union - 6. Connection between fuel outlet and filter bracket - 7. Connection for fuel inlet from heat exchanger ECU -8. Connection between fuel outlet from mechanical pump and filter -9. Mechanical supply pump.








 Plunger inlet - 2. Pump lubrication pipes - 3. Plunger inlet - 4. Main plunger supply pipe - 5. Pressure regulator -6. Plunger inlet - 7. Regulator drainpipe - 8. Pressure limiting valve 5 bar - 9. Fuel discharge from regulator inlet.

Figure 17 shows the routes of the fuel at low pressure inside the pump; it shows the main supply pipe of the pumping elements (4), the pumping element supply pipes (1 - 3 - 6), the pipes used to lubricate the pump (2), the pressure regulator (5), the 5-bar pressure relief valve (8) and the fuel discharge (7).

Pump shaft is lubricated by fuel through delivery and return ducts (2).

The pressure regulator (5) establishes the quantity of fuel to be supplied to the plungers; The excess fuel flows off through the pipe (9).

The 5 bar relief valve, in addition to functioning as a collector for fuel discharge, has the function of keeping the pressure constant at 5 bar at the entrance of the regulator.



108609

Operation

The cylinder is filled through the plate intake valve only if the supply pressure can open the delivery valves on the plungers (approx. 2 bar).

The amount of fuel that supplies the high pressure pump is metered by the pressure regulator, positioned on the low pressure system; the pressure regulator is controlled by the EDC 7 control unit through a PWM signal.

If the fuel is sent to the plunger, its piston is moving down (intake stroke). When the piston stroke inverts, the intake valve closes and the fuel remaining in the plunger chamber, which cannot exit, is compressed beyond the existing supply pressure in the rail.

The pressure generated this way causes the discharge valve to open and the compressed fuel reaches the high pressure circuit.

The plunger compresses the fuel till the top dead centre (delivery stroke) is reached. Then the pressure decreases so that the discharge valve closes.

The plunger piston returns to the bottom dead centre and the residual fuel is decompressed.

When the pressure in the plunger chamber is lower than the supply pressure, the intake valve opens again and the cycle is repeated.

The delivery valves must always be free in their movement, with no impurities or oxidation.

The rail delivery pressure is modulated between 250 and 1,600 bar by the electronic control unit through the solenoid valve of the pressure regulator.


The pump is lubricated and cooled by the same fuel.

The removal - refitting time of the radial jet pump on the engine is significantly reduced compared to traditional injection pumps because no timing is necessary.

In the event of removal - refitting of the fuel filter pipe and high pressure pump, make sure hands and components are as clean as possible.

RAIL (PRESSURE ACCUMULATOR)

Figure 19 (NEF67 TE1F/TE2F)



I. Rail. - 2. Fuel inlet from high pressure pump. - 3. Overpressure valve -4. Pressure sensor.

The rail volume is of reduced size to allow a quick pressurisation at start-up, at idle and in case of high flow-rates.

It anyway has enough volume as to minimise pulsations caused by injectors openings and closings and by the high-pressure pump operation. This function is further enabled by a calibrated hole being set downstream of the high-pressure pump.


A fuel pressure sensor (4) is screwed to the rail. The signal sent by this sensor to the electronic control unit is a feed-back information, depending on which the rail pressure value is checked and, if necessary, corrected.

OVERPRESSURE VALVE


Once the valve has been mounted at one rail end, the valve task is to protect system components in the case where a fault in either rail pressure sensor or pump pressure regulator CP3 causes pressure excessive increment in high pressure system.

When pressure reaches 1800 bars in the rail, initially valve intervenes to drain fuel and therefore reduce pressure to safe values, then it mechanically adjusts pressure in rail at approx. 800 bars.

This valve enables to have the engine operated for long time with limited performance and inhibits fuel excessive overheating, so preserving the pipings returning from the tank.



 Pressure rod - 2. Needle - 3. Nozzle -4. Coil - 5. Pilot valve - 6. Ball shutter Control area - 8. Pressure chamber - 9. Control volume 10. Control duct - 11. Supply pipe - 12. Control fuel outlet -13. Power connection - 14. Spring -15. High pressure fuel inlet.



When coil (4) is energised, it makes shutter (6) move upwards. The control volume (9) fuel flows towards flow duct (12) making a pressure drop occur in control volume (9). Simultaneously the fuel pressure into pressure chamber (8) makes plunger (2) lift, with following fuel injection into the cylinder.

End of injection

When coil (4) is de-energised, shutter (6) goes back to its closing position, in order to re-create such a force balance as to make plunger (2) go back to its closing position and end the injection.


NOTE The electro-injector cannot be overhauled and therefore it must not be disassembled.


LUBRICATION CIRCUIT


Principles


The lubrication system includes components such as the heat exchanger, the turbocharger, for the turbocharged versions, and the compressor to the compressed air system if necessary.

All these components often vary depending on use and are therefore dealt with in the specific part of the manual.












PUMP FE	ATURES
Rotation speed	750 rpm - 4200 rpm
Delivery pressure	2 Bar - 4 Bar
Ampere rating	14.6 l/min - 93.5 l/min
Type of oil	SAE 20/30
Max oil temperature	80 °C


I. Primary gear - 2. Secondary gear - 3. Pump body - 4. Control shaft - 5. Layshaft
6. Cover - 7. Internal rotor - 8. External rotor - 9. Bushing.







Engine oil filter Figure 29		
		201798
Evaluation pressure:	C. Filtration	U.F.I.
Explosion pressure:	20 bar (ISO 4548/3)	U.F.I. 20 bar (ISO 4548/3)
	20 bar (ISO 4548/3) 0-15 bar (1Hz) > 50,000 cycles	U.F.I. 20 bar (ISO 4548/3) 0- 15 bar (1Hz) > 50,000 cycles
Button pressure:	20 bar (ISO 4548/3) 0-15 bar (1Hz) > 50,000 cycles (ISO 4548/5)	U.F.I. 20 bar (ISO 4548/3) 0- 15 bar (1Hz) > 50,000 cycles (ISO 4548/5)
Button pressure: Operating temperature:	20 bar (ISO 4548/3) 0-15 bar (1Hz) > 50,000 cycles (ISO 4548/5) -40 / +140 °C	U.F.I. 20 bar (ISO 4548/3) 0- 15 bar (1Hz) > 50,000 cycles (ISO 4548/5) -40 / + 140 °C
Button pressure: Operating temperature: Tightening torque:	20 bar (ISO 4548/3) 0-15 bar (1Hz) > 50,000 cycles (ISO 4548/5) -40 / +140 °C 20 0/+5 Nm	U.F.I. 20 bar (ISO 4548/3) 0- 15 bar (1Hz) > 50,000 cycles (ISO 4548/5) -40 / + 140 °C 18 ± 2 Nm
Button pressure: Operating temperature: Tightening torque: Maximum flow rate:	20 bar (ISO 4548/3) 0-15 bar (1Hz) > 50,000 cycles (ISO 4548/5) -40 / +140 °C 20 0/+5 Nm 100 l/mn	U.F.I. 20 bar (ISO 4548/3) 0- 15 bar (1Hz) > 50,000 cycles (ISO 4548/5) -40 / + 140 °C 18 ± 2 Nm 100 l/mn
Button pressure: Operating temperature: Tightening torque: Maximum flow rate: Loss of load at end of life:	20 bar (ISO 4548/3) 0-15 bar (1Hz) > 50,000 cycles (ISO 4548/5) -40 / +140 °C 20 0/+5 Nm 100 l/mn 2.5 bar	U.F.I. 20 bar (ISO 4548/3) 0- 15 bar (1Hz) > 50,000 cycles (ISO 4548/5) -40 / + 140 °C 18 ± 2 Nm 100 l/mn 2.5 bar
Explosion pressure: Button pressure: Operating temperature: Tightening torque: Maximum flow rate: Loss of load at end of life: Accumulation power:	20 bar (ISO 4548/3) 0-15 bar (1Hz) > 50,000 cycles (ISO 4548/5) -40 / +140 °C 20 0/+5 Nm 100 l/mn	U.F.I. 20 bar (ISO 4548/3) 0- 15 bar (1Hz) > 50,000 cycles (ISO 4548/5) -40 / + 140 °C 18 ± 2 Nm 100 l/mn










The system requires the presence of a valve that allows the oil to condense and fall by gravity into the underlying tappet cover.

By means of the appropriate breather, any vapours which


have not condensed can be conveyed into ducts where lubrication is required such as the intake or exhaust manifolds.





The tappet cover houses the pre-separator (1), whose shape and position determines an increase in oil vapour outlet speed and condenses a part of the vapours at the same time.


Condensate oil returns to the oil sump whereas the residual vapours are ducted, collected and filtered in the blow-by (3).


In the blow-by (3), part of the vapours condense and return to the oil sump whereas the remaining part is put into cycle again through pipe (2).

















The heat exchange between the lubricant oil and the coolant (water), designed to keep the temperature within the established and control values, takes place inside of the heat exchanger. The coolant is sucked by a pump from the expansion tank, the position of which varies depending on the set-up of the engine; the fluid moves into the radiator through the conveyor and then into the flow regulator. The pump then sends the coolant to the heat exchanger (inside of which it moves in the skirt). Upon leaving the heat exchanger, it is conveyed into the engine and then the thermostat, whose task is to regulate the circulation of the coolant. The coolant circuit ends with the return back into the radiator. The radiator dissipates the heat taken from the engine by the coolant. The dissipating power of the radiator is increased by the viscous fan which is present depending on the engine outfitting.





The water pump is of the vane centrifugal type. The pump bearing (2) forms a single piece with the spindle of the impeller. The water seal between the pump body (3) and the spindle (2) is obtained by the gasket (4).

Thermostat



THERMOSTAT DIAGRAM

operation

When the engine is cold the water comes out from the front of the cylinder head entering a union where the thermostat is located, which excludes the movement of the water in the radiator. This way water circulation will take place only between the pump and the engine, allowing its rapid heating.

The thermostat valve starts to open at about 80° C, allowing water circulation through the radiator and simultaneously blocking the direct return to the engine.

Check that the thermostat works properly, replace it if there is any doubt.


- I. Start stroke at approximately $79^{\circ} \pm 2 ^{\circ}C$
- 2. Stroke of 7.5 mm at 96 °C


Heat exchanger Figure 43	I
	2
I. Gaskets - 2. Internal heat exchanger element (7 elements) - 3. Heat exc 4. Pressure regulator valve	201794 Changer body -
The heat exchanger, installed in the engine cooling system, has the task of regulating the oil	temperature by subtracting heat


The heat exchanger, installed in the engine cooling system, has the task of regulating the oil temperature by subtracting heat through the use of coolant.

Pressure range	0 2.5 MPa	
Frequency	0.5 ÷ 3 Hz	
Trend	Sinusoidal	
No. of cycles	>500000	
Explosion pressure	> 10 MPa	
Piping		
Engine	5W30	
Internal oil temperature	I I 5.6 °C	
Capacity	51 dm ³ /min	

glycol
82.2 °C
230 dm ³ /min









Exhaust manifolds

The exhaust manifold however conveys the combusted gas from the cylinder chambers to the turbine.

Its internal structure allows the six flows from the chambers to come together in two distinct flows conveyed to the turbine impeller.





The turbocharger consists of the following main parts, a turbine, a valve for regulating the boost pressure, a central body and a compressor.

During operation of the engine exhaust gases pass through the body of the turbine by rotating the impeller of the turbine itself.

Since the compressor impeller is connected to the turbine impeller by means of a spindle, it turns with the turbine impeller compressing the air taken in through the air filter.

manifold to the pistons.

The turbocharger is equipped with a pressure regulating valve placed on the exhaust manifold before the turbine and connected via pipes to the intake manifold.

Its purpose is to choke the exit of the exhaust gas sending a part directly into the exhaust pipe when the boost pressure downstream of the compressor reaches the specified value in bar.

Cooling and lubrication of the turbocharger and the bearing brass is performed by means of the engine oil.

EGR SYSTEM (ONLY FOR NEF67 TMIF)

In the STAGE IIIA version, the profile of the exhaust cam has been modified to allow the partial opening of the corresponding valve during the suction phase (EGR exhaust gas recirculation) with the consequent re-entry of a part of the exhaust gas into the engine cylinders.


The exhaust gases can be brought partially into the cylinders to reduce the maximum combustion temperature values responsible for the production of nitrogen oxides (NO_x). The exhaust gas recirculation (EGR) system, by reducing the combustion temperature through the decrease in the concentration of oxygen in the combustion chamber, thus represents an effective system for controlling the emission of NO_x.

The internal EGR system does not come with any electronically controlled elements: the system is always active. Its configuration does not need additional elements such as control valves, pipes or heat exchangers.

The exhaust cam (B) presents an addition lobe to the main lobe (see Sec. A-A of the figure) compared to the configuration without EGR.

The additional lobe, during the suction phase of the cylinder in question, allows a quick opening of the exhaust valve by generating a recirculation due to the recall of the exhaust gas caused by the vacuum that is created inside the cylinder in the suction phase.

Figure 52




A. Intake valve control - B. Exhaust valve control.

SECTION 3

Electric / electronic equipment


		Page
GEI	NERAL INFORMATION ON THE LOCATION DF ELECTRICAL COMPONENTS ON	
	THE ENGINE	3
	Starter motor	4
	Water temperature sensor for KSB	4
	Oil pressure sensor	4
	Pre-post heating (if present)	4
	Alternator	5
	EDC7 UC31 electronic control unit	7
	Injector connector (A)	9
	Sensor connector (B)	9
	KSB connection cable - Stanadyne pump	10
	Crankshaft sensor	
	Timing sensor	
	Turbocharged air pressure/temperature sensor;	12
	Engine oil temperature/pressure sensor;	12
	Fuel pressure sensor	13
	Electro-injectors	4
	Resistor and contactor for pre-post heating	15
	Coolant temperature sensor	16
	Fuel temperature sensor	17
	High pressure pump - pressure regulator	81



12 ÷ 24 V

0.6 bar


0.9 bar




2 cc / min

75723

12 V







The NEF F4HE engines are entirely managed by the electronic control unit. This is mounted directly on the engine by means of a heat exchanger that allows the cooling, using the elastic plugs which reduce the vibrations transmitted from the engine.

With the electronic control unit you can verify the correct operation of the engine. (see the third part of this manual, specifically dedicated to diagnostics). Listed below are the electrical and electronic components on the engine:

- I. Coolant temperature sensor.
- 2. Electro-injector.
- 3. RAIL Pressure sensor.
- 4. Air pressure/temperature sensor.
- 5. Starter motor
- 6. Timing sensor.
- 7. Pressure regulator solenoid valve.
- 8. Fuel temperature sensor.
- 9. EDC electronic control unit.
- 10. Crankshaft sensor.
- II. Engine oil temperature/pressure sensor.
- 12. Resistor for pre-post heating.






ecu Pin	FUNCTION		
	-		
2	-		
3	-		
4	-		
5	-		
6	-		
7	-		
8	-		
9	Timing sensor		
10	Timing sensor		
	-		
12	Negative for Rail pressure and temperature sens		
13	Positive for Rail pressure and temperature sense		
14	Signal from Rail pressure and temperature sense		
15	Coolant temperature sensor		
16	-		
17	-		
18	Fuel temperature sensor signal		
19	Engine speed sensor		
20	-		
21	-		
22	-		
23	Engine speed sensor		
24	Negative for engine oil pressure and temperatu sensor		
25	Negative for air pressure and temperature sense		
26	Coolant temperature sensor		
27	Signal from engine oil pressure sensor		
28	Signal from engine oil temperature sensor		
29	-		
30	-		
31	-		
32	Positive for engine oil pressure and temperatur sensor		
33	Positive for air pressure and temperature senso		
34	Signal from air pressure sensor		
35	Negative for fuel temperature sensor		
36	Signal from air temperature sensor		

Sensor connector (B)


ecu Pin	FUNCTION
	Cylinder 5 injector
2	Cylinder 6 injector
3	Cylinder 4 injector
4	Cylinder I injector
5	Cylinder 3 injector
6	Cylinder 2 injector
7	-
8	-
9	Pressure regulator
10	Pressure regulator
	Cylinder 2 injector
12	Cylinder 3 injector
13	Cylinder I injector
14	Cylinder 4 injector
15	Cylinder 6 injector
16	Cylinder 5 injector



Crankshaft sensor

This inductive sensor is located on the left front of the engine. It generates signals obtained from changes in magnetic flux created by spaces between the teeth on the phonic wheel fitted to the crankshaft.


It is connected to the control unit at pins 19A - 23A. The sensor resistance value is ~900 Ω .



Timing sensor

This inductive type sensor is located on the rear left part of the engine. It generates the signals obtained from the magnetic flux lines that close through the holes keyed

on the gear of the camshaft. The signal generated by this sensor is used by the control unit as the injection timing signal. Although similar to the flywheel sensor, they are NOT interchangeable since it has a different outer shape. It is connected to the control unit at pins 9A - 10A. The sensor resistance value is \sim 900 Ω .



Turbocharged air pressure/temperature sensor;

This component incorporates a temperature sensor and a pressure sensor.

It is fitted to the intake manifold so that, by measuring the maximum quantity of air taken in, it makes it possible to determine the exact amount of fuel to be injected at each cycle.

It is connected to the control unit at pins 25Å - 36Å - 33Å - 34Å.

It is powered at 5 volt

The voltage present at output is proportional to the pressure or temperature detected by the sensor.

Pins 25A - 36A	Temperature
Pins 33A - 34A	Pressure

Engine oil temperature/pressure sensor;

This component is identical to the air temperature/pressure sensor.

It measures the temperature and pressure of the engine oil.

It measures the engine oil temperature and pressure.


It is connected to the control unit at pins 24A - 28A - 32A - 27A.

It runs on 5 Volts. The detected signal is sent to the EDC control unit which in turn controls the indicator tool in the dashboard (indicator + low pressure light).


The oil temperature is not shown by any of the instruments- it can only be used by the Control Unit.

Pins 24A - 28A	Temperature
Pins 32A - 27A	Pressure

Figure 14







50344


Wiring Diagram

Ref.	Description	Control unit pin	Control unit pin	
	Description	Engine	Air	
	Ground	24A	25A	
2	NTC signal (temperature)	28A	36A	
3	Power supply +5 V	32A	33A	
4	Signal (pressure)	27A	34A	

Fuel pressure sensor

Assembled on one end of the rail, measures the existing fuel pressure and informs the control unit (feed - back). The value of injection pressure is used to keep the pressure level under control and to determine the time duration of the injection electronic command.

It is connected to the control unit at pins I2A - I4A - I3A. It runs on 5 Volts.



Electro-injectors

This is an N.O. solenoid value. They are individually connected to the EDC control unit on connector B. The coil resistance of each individual injector is 0.56 \div 0.57 Ω .

Ref.		Description	Control unit pin
Connector I	1	Cylinder injector 2	B
	2	Cylinder injector 2	6 B
	3	Cylinder injector 1	3 B
	4	Cylinder injector 1	4 B
CONNECTOR 2		Cylinder injector 4	I4 B
	2	Cylinder injector 4	3 B
	3	Cylinder injector 3	I2 B
	4	Cylinder injector 3	5 B
CONNECTOR 3		Cylinder injector 6	I5 B
	2	Cylinder injector 6	2 B
	3	Cylinder injector 5	I B
	4	Cylinder injector 5	I6 B

Figure 16






Figure 17



50349



Coolant temperature sensor


This is a variable resistance sensor that is able to measure coolant temperature and transmit a signal to the control unit reflecting the thermal conditions of the engine.


The same signal is used by the control unit to drive a temperature device, if present, in the dashboard.


It is connected to the control unit at pins 15A - 26A.

Its resistance at 20 °C is about 2.50 $\dot{\Omega}$.

Figure 20







Principles

To ensure best operating conditions, the checks, tests and adjustments which are to be carried out on the different parts at the established time are provided on the following pages.

The frequencies of the maintenance operations are indicative since the engine use and its characteristics are essential to evaluate replacements and checks.

Not only it is permitted, but it is recommended that the staff in charge of maintenance should also perform those checking and maintenance operations which are not included in the list below, but are recommended by good-practices and particular conditions of use of the engine.

Checks and scheduled maintenance procedures	Intervals (hours)
Check the engine lubricant oil level	daily
Check engine coolant level	daily
Check cleanliness of the heat exchanger	daily
Check cleanliness of the air filter	daily
Check belt condition and tension	300 hours ⁽²⁾
Checking/topping-up the level of the electrolytic solution in the batteries and cleaning the terminals	Six-months
Check the condition of the exhaust duct(s)	Six-months
Periodical maintenance	
Engine lubricant oil change	600 hours ⁽³⁾⁽⁴⁾
Oil filter change	600 hours ⁽³⁾⁽⁴⁾⁽⁵⁾
Fuel filter replacement	600 hours ⁽¹⁾⁽³⁾⁽⁵⁾
Fuel pre-filter change	600 hours ⁽¹⁾⁽³⁾
Change oil vapour filters	900 hours ⁽³⁾⁽⁴⁾
Drain water from the fuel filter	150 hours ⁽¹⁾
Drainage/suction of water, condensation and impurities from the fuel tank/s	150 hours ⁽¹⁾
Change air filter	1200 hours ⁽⁶⁾
Change the engine coolant	1200 hours / 3 years
Unscheduled maintenance	
Visually inspect turbocharger	1200 hours
Ancillary belt replacement	1200 hours
Clean the heat exchanger (radiator)	1200 hours
Injector calibration (Mechanical engines)	1800 hours
Checking and setting the valve clearance	3000 hours


 Maximum period relating to the use of high quality fuel, (specification EN 590); it decreases depending on fuel contamination and the alarm signals for filter clogging and/or the presence of water in the pre-filter. The filter clogging signal indicates that the filter must be replaced. If the alarm signalling water in the pre-filter is not turned off, the pre-filter must be replaced.


- 2) Refers to engines with conventional and automatic tensioners
- 3) Must be performed annually even if the intended operating hours are not reached
- 4) Intervals valid for lubricants as specified in the REFUELLING table.
- 5) Only use filters with the following specifications:
 - degree of filtering < 12 μ m
 - filtering efficiency $\beta > 200$.

6) The frequency depends on the ambient conditions and product efficiency/wear.

NOTE Checks, inspections and changes are indicative and must integrate those specifications foreseen for vehicles equipped with an NEF engine.

The data are only valid if the vehicle manufacturer observes all the installation regulations provided by FPT.





Inspection of the exhaust duct

Visually check that the exhaust gas / exhaust system is not obstructed or damaged.

A Make sure that there is no risk of harmful fumes in the environment where the engine is being worked on. Contact the manufacturer if necessary.

Check tightening and cleanliness of battery terminals

Check that the battery terminals and cable clamps are clean, well tightened and protected by Vaseline.

In the event of dirty cable clamps and battery terminals:

- Loosen the nut and remove the terminal from the negative terminal (marked with a "-").
- Loosen the nut and remove the terminal from the positive terminal (marked with a "+").
- Use a metal brush or fine grade sand paper to clean the cable terminals and the battery terminals until they are shiny.
- Smear the cable terminals with Vaseline and insert them onto the battery terminals making sure that the positive pole is connected first, followed by the negative pole, and then tighten each terminal.

Check the cables and clamps for signs of wear and corrosion; if there is any deterioration, replace them.

Visually check the condition of the battery: the terminals must not show signs of deterioration and the body must not be damaged, otherwise they should be replaced.



Wear protective glasses and gloves

Check electrolyte level of the batteries


The batteries used are of reduced maintenance type. Therefore, under normal conditions of use, no top up of the electrolyte is required.

However, the routine checking of the electrolyte level is recommended.

Proceed after positioning the batteries on a horizontal surface.

- ❑ Visually check that the electrolyte level is between the "Min" and "Max" reference marks on the batteries; in the absence of any reference marks, make sure the liquid covers the lead plates contained in the elements by approx. 5 mm.
- Only use distilled water to top up the elements whose level is below the minimum.
- If the battery has to be recharged, contact a specialised workshop.

tempe	rature move) of cy N	so as not to run the the oil vapour filter linders 5 - 6, acting o o. Screws descri	e risk of burns. (2) from the tappet cover on the retaining screws (1).
ot Ref.	nerwis positio t cove). No.	e replace. on the oil vapour filte r (3) of cylinders 3 Screws descrip- tion	er (2) in the seat on the tap- - 4 and tighten the screws Tightening torques
	Disp cont danc The	ose of consumable act with them (for e with the law. FPT Technical Servic	- materials and the parts in example filters) in accor- e Network workshops are e.
	Fig	Figure 4 Image: Second seco	Ref. No. Screw - Make sure the oil vapour filter (3) of cylinders 5 - 6, acting of cylinders 3 - 6, acting of cylin



Periodical maintenance

Engine lubricant oil change



Due to the high operating temperature of the engine it is recommended to wear suitable protection.

The oil reaches very high temperatures: always wear protective gloves.

It is recommended that the oil is drained while hot.

- Place an appropriate container for the oil collection under the sump in correspondence with the drain plug.
- Unscrew the plug and then remove the oil level dipstick and the filler plug to facilitate the lubricant oil flow.



The engine oil is highly pollutant and noxious.

In case of contact with skin, wash thoroughly with water and detergent.

Suitably protect skin and eyes; proceed in accordance with accident prevention standards.

Suitably dispose of the residuals and in accordance with regulations.

When draining has been completed, screw in the plug and then fill with clean oil.




Use only the recommended oils or oils with the characteristics required for the proper functioning of the engine.


If topping up, do not mix oils with different properties.

Failure to comply with these rules will result in the loss of guarantee assistance.

Check the level using the dipstick up to obtain a filling close to the maximum level mark on the dipstick itself.

Oil filter change





Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns.

Place a container for the oil recovery.

Use tool 99360076 to unscrew the oil filter (1).

Ref.	No.	Screws description
(1)	Ι	Cartridge M27x2

Be careful since the oil filter contains a significant quantity of engine oil .

Properly position a container that can contain the liquid.

Attention! Avoid skin contact with the engine oil: in case of contact, wash thoroughly with water.

The engine oil is highly pollutant: it must be disposed of according to applicable laws.


Tighten the oil filter (1) in correspondence to the slot on the heat exchanger (2).

Operate the engine for a few minutes and then check the level using the dipstick. If necessary, top up to compensate for the quantity of oil used to fill up the filtering cartridge.

Ref.	No.	Screws descrip- tion	Tightening torques
(1)		Cartridge M27x2	20 ± 2 Nm

Fuel filter replacement


Ē



Do not smoke or use open flames during this opera-

Do not inhale the vapours that exit the filter.

When replacing the filters, the feed system must then always be deaerated.




Collect any fuel still present in the filtering cartridge.

Clean the gasket seat on the support and lightly oil the gasket on the new filtering cartridge.

Manually screw in the new filtering cartridge until the gasket rests completely on its seat.

Tighten further with the help of the tool 99360076.

渝




Start the engine and run it at idle for a few minutes to remove any residual air.

Tighten the previously loosened fitting to the specified

NOTE If it is necessary to accelerate the bleeding of residual air, proceed by acting on the hand pump, even during start-up.

Change oil vapour filters

torque.



Replace the oil vapour filter (2) and its gasket (3).

Reposition the oil vapour filter (2) in the seat on the tappet cover (4) of cylinders 5 - 6 and tighten the screws (1).

Ref.	No.	Screws descrip- tion	Tightening torques
(1)	3	Screw -	-



Dispose of consumable materials and the parts in contact with them (for example filters) in accordance with the law. The FPT Technical Service Network workshops are equipped for this purpose.


Act on the pre-filter hand pump until the diesel comes out with no residual air content or carry out a similar operation on the mechanical feed pump (2).




2

3

137359





Unscheduled maintenance


Ancillary belt replacement

(日)


∕₼\

When the engine is off, but still hot, the belt may start to move without warning. Wait for the engine temperature to decrease in order to avoid serious risk of injury.

Replace the ancillary belt if it shows signs of abrasions, cracks or tears or if it is soiled with oil or fuel.



- Remove the protective grille and the fan together with spacer by acting on the relative fasteners.
- Using tool (3), loosen the automatic belt tensioner (1).
- \Box Remove the belt (3).
- Place the new belt (3) inside of the shoulders of all the pulleys.
- Release the automatic belt tensioner (1) and remove the tool (3).
- Reposition the fan together with spacer in its seat and the protective grilles and tighten the relative fasteners.



	Ref.	No.	Screws description
ľ	()		Screw MI0x1.5
	(2)	2	Screw MI0x1.5

- Use the special tool (3) to turn the automatic tensioner (4) in the direction of the arrow and remove the belt (5).
- Use the special tool (3) to turn the automatic tensioner (4) and place the new belt (5) inside the shoulders of all the pulleys.
- ☐ Tighten the bolt (1) anchoring the alternator to its lower support and the screw (2) fixing the alternator to the bracket.

Ref.	No.	Screws descrip- tion	Tightening torques
()		Screw MI0x1.5	43 ± 6 Nm
(2)	2	Screw MI0x1.5	43 ± 6 Nm

Reposition the fan together with spacer in its seat and the protective grilles and tighten the relative fasteners.

Visually inspect turbocharger

Only proceed when the engine is not turning over. Visually check that the impellers of the turbine and the compressor and their relative inlets and outlets are not blocked or damaged; in this case, proceed with replacement.

Clean the heat exchanger (radiator)

Check that the air intake surfaces of the radiators are free of impurities.

Clean them using compressed air or steam.



The use of compressed air requires the use of suitable protective equipment for the hands, face and eyes.


Injector calibration (Mechanical engines)

The injectors require periodic cleaning and calibration of the exact injection pressure, through the addition or replacement of shims inserted under the spring; check the injection pressure by using a hand operated pump equipped with a pressure gauge which, operated by the lever, enables the injector calibration pressure to be obtained and which is displayed on the pump pressure gauge at the moment in which diesel delivery occurs.

During testing it is also possible to see whether the flow direction is correct and whether the injector is leaking fuel.

Clean the injectors by removing carbon deposits from the top of the sprayer with a metallic brush.

Adjust valve/rocker arm clearance



70520

Registration of the clearance between the rocker arms and crossbars which control the intake and exhaust valves must be carried out carefully using the hex key (1) box wrench (3) and feeler gauge (2).

The clearance is:

intake valves 0.25 ± 0.05 mm

 \Box exhaust valves 0.50 \pm 0.05 mm.

SECTION 5

Removal/refitting of the main components of the engine

Т


	Page
PROCEDURE FOR REMOVAL/REFITTING OF PROTECTION GRILLE	5
🔲 Removal	5
Refitting	5
PROCEDURE RADIATOR REMOVAL/REFITTING	6
🔲 Removal	6
Refitting	7
PROCEDURE FOR FAN REMOVAL/REFITTING	8
Removal	8
Refitting	9
PROCEDURE FOR ANCILLARY BELT REMOVAL/REFITTING	10
Removal NEF67 TM1F engines	10
Refitting	
Removal NEF67 TE1F/TE2F engine	
Refitting	12
PROCEDURE FOR ENGINE CABLE REMOVAL/REFITTING	13
Removal NEF67 TE1F/TE2F engines	13
Refitting	14
PROCEDURE FOR AIR FILTER REMOVAL/REFITTING	14
Removal NEF67 TE1F/TE2F engines	14
Refitting	4
PROCEDURE FOR ALTERNATOR REMOVAL/REFITTING	15
Removal NEF67 TM1F engine	15
1	

	Page
Refitting	15
Removal NEF67 TE1F/TE2F engines	15
Refitting	15
PROCEDURE FOR WATER PUMP REMOVAL/REFITTING	16
🔲 Removal	16
Refitting	16
PROCEDURE FOR THERMOSTAT REMOVAL/REFITTING	16
Removal NEF67 TM1F engines	16
Refitting	
Removal NEF67 TE1F/TE2F engines	17
Refitting	17
PROCEDURE FOR ELECTRIC STARTER MOTOR REMOVAL/REFITTING	18
🔲 Removal	18
Refitting	18
PROCEDURE FOR TURBOCHARGER REMOVAL/REFITTING	18
Removal	18
Refitting	19
PROCEDURE FOR OIL FILTER REMOVAL/REFITTING	21
🔲 Removal	21
Refitting	21
PROCEDURE FOR HEAT EXCHANGER REMOVAL/REFITTING	21
Removal	21
Refitting	22
PROCEDURE FOR OIL SUMP REMOVAL/REFITTING	22
🔲 Removal	22

		Page
	Refitting	23
PRC F	DCEDURE FOR OIL PUMP REMOVAL/REFITTING	23
	Removal	23
	Refitting	24
S	DCEDURE FOR OIL VAPOUR RECIRCULATION YSTEM REMOVAL/REFITTING	۱ 25
	Removal NEF67 TM1F engines	25
	Refitting	25
	Removal NEF67 TETF/TE2F engines	25
	Refitting	26
	DCEDURE FOR LOW PRESSURE FUEL PIPE REMOVAL/REFITTING	26
	Removal NEF67 TM1F engines	26
	Refitting	28
	Removal NEF67 TE1F/TE2F engines	29
	Check mechanical pump power using tool 99305453	30
	Refitting	31
PRC F	DCEDURE FOR HIGH PRESSURE FUEL PIPE REMOVAL/REFITTING	31
	Removal NEF67 TM1F engines	31
	Refitting	32
	Removal NEF67 TE1F/TE2F engines	33
	Refitting	33
	DCEDURE FOR REMOVAL/REFITTING OF	34
	Removal NEF67 TE1F/TE2F engines	34
	Refitting	34

		Page
PRC F	DCEDURE FOR FUEL FILTER REMOVAL/REFITTING	34
	Removal NEF67 TM1F engines	34
	Refitting	34
	Removal NEF67 TE1F/TE2F engines	35
	Refitting	35
PRC F	DCEDURE FOR TAPPET COVER REMOVAL/REFITTING	36
	Removal NEF67 TM1F engines	36
	Refitting	36
	Removal	36
	Refitting	36
	DCEDURE FOR ROCKER ARM ASSEMBLY REMOVAL-REFITTING	37
	Removal NEF67 TE1F/TE2F engines	37
	Refitting	37
PRC F	DCEDURE FOR INJECTOR REMOVAL/REFITTING	38
	Removal NEF67 TM1F engines	38
	Refitting	38
	Removal NEF67 TE1F/TE2F engines	39
	Refitting	39
	DCEDURE FOR FEED PUMP REMOVAL/REFITTING	40
	Removal NEF67 TM1F engines	40
	Refitting	42
	Removal NEF67 TE1F/TE2F engines	43
	Refitting	43


	Page
DCEDURE FOR PRIMING PUMP REMOVAL/REFITTING	44
Removal NEF67 TM1F engines	44
Refitting	44
DCEDURE FOR ROCKER ARM ASSEMBLY REMOVAL/REFITTING	45
Removal NEF67 TM1F engines	45
Refitting	45
DCEDURE FOR INTAKE MANIFOLD REMOVAL/REFITTING	46
Removal NEF67 TM1F engines	46
Refitting	46
Removal NEF67 TE1F/TE2F engines	47
Refitting	47
DCEDURE FOR EXHAUST MANIFOLD REMOVAL/REFITTING	48
Removal NEF67 TM1F engines	48
Refitting	48
Removal NEF67 TE1F/TE2F engines	49
Refitting	49
DCEDURE FOR CYLINDER HEAD REMOVAL/REFITTING	50
Removal NEF67 TM1F engine	50
Refitting	52
Removal NEF67 TE1F/TE2F engine	54
Refitting	55



2

3


129290




with sleeves, from the engine side. Unscrew the screws on clamps (2 and 3). Screws description Screw M6x1x16 Screw M8x1.25x16 2

- Ē 3 6 5 4 129291
- Disconnect and remove the pipe (1), complete with sleeves, from the engine side, unscrewing the screws on the relative clamps (6).
- Disconnect and remove the pipe (2), unscrewing the screws on the relative clamp (3).
- Disconnect and remove the pipe (4), complete with sleeves, from the engine side, unscrewing the screws on the relative clamps (5).
- Properly lock the radiator unit, then release it from the base by adjusting the hardware on both sides.
- Remove the radiator unit from its seat.

Ref.	No.	Screws description
(3)	2	Screw M6x1x16
(5)	2	Screw M8x1.25x16
(6)	2	Screw M6x1x16





NOTE Check the state of wear of the rubber sleeves.



Connect the air and water pipes to the radiator assembly using the clamps (1, 2, 3 and 4) and the mounting bracket (5).

Ref.	No.	Screws description	Tightening torques
(5)		Screw M6x1x16	43 ± 6 Nm






Ref.	No.	Screws description	Tightening torques
(2)	4	Screw M8x1.25	24 ± 4 Nm


Fit the protection grille as described in the relative procedure.

PROCEDURE FOR FAN REMOVAL/REFITTING Removal

Remove the protection grille as described in the relative procedure.

Remove the radiator as described in the relevant section.







Screw M7x1

Screw M7x1

L


(5)





- Connect the air intake pipes (6), closing their clamps (1) and (5)
- Connect the oil vapour recovery pipes (3), closing their clamps (2) and (4).


Ref.	No.	Screws description	Tightening torques
(1)		Screw M7x1	13 ± 2 Nm
(5)		Screw M7x1	13 ± 2 Nm



Connect the discharge pipe (1), tightening the screw (2) to close the clamp (3).

Ref.	No.	Screws description	Tightening torques
(2)		Screw M7x1	13 ± 2 Nm

	Ref.	No.	Screws description	Tightening torques
	(2)	6	Screw M8x1.25	24 ± 4 Nm
ľ				



Ref.	No.	Screws description	Tightening torques
()		Screw M6x1x16	43 ± 6 Nm
(2)	2	Screw M6x1x16	43 ± 6 Nm
(3)	2	Screw M8x1.25x16	43 ± 6 Nm

Fit the radiator as described in the relevant section.

Fit the protection grille as described in the relative procedure.


PROCEDURE FOR ANCILLARY BELT REMOVAL/REFITTING

Removal NEF67 TM1F engines

Remove the protection grille as described in the relative procedure.

Remove the radiator as described in the relevant section.


Remove the fan as described in the relevant section.



Using tool (3), loosen the automatic belt tensioner (1).Remove the belt (3).

Refitting

- Place the new belt (3) inside of the shoulders of all the pulleys.
- Release the automatic belt tensioner (1) and remove the tool (3).
- Reposition the fan together with spacer in its seat and the protective grilles and tighten the relative fasteners.



BELT ASSEMBLY DIAGRAM I. Fan pulley - 2. Idler pulley - 3. Crankshaft pulley -4. Water pump - 5. Alternator

Fit the fan as described in the relevant section.

Fit the radiator as described in the relevant section.


Fit the protection grille as described in the relative procedure.

Removal NEF67 TE1F/TE2F engine

Remove the protection grille as described in the relative procedure.

Remove the radiator as described in the relevant section.

Remove the fan as described in the relevant section.



Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns.

- Remove the protective grille and the fan together with spacer by acting on the relative fasteners.
- Unscrew the bolt (1) anchoring the alternator to its lower support and the screw (2) fixing the alternator to the bracket.

Ref.	No.	Screws description
(1)	I	Screw MI0x1.5
(2)	2	Screw MI0x1.5


Use the special tool (3) to turn the automatic tensioner (4) in the direction of the arrow and remove the belt (5).

Refitting

- Use the special tool (3) to turn the automatic tensioner in the direction of the arrow (4) and reposition the belt (5) inside the shoulders of all the pulleys.
- Tighten the bolt (1) anchoring the alternator to its lower support and the screw (2) fixing the alternator to the bracket.

Ref.	No.	Screws description	Tightening torques
()		Screw MI0x1.5	43 ± 6 Nm
(2)	2	Screw MI0x1.5	43 ± 6 Nm

Reposition the fan together with spacer in its seat and the protective grilles and tighten the relative fasteners.




BELT ASSEMBLY DIAGRAM I. Fan pulley - 2. Idler pulley - 3. Crankshaft pulley -4. Water pump - 5. Alternator -6. Automatic belt tensioner

Fit the fan as described in the relevant section.


Fit the radiator as described in the relevant section.

Fit the protection grille as described in the relative procedure.



107246

I. Connections for electro-injectors - 2. Engine coolant temperature sensor - 3. Fuel pressure sensor cable - 4. Engine oil temperature and pressure sensor - 5. Crankshaft sensor - 6. EDC control unit 7 - 7. Pressure regulator cable - 8. Fuel heater and fuel temperature sensor cable - 9. Timing phase sensor - 10. Air temperature and pressure sensor - 11. Electro-injector.




To disconnect lower pressure fuel pipes from their couplings, press clip (1) as shown in figure B.

After removing the pipe, move the clip (1) to the locked position (Figure A) to prevent possible deformations.

Disconnect the engine cable from the connectors: electro-injector wiring (1); (10) air pressure/temperature sensor; (3) fuel pressure sensor; (6) control unit; (9) timing gear phase sensor; (2) engine coolant temperature sensor on thermostat; (5) engine rpm sensor.

Remove the clamps that hold it to the crankcase and remove it completely.

Refitting




To connect lower pressure fuel pipes from their couplings, press clip (1) as shown in figure B.

After removing the pipe, move the clip (1) to the locked position (Figure A).

Connect the engine cable from the connectors: electro-injector wiring (1); (10) air pressure/temperature sensor; (3) fuel pressure sensor; (6) control unit; (9) timing gear phase sensor; (2) engine coolant temperature sensor on thermostat; (5) engine rpm sensor.

Insert the clamps that hold it to the crankcase.



Ref.	No.	Screws description
(3)	2	Screw M8x1.25x100

Refitting

- Place the air filter (2) in the relative position.
- Tighten the screws (3) to the support clamp.
- \Box Connect the clamp (1).

Ref.	No.	Screws description	Tightening torques
(3)	2	Screw M8x1.25x100	-

PROCEDURE FOR ALTERNATOR REMOVAL/REFITTING


Removal NEF67 TM1F engine

Remove the protection grille as described in the relative procedure.

Remove the radiator as described in the relevant section.

Remove the fan as described in the relevant section.

Remove the belt as described in the relevant section.



Unscrew the screws (2 and 4) anchoring the alternator (5) to its support and the screw (1) adjusting the position of the alternator.

Ref.	No.	Screws description
(1)	I	Screw M8x1.25x100
(2)	I	Screw MI0x1.5x40
(4)	I	Screw MI0x1.5x110

Remove the alternator (5) from its housing.

Refitting

Position the alternator (5) in its housing.

- Place the new belt (3) inside of the shoulders of all the pulleys.
- Tighten the screw (1) adjusting the alternator (5).
- Tighten the screws (2 and 4) anchoring the alternator to its support.

Ref.	No.	Screws description	Tightening torques
()		Screw M8x1.25x100	-
(2)		Screw MI0xI.5x40	43 ± 6 Nm
(4)		Screw MI0x1.5x110	43 ± 6 Nm

Fit the fan as described in the relevant section.

Fit the radiator as described in the relevant section.

Fit the protection grille as described in the relative procedure.


Removal NEF67 TE1F/TE2F engines

Remove the protection grille as described in the relative procedure.

Remove the radiator as described in the relevant section.

Remove the fan as described in the relevant section.

Remove the belt as described in the relevant section.



Unscrew the screw (1) anchoring the alternator to its lower support and the screw (2) securing the bracket.

Ref.	No.	Screws description
(1)		Screw MI0x1.5
(2)	2	Screw MI0x1.5

Remove the alternator from its housing.

Refitting

Position the alternator in its housing.

- Use the special tool (3) to turn the automatic tensioner in the direction of the arrow (4) and reposition the belt (5) inside the shoulders of all the pulleys.
- Tighten the bolt (1) anchoring the alternator to its lower support and the screw (2) fixing the alternator to the bracket.

Ref.	No.	Screws description	Tightening torques
(1)		Screw MI0x1.5	43 ± 6 Nm
(2)	2	Screw MI0x1.5	43 ± 6 Nm

Fit the fan as described in the relevant section.

Fit the radiator as described in the relevant section.

Fit the protection grille as described in the relative procedure.


PROCEDURE FOR WATER PUMP REMOVAL/REFITTING Removal

Remove the protection grille as described in the relative procedure.

Remove the radiator as described in the relevant section.

Remove the fan as described in the relevant section.

Remove the belt as described in the relevant section.



 $\hfill \Box$ Loosen and remove the screws (1).

Take the water pump (2) out of its housing.

Ref.	No.	Screws description
(1)	2	Screw M8x1.25

Recover the gasket (3).

Refitting

- Insert the gasket (3) into the seat on the crankcase.
- Position the water pump (2) in its housing and tighten the screws (1).

Ref.	No.	Screws description	Tightening torques
()	2	Screw M8x1.25	24 ± 4 Nm

Fit the belt as described in the relevant section.

Fit the fan as described in the relevant section.

Fit the radiator as described in the relevant section.


Fit the protection grille as described in the relative procedure.

PROCEDURE FOR THERMOSTAT REMOVAL/REFITTING

Removal NEF67 TM1F engines

Remove the protection grille as described in the relative procedure.

Remove the radiator as described in the relevant section.





Unscrew the screws (1) securing the thermostat cover (2).

Remove the thermostat cover (2).

 \Box Remove the lifting eyelet (3).

Ref.	No.	Screws description
(1)	3	Screw M6x1






Fit the protection grille as described in the relative procedure.

Removal NEF67 TE1F/TE2F engines

Remove the protection grille as described in the relative procedure.

Remove the radiator as described in the relevant section.



Remove the thermostat (3).

Ref.	No.	Screws description
(1)	3	Screw M6x1x20

Refitting

Insert the thermostat assembly (3) into the relative seat.

Position the thermostat cover (2) and tighten the screws (1).

Ref.	No.	Screws description	Tightening torques
(1)	3	Screw M6x1x20	10 ± 2 Nm

Fit the radiator as described in the relevant section.

Fit the protection grille as described in the relative procedure.

	oval _{gure} 37	,		
1				π/
				/
$\overline{\mathbb{N}}$)-
V				,
	3 2			
				- Jan Lan
1		the energy (1)		2116
to	the fly	the screws (1) securing wheel housing (3).		(Z)
R	emove	the starter motor (2) fr	rom its seat.	
Ref.	No		n	
() efit) In ho	3 sert the ousing (Screw MI0x1.5 e starter motor (2) in i (3).		eel
) In ha) Ti	3 sert the ousing (ighten t	Screw M10x1.5 e starter motor (2) in i (3). he screws (1).	its seat at the flywhe	
(1) efit In Ti Ti ef.	3 sert the ousing (ighten t No.	Screw M10x1.5 e starter motor (2) in i (3). he screws (1). Screws description	its seat at the flywhe	
() efit In ha Ti ef.	3 sert the ousing (ighten t	Screw M10x1.5 e starter motor (2) in i (3). he screws (1).	its seat at the flywhe	
() efit In ha Ti ef.	3 sert the ousing (ighten t No.	Screw M10x1.5 e starter motor (2) in i (3). he screws (1). Screws description	its seat at the flywhe	
() efit In ha Ti ef.	3 sert the ousing (ighten t No.	Screw M10x1.5 e starter motor (2) in i (3). he screws (1). Screws description	its seat at the flywhe	
() efit In ha Ti ef.	3 sert the ousing (ighten t No.	Screw M10x1.5 e starter motor (2) in i (3). he screws (1). Screws description	its seat at the flywhe	
() efit In ha Ti ef.	3 sert the ousing (ighten t No.	Screw M10x1.5 e starter motor (2) in i (3). he screws (1). Screws description	its seat at the flywhe	
() efit In ha Ti ef.	3 sert the ousing (ighten t No.	Screw M10x1.5 e starter motor (2) in i (3). he screws (1). Screws description	its seat at the flywhe	
() efit In ha Ti ef.	3 sert the ousing (ighten t No.	Screw M10x1.5 e starter motor (2) in i (3). he screws (1). Screws description	its seat at the flywhe	
() efit In ha Ti ef.	3 sert the ousing (ighten t No.	Screw M10x1.5 e starter motor (2) in i (3). he screws (1). Screws description	its seat at the flywhe	
() efit) In ho	3 sert the ousing (ighten t No.	Screw M10x1.5 e starter motor (2) in i (3). he screws (1). Screws description	its seat at the flywhe	

PROCEDURE FOR TURBOCHARGER REMOVAL/REFITTING Removal

Remove the radiator as described in the relevant section.

Remove the air filter as described in the relevant section.


Figure 38 \square 0 00 0 Ø Ôı 4 煮 6 3 PERBE 5 **(®**) ODO EEE 2 214290


Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns.


Place a container for the oil recovery.

- Unscrew the screws (1, 2 and 3).
- Remove the turbocharger protection grille (4).

Ref	•	No.	Screws description
(1)		-	Screw M8x1x10
(2)		2	Screw M8x1x10
(3)		2	Screw M8x1x10







Position the grille (4) protecting the turbocharger.

Tighten the screws (1, 2 and 3).

 $\left\langle \right\rangle$

Ref.	No.	Screws description	Tightening torques
()		Screw M8x1x10	36 ± 5 Nm
(2)	2	Screw M8x1x10	36 ± 5 Nm
(3)	2	Screw M8x1x10	36 ± 5 Nm

NEF 67 SERIES

PROCEDURE FOR OIL FILTER REMOVAL/REFITTING Removal

Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns.

202120

Place a container for the oil recovery.

Use tool 99360076 to unscrew the oil filter (1).

Ref.	No.	Screws description
(1)		Cartridge M27x2

Refitting


Tighten the oil filter (1) in correspondence to the slot on the heat exchanger (2).

Ref.	No.	Screws description	Tightening torques
()		Cartridge M27x2	20 ± 2 Nm

PROCEDURE FOR HEAT EXCHANGER REMOVAL/REFITTING Removal

Remove the oil filter as described in the relevant section.


Remove the alternator as described in the relevant section.





Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns.

Unscrew the delivery pipe (2) fittings (1).

Ref.	No.	Screws description
(1)	2	MI6 nut








Refill with lubricant oil.


2

3

4

202397





Ref.	No.	Screws description	Tightening torques
()	8	Screw M8x1.25x30	24 ± 4 Nm
(2)	Ι	Screw MI0x1.5x70	43 ± 6 Nm
(4)	6	Screw M12x1.25x78.5	68 ± 7 Nm
(6)	5	Screw M8x1.25x45	24 ± 4 Nm

Fit the oil sump as described in the relevant section.

Fit the ancillary belt as described in the relevant section.

Fit the fan as described in the relevant section.

Fit the radiator as described in the relevant section.

Fit the protection grille as described in the relative procedure. Refill with lubricant oil.


RECIF REMC Remo	VAL/F	E FOR OIL VAPOUR REFITTING F67 TMIF engines	R Re
🗋 Uns	screw the	e screws (1) securing the oil vapour filter (2).	
		e gasket (3).	
Ref.	No.	Screws description	
(1)	3	Screw M6x1x20	

Refitting

Insert the gasket (3) into its seat.


Fit the oil vapour filter (2) and tighten the screws (1).

Ref.	No.	Screws description	Tightening torques
(1)	3	Screw M6x1x20	-




Re	. No.	Screws description
(1)	3	Screw M6x1x25
F	gure 61	
י ם ו	Jnscrew the	e support screw (1) from the clamp.
F	Remove the	engine breather pipe (4).
	Jnscrew the ipe (3).	e threaded couplings (2) and remove the

Ref.	No.	Screws description
(1)	I	Screw -
(2)	2	Coupling M12x1.5x11



Ref.	No.	Screws description	Tightening torques
()	-	Screw -	-
(2)	2	Coupling M12x1.5x11	-




PROCEDURE FOR LOW PRESSURE FUEL PIPE REMOVAL/REFITTING

Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns.

Place a container for the oil recovery.


Removal NEF67 TM1F engines


Remove the oil vapour filter as described in the relevant section.




To disconnect lower pressure fuel pipes from their couplings, press clip (1) as shown in figure B.

After removing the pipe, move the clip (1) to the locked position (Figure A) to prevent possible deformations.










Ref.	No.	Screws description	Tightening torques
()		Screw M8x16	-
(2)		Nut -	-

Removal NEF67 TE1F/TE2F engines



- Remove the excess fuel return pipe (1) from the Common Rail.
- Remove the fuel return pipe (3) for the injection pump
 (2) from the filter (5).
- \Box Remove the fuel supply pipe (4) from the control unit.
- Remove the fuel delivery pipe (6) from the injection pump (2) to the filter (5).
- Remove the fuel delivery pipe (7) for the injection pump (2) from the filter (5).







PROCEDURE FOR HIGH PRESSURE FUEL PIPE REMOVAL/REFITTING


Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns.

Place a container for the oil recovery.

Removal NEF67 TM1F engines








PROCEDURE FOR REMOVAL/REFITTING OF ELECTRONIC CONTROL UNIT

Removal NEF67 TE1F/TE2F engines

Remove the engine cable as described in the relevant section.

Remove the low pressure pipe as described in the relevant section.



- Unscrew the screws (3 and 6).
- \Box Unscrew the nut (4) and the corresponding stud (5).
- Remove the control unit (2).
- Remove the support (1).

Ref.	No.	Screws description
(3)	7	Screw M6x1x30
(4)	I	Nut M6x1
(5)	I	Stud M6x1x25
(6)	3	Screw M8x1.25x45

Refitting

- \Box Place the support (1) in its seat.
- Position the control unit (2).
- Tighten the stud (5) and the corresponding nut (4).
- Tighten the screws (3 and 6).

Ref.	No.	Screws description	Tightening torques
(3)	7	Screw M6x1x30	10 ± 2 Nm
(4)		Nut M6x1	10 ± 2 Nm
(5)		Stud M6x1x25	10 ± 2 Nm
(6)	3	Screw M8x1.25x45	24 ± 4 Nm

Fit the low pressure pipes as described in the relevant section.

Fit the engine cable as described in the relevant section.


PROCEDURE FOR FUEL FILTER REMOVAL/REFITTING

Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns.

Place a container for the oil recovery.

Removal NEF67 TM1F engines

Remove the low pressure pipe as described in the relevant section.



- Unscrew the screws (1) securing to the crankcase.
- Remove the fuel filter (2) together with the support and the filtering cartridge.


Ref.	No.	Screws description
(1)	2	Screw M8x1.25x25

Refitting

Set the fuel filter (2) and tighten the screws (1) securing it to the crankcase.

Ref.	No.	Screws description	Tightening torques
()	2	Screw M8x1.25x25	80 ± 8 _Nm

Fit the low pressure pipes as described in the relevant section.




Refitting


- Position the support (4) in the relative seat and tighten the screws (7).
- Insert the clamp (5) for supporting the pipe (8) in low pressure.
- Tighten the cartridge (6) using tool 99360076.
- Position the pre-filter (3) and tighten the screws (2) and the relative nuts (1).
- Connect all the pipes to the pre-filter (3).

Ref.	No.	Screws description	Tightening torques
(1)	2	Screw M20x1.5	-
(2)	2	Screw M20x1.5	20 0/+5 Nm
(6)		Cartridge M20x1.5	20 0/+5 Nm
(7)	2	Screw MI2xI.75x30	80 ± 8 Nm

Fit the low pressure pipes as described in the relevant section. Fit the engine cable as described in the relevant section.




Remove the air filter as described in the relevant section Remove the oil vapour filter as described in the relevant sec-




- Tighten the double stem screws (5).
- Insert the gasket (6) into the relative seat.
- Insert the oil vapour condensation sector (4).
- Position the tappet cover (3) in the relative seat.
- Insert the elastic plugs and tighten the screws (1).


Ref.	No.	Screws description	Tightening torques
()	6	Nut M8×1.25	24 ± 4 Nm
(5)	6	Screw M8x1.25x17	24 ± 4 Nm

Fit the oil vapour filter as described in the relevant section. Fit the air filter as described in the relevant section






Check the coupling surfaces between the support and the shaft: there must be no sign of excessive wear or damage. Replace if necessary.



Before assembly, check the rocker arm rods: there must be no sign of any deformation; the spherical seats for contact with the rocker arm adjusting screw and with the tappets (arrows) must show no trace of seizure or wear; if they do, replace them.

Intake and exhaust valve push rods are identical and are therefore interchangeable.




Fit the air filter as described in the relevant section.

Fit the high pressure engine cable as described in the relevant section.

PROCEDURE FOR INJECTOR REMOVAL/REFITTING

Removal NEF67 TM1F engines

Remove the high pressure pipe as described in the relevant section.



Remove the injector exhaust pipe (4).

Unscrew the ring nut (2) and remove the injector (1).

Ref.	No.	Screws description
(2)	4	Ring nut M24×1.5
(3)	4	M6x1 union

Refitting

- Insert the injector (1) together with the ring nut (2) in the specific seat.
- Tighten the ring nut (2).
- Position the injector exhaust pipe (4) and tighten the fittings (3).

Ref.	No.	Screws description	Tightening torques
(2)	4	Ring nut M24x1.5	60 ± 5 Nm
(3)	4	M6x1 union	-

Connect the high pressure pipe as described in the relevant section.

Removal NEF67 TE1F/TE2F engines


Remove the high pressure pipe as described in the relevant section.

Remove the air filter as described in the relevant section.

Remove the oil vapour filter as described in the relevant section.

Remove the tappet cover as described in the relevant section.

Remove the rocker arm assembly as described in the relevant section.



Ref.	No.	Screws description
(1)	8	Screw M6x1x35
(6)	4	Nut M22x1.5

Refitting

- Insert the injector (3) together with the fastening bracket (4).
- Tighten the screws (1).
- Tighten the nuts (2) fixing the wiring on the injectors.
- Position the union (5).
- Tighten the nut (6) connecting the head.

Ref.	No.	Screws description	Tightening torques
()	8	Screw M6x1x35	
		l st phase 2 nd phase angle	3.5 ± 0.35 Nm 7.5 ± 2.5 Nm 25°+25°+25°
(6)	4	Nut M22×1.5	60 ± 5 Nm

Fit the rocker arm assembly as described in the relevant section.

Fit the tappet cover as described in the relevant section.

Fit the oil vapour filter as described in the relevant section.

Fit the air filter as described in the relevant section.

Connect the high pressure pipe as described in the relevant section.

PROCEDURE FOR FEED PUMP REMOVAL/REFITTING


Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns.

Place a container for the oil recovery.

Removal NEF67 TM1F engines

Remove the low pressure pipe as described in the relevant section.

Remove the high pressure pipe as described in the relevant section.




Once the starter motor is removed, fit tool 99360339 (1) to rotate the flywheel.

If it is necessary to replace the feed pump, this spare is supplied preset.

If however the pump needs to be disassembled and refitted without having undergone any repair interventions, reset it while it is still fitted on the engine and only then remove it.

The following procedure refers to the second possibility as this is the more complex one.


Identifying top dead centre with tool (99395097) - False injector



To search for the position of 1st cylinder at top dead, end of compression stroke, remove the rocker arm cover of the 1st cylinder, remove the 1st injector and position the tool (1). pre-load the dial gauge.


NOTE For the removal of the Ist injector and the tappet cover refer to the relevant section.

The required condition is obtained by turning the crankshaft appropriately until the maximum value appears on the dial gauge and making sure that the intake and exhaust valves are both closed.





Make sure that the non-drilled part (1) of the phonic wheel is positioned at the top along its vertical axis.

Figure 104




Rotate the flywheel until it pushes the pin 99360616 (1), this will not block the gear (2), obtaining the TDC of the 1^{st} cylinder.






Ref.	No.	Screws description
(1)	2	Screw M6x1
(3)	I	Nut MI4xI.5




- Suitably support the feed pump and unscrew the fastening nuts completely.
- Take the pump off the studs together with the gasket.

Ref.	No.	Screws description
(1)	3	Nut M8x1.25

NOTE Support the pump drive gear to prevent interference or sticking when the timing gears rotate.






Removal NEF67 TE1F/TE2F engines

Remove the engine cable as described in the relevant section.

Remove the low pressure pipe as described in the relevant section.

Remove the high pressure pipe as described in the relevant section.



- Loosen the nuts (3).
- Remove the supply pump assembly (1).
- Unscrew the studs (2).

Ref.	No.	Screws description	
(2)	3	Stud M8x1.25x5	
(3)	3	Nut M8x1.25	

Refitting

- Tighten the studs (2).
- Position the supply pump (1) in the relative seat.
- Tighten the nuts (3).

Ref.	No.	Screws description	Tightening torques
(2)	3	Stud M8x1.25x5	-
(3)	3	Nut M8x1.25	24 ± 4 Nm

Connect the high pressure pipe as described in the relevant section.

Connect the low pressure pipe as described in the relevant section.


Fit the engine cable as described in the relevant section.

PROCEDURE FOR PRIMING PUMP REMOVAL/REFITTING

Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns.


Place a container for the oil recovery.






To disconnect lower pressure fuel pipes from their couplings, press clip (1) as shown in figure B.


After removing the pipe, move the clip (1) to the locked position (Figure A) to prevent possible deformations.





To connect lower pressure fuel pipes from their couplings, press clip (1) as shown in figure B.

After removing the pipe, move the clip (I) to the locked position (Figure A).




Tighten the screws (3).

Ref.	No.	Screws description	Tightening torques
(3)	2	Screw M8x1.25x25	24 ± 4 Nm

PROCEDURE
ASSEMBLY REMOVAL/REFITTINGARMOnly proceed when the engine is not turning and is at low
temperature so as not to run the risk of burns.ARMPlace a container for the oil recovery.RemovalRemovalNEF67 TM1F enginesRemove the oil vapour filter as described in the relevant sec-

Remove the oil vapour filter as described in the relevant section.

Remove the tappet cover as described in the relevant section.




Disassemble the rocker arm mounts:


unscrew the fastening screws (1 and 2) and disassemble the mount together with the rocker arms; remove the push rods.

Repeat the operation for the remaining rocker arm mounts.

Ref.	No.	Screws description
(1)	4	Screw M8x1.25x75
(2)	4	Screw MI2xI.75xI80


Refitting






MAIN DATA FOR SHAFT-ROCKER ARMS

Check the coupling surfaces between the support and the shaft: there must be no sign of excessive wear or damage. Replace if necessary.




MAIN DATA FOR ROCKER ARM ADJUSTMENT SCREW

If disassembled, check the adjustment dimension. Tighten the nut (1) to a torque of 24 to ± 4 Nm.



Before assembly, check the rocker arm rods: there must be no sign of any deformation; the spherical seats for contact with the rocker arm adjusting screw and with the tappets (arrows) must show no trace of seizure or wear; if they do, replace them.

Intake and exhaust valve push rods are identical and are therefore interchangeable.



PROCEDURE FOR INTAKE MANIFOLD REMOVAL/REFITTING

Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns.


Place a container for the oil recovery.


Removal NEF67 TM1F engines

Remove the oil vapour filter as described in the relevant section.

Remove the tappet cover as described in the relevant section.


Remove the high pressure pipe as described in the relevant section.






To disconnect lower pressure fuel pipes from their couplings, press clip (1) as shown in figure B.

After removing the pipe, move the clip (1) to the locked position (Figure A) to prevent possible deformations.






- Unscrew the screws (1 and 4).
- Remove the intake manifold (3), together with the air pressure and temperature sensor (2).


Ref.	No.	Screws description
(1)	7	Screw M8x1.25x125
(4)	3	Screw M8x1.25x70

Refitting




- Place the intake manifold (3) in its seat, together with the air pressure and temperature sensor (2).
- Tighten the screws (1 and 4).

Ref.	No.	Screws description	Tightening torques
()	7	Screw M8x1.25x25	24 ± 4 Nm
(4)	3	Screw M8x1.25x70	24 ± 4 Nm



To connect lower pressure fuel pipes from their couplings, press clip (1) as shown in figure B.

After removing the pipe, move the clip (1) to the locked position (Figure A).



- Place the Common Rail (3) in its seat.
- Screw the threaded double stem screws (1).
- Fit the fuel return pipe (2) from the Common Rail (3).
- Position the radiator connection pipe (5) and tighten the screws (4).

Ref.	No.	Screws description	Tightening torques
()	3	Screw M8x1.25x25	35 ± 6 Nm
(4)	4	Screw M8x1.25x70	35 ± 6 Nm

Fit the high pressure pipes as described in the relevant section.

Fit the engine cable as described in the relevant section.

PROCEDURE FOR EXHAUST MANIFOLD REMOVAL/REFITTING

Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns.


Place a container for the oil recovery.

Removal NEF67 TM1F engines

Place a container for the oil recovery.

Remove the turbocharger as described in the relevant section.






- Remove the exhaust manifold (5).
- Recover the gaskets (3).


Ref.	No.	Screws description
(1)	4	Screw MI0x1.5x95
(2)	6	Screw MI0x1.5x65
(4)	4	Stud MI0x1.5x42
(7)	2	Screw MI0x1.5x65

Refitting

- Position the gaskets (3).
- Place the exhaust manifold (5) in the specific seat.
- Tighten the screws (1, 2 and 7) together with the spacers (6).
- Tighten the studs (4) for the turbocharger assembly.

Ref.	No.	Screws description	Tightening torques
(1)	4	Screw MI0x1.5x95	55 ± 3 Nm
(2)	6	Screw MI0x1.5x65	55 ± 3 Nm
(4)	4	Stud MI0x1.5x42	24 ± 4 Nm
(7)	2	Screw MI0x1.5x65	55 ± 3 Nm





PROCEDURE FOR CYLINDER HEAD REMOVAL/REFITTING

Only proceed when the engine is not turning and is at low temperature so as not to run the risk of burns.

Place a container for the oil recovery.

Removal NEF67 TM1F engine

Remove the protection grille as described in the relative procedure.

Remove the radiator as described in the relevant section.

Remove the fan as described in the relevant section.

Remove the belt as described in the relevant section.

Remove the turbocharger as described in the relevant section.

Remove the exhaust manifold as described in the relevant section.

Remove the low pressure pipe as described in the relevant section.

Remove the high pressure pipe as described in the relevant section.

Remove the fuel filter as described in the relevant section.

Remove the intake manifold as described in the relevant section.


Remove the air filter as described in the relevant section.

Remove the oil vapour filter as described in the relevant section.

Remove the tappet cover as described in the relevant section.

Remove the injectors as described in the relevant section.


Remove the rocker arm assembly as described in the relevant section.





Screw MI2xI.75x70

(2)

6







Position the automatic belt tensioner (2) and tighten the screws (1).

Ref.	No.	Screws description	Tightening torques
(1)	2	Screw M8x1.25x25	-
(4)	4	Screw M8x1.25x25	-

Fit the rocker arm assembly as described in the relevant section.

Fit the injectors as described in the relevant section.

Fit the tappet cover as described in the relevant section. Fit the oil vapour filter as described in the relevant section. Fit the air filter as described in the relevant section.

Fit the intake manifold as described in the relevant section. Fit the fuel filter as described in the relevant section.

Connect the high pressure pipe as described in the relevant section.

Connect the low pressure pipe as described in the relevant section.

Fit the exhaust manifold as described in the relevant section. Fit the turbocharger as described in the relevant section. Fit the belt as described in the relevant section.

Fit the fan as described in the relevant section.

Fit the radiator as described in the relevant section.

Fit the protection grille as described in the relative procedure.

Removal NEF67 TE1F/TE2F engine

Remove the protection grille as described in the relative procedure.

Remove the radiator as described in the relevant section.

Remove the fan as described in the relevant section.

Remove the engine cable as described in the relevant section.

Remove the belt as described in the relevant section.

Remove the turbocharger as described in the relevant section.

Remove the exhaust manifold as described in the relevant section.

Remove the low pressure pipe as described in the relevant section.

Remove the high pressure pipe as described in the relevant section.

Remove the intake manifold as described in the relevant section.

Remove the air filter as described in the relevant section.


Remove the oil vapour filter as described in the relevant section.

Remove the tappet cover as described in the relevant section.

Remove the injectors as described in the relevant section.


Remove the rocker arm assembly as described in the relevant section.


Ref.	No.	Screws description
(2)	4	Screw -
(5)	4	Screw MI0x1.5x110
(6)	2	Screw M8x1.25x30




	Recover	the	gasket	(3).
--	---------	-----	--------	------

Ref.	No.	Screws description
(1)	14	Screw MI2xI.75xI50
(4)	12	Screw MI2xI.75xI30







Fit the rocker arm assembly as described in the relevant section.

Fit the injectors as described in the relevant section.

Fit the tappet cover as described in the relevant section.

Fit the oil vapour filter as described in the relevant section.

Fit the air filter as described in the relevant section.

Fit the intake manifold as described in the relevant section. Connect the high pressure pipe as described in the relevant

Connect the low pressure pipe as described in the relevant section.

Fit the exhaust manifold as described in the relevant section.

Fit the turbocharger as described in the relevant section.

Fit the belt as described in the relevant section.

section.

Fit the engine cable as described in the relevant section.

Fit the fan as described in the relevant section.

Fit the radiator as described in the relevant section.

Fit the protection grille as described in the relative procedure.

General mechanical overhaul

		Page
MO	UNTING ON ROTATING STAND	5
	Removal of radiator assembly pipes from engine	5
	Protection grille removal	5
	Removing the radiator	6
	Fan removal	8
	Removal of components hindering bracket assembly	8
	Removal of turbocharger lubricant return pipes	8
	Removal of oil filter	9
	Removal of starter motor	9
	Mounting brackets on rotating stand	10
	Engine lubricant oil drainage	10
	Engine cable removal	
	Removal of components hindering bracket assembly	12
	Removal of fuel pipes	12
	Fuel filter removal	12
	Feed pump removal	12
	Mounting brackets on rotating stand	13
	Starter motor removal	13
	Oil discharge pump removal	13
	Engine lubricant oil drainage	14
	ASSEMBLY OF ENGINE AT BENCH COMPONENTS AT THE FRONT)	14
	Alternator removal	14
	Alternator mount removal	15
	Removal of water pump	15
	Removal of automatic belt tensioner and fan mount	15
	Removal of crankshaft pulley	16

2	SECTION 6 - GENERAL MECHANICAL OVERHAUL	
		Page
	ASSEMBLY OF ENGINE AT BENCH COMPONENTS ON THE LEFT SIDE)	16
	Air filter removal	16
	ASSEMBLY OF ENGINE AT BENCH COMPONENTS ON THE LEFT SIDE)	17
	Turbocharger removal	17
	Removal of heat exchanger	17
	Exhaust manifold removal	18
	Thermostat unit removal	18
	ASSEMBLY OF ENGINE AT BENCH COMPONENTS ON UPPER SIDE)	19
	Removal of oil vapour filter	19
	Tappet cover removal	19
	High pressure fuel pipe removal	19
	ASSEMBLY OF ENGINE AT BENCH COMPONENTS ON RIGHT SIDE)	20
	Low pressure fuel pipe removal	20
	Removal of fuel filter and priming pump	21
	Rocker assembly removal	22
	Intake manifold removal	22
	Injector removal	22
	Cylinder head unit removal	22
	ASSEMBLY OF ENGINE AT BENCH COMPONENTS ON THE LEFT SIDE)	23
	Exhaust manifold removal	23
	Extension kit removal	23

DISASSEMBLY OF ENGINE AT BENCH (COMPONENTS ON UPPER SIDE)

Removal of oil vapour filter

Common Rail removal

Intake manifold removal

Tappet cover removal

Rocker assembly removal

24

24

24

25

25

25

	Electro-injector removal	26
	Thermostat unit removal	26
	Cylinder head unit removal	27
	ASSEMBLY OF ENGINE AT BENCH COMPONENTS ON RIGHT SIDE)	27
	Electronic Control Unit Removal	27
	Oil level dipstick removal	28
	ASSEMBLY OF ENGINE AT BENCH COMPONENTS AT THE BOTTOM)	28
	Oil sump removal	28
	ASSEMBLY OF ENGINE AT BENCH COMPONENTS ON RIGHT SIDE)	29
	Injection pump removal	29
	Suction strainer removal	29
DIS. (ASSEMBLY OF ENGINE AT BENCH COMPONENTS AT THE REAR)	31
	Removal of engine flywheel	31
	Removal of flywheel cover housing sealing ring	31
	Removal of flywheel housing	33
	Removal of timing gear	33
	Timing gear case removal	33
DIS. (ASSEMBLY OF ENGINE AT BENCH COMPONENTS AT THE REAR)	34
	Removal of engine flywheel	34
	ASSEMBLY OF ENGINE AT BENCH COMPONENTS AT THE FRONT)	34
	Removal of crankshaft pulley	34
	Removal of flywheel cover housing sealing ring	35
	Removal of flywheel housing	35
	Removal of timing gear	35
	Removal of timing gear case	36
	ASSEMBLY OF ENGINE AT BENCH COMPONENTS AT THE FRONT)	36
	Removing the engine - front cover sealing ring	36

NEF 67 SERIES

Page

		Page
	Removal of front cover	37
	Oil pump removal	37
	ASSEMBLY OF ENGINE AT BENCH COMPONENTS AT THE BOTTOM)	37
	Piston-connecting rod unit removal	37
	Removal of crankshaft	38
	ASSEMBLY OF ENGINE AT BENCH COMPONENTS AT THE REAR)	39
	Camshaft removal	39
	Camshaft bushing removal	39
	Tappet removal	39
CH	ECKS	40
	Cylinder block	40
	Checking cylinder block head contact surface	41
	Timing system	42
	Measuring main journals and connecting rod .	47
	Connecting rod and piston assembly	56
	Valve unit removal	58
	Removal of the second lifting eyelet	59
	Valve unit removal	61
	Lifting eyelet removal	61
	Cylinder head assembly fitting	65
	Refitting of valve seats	65
	Refitting valve assembly	65
	Lifting eyelet refitting	66
	Refitting valve assembly	66
	GINE ASSEMBLY AT BENCH CRANKCASE COMPONENTS)	67
	Refitting tappets	67
	Refitting camshaft	67
	Refit the oil sprayers and main half bearings	67

		Page
	Crankshaft refitting	68
	Pisting-connecting rod refitting	68
	Connecting rod caps refitting	70
	Piston protrusion check	71
ASS (SEMBLY OF ENGINE AT BENCH COMPONENTS AT THE FRONT)	71
	Oil pump refitting	71
	Removing the front cover sealing ring	71
	Refitting front cover	72
	Refitting the engine - front cover sealing ring .	72
	SEMBLY OF ENGINE AT BENCH COMPONENTS AT THE REAR)	73
	Timing gear case refitting	73
	Camshaft gear refitting	74
	Refitting engine flywheel housing	75
	Refitting flywheel cover housing sealing ring	76
	Refitting engine flywheel	76
ASS (SEMBLY OF ENGINE AT BENCH COMPONENTS AT THE FRONT)	77
	Crankshaft pulley refitting	77
	SEMBLY OF ENGINE AT BENCH COMPONENTS AT THE REAR)	78
	Timing gear case refitting	78
	Camshaft gear refitting	79
	Injection pump refitting	81
	Refitting engine flywheel housing	81
	Refitting engine flywheel	82
E	DCEDURE FOR MOUNTING THE ''ADC100'' ELECTRONIC ACTUATOR ON STANADYNE 'D'' INJECTION PUMPS''	SERIES 84
E	DCEDURE FOR MOUNTING THE "ADC100" ELECTRONIC ACTUATOR ON STANADYNE SERIES "D" INJECTION PUMPS"	86
REF	PLACING ELECTROSTOP AND COLD ADVAN	NCE 89

4	SECTION 6 - GENERAL MECHANICAL OVERHAUL
	SEMBLY OF ENGINE AT BENCH (COMPONENTS AT THE BOTTOM)
	Sound-proofing plate and suction strainer refitting
	Oil sump refitting
	SEMBLY OF ENGINE AT BENCH COMPONENTS ON RIGHT SIDE)
	Oil level dipstick refitting
	Electronic Control Unit Refitting
	SEMBLY OF ENGINE AT BENCH COMPONENTS AT THE TOP)
	Cylinder head assembly refitting
	Thermostat unit refitting
	Refitting electro-injectors
	Refitting rocker assembly
	Refitting tappet covers
	Refitting intake manifold

ASSEMBLY OF ENGINE AT BENCH

VASSEMBLY OF ENGINE AT BENCH

ASSEMBLY OF ENGINE AT BENCH

(COMPONENTS AT THE REAR)

Oil vapour filter refitting

Extension kit refitting

Refitting exhaust manifold;

(COMPONENTS ON THE LEFT SIDE)

(COMPONENTS AT THE FRONT)

Cylinder head assembly refitting

Injector refitting

Refitting intake manifold

Refitting rocker assembly

Setting rocker free play

Preliminary operations

101

101

102

102

102

103

103

104

105

105

107

107

108

		Tage
	Refitting of fuel filter and priming pump	109
	Refitting low pressure pipes	109
	Refitting high pressure pipes	110
	Refitting tappet covers	111
	Oil vapour filter refitting	112
	EMBLY OF ENGINE AT BENCH COMPONENTS ON THE LEFT SIDE)	112
	Refitting heat exchanger	112
	Refitting exhaust manifold;	112
	Turbocharger refitting	113
	EMBLY OF ENGINE AT BENCH COMPONENTS AT THE REAR)	113
	Air filter refitting	113
ASS (EMBLY OF ENGINE AT BENCH COMPONENTS AT THE FRONT)	4
	Crankshaft pulley refitting	114
	Refitting of automatic belt tensioner and fan mount	114
	Refitting water pump	115
	Refitting alternator support	115
	Refitting alternator	115
	Engine completion	116
	Oil discharge pump refitting	116
	Supply pump refitting	116
	Fuel filter refitting	117
	Refitting engine cable	118
	Engine completion	119
	Refitting starter motor	119
	Refitting oil filter	120
	Refitting lubricant oil return pipe from turbocharger	120
	Fan refitting	120
	Refitting radiator assembly	121
	Drin≁ D4F	032NI009 F

Page

 $\widehat{\mathbb{O}}$

5


129287

L

Ø

B

129288



Print	P4D32N009	F


(3)


Screw M8x1.25x16

Screw M8x1.25

(2)

4







(5)

Τ


Screw M7x1




Remo	oval of o	oil filter
Figu	ire 12	NEF67 TM1F engine
II NE	F67 TEIF	-/TE2F engine Page 10
to the s wing w From th	itand 993 ay. he right si h tool 992 oport. Attentio of engin	and dispose of the engine oil according to
Ref.	No.	Screws description
(1)		Cartridge M27x2



Ref.	No.	Screws description	Tightening torques
()	3	MI2xI.75	43 ± 6 Nm
(2)	3	Nut MI0x1.5	-
(4)	3	Stud MI0x1.5x20	-




NEF 67 SERIES The oil sump contains approximately 7.65 kg of **∕** engine oil. Collect and dispose of the engine oil according to applicable laws. Ref. No. Screws description Plug M18x1.5 (|)Figure 16 NEF67 TE1F/TE2F engine $\langle \rangle$ 7 8 6 5 214307 II NEF67 TM1F engine Page 14 From the right hand: Disconnect the fuel pre-filter (2) from all connection pipes. Unscrew the screws (1) and the relative nuts. Remove the fuel pre-filter (2). Remove the clamp (4) for supporting the pipe (7) in low pressure. Unscrew the screws (5), remove the quick-fit couplings (3) and remove the low pressure pipe (7). Connect the bracket 99361037 (6) by inserting the screws (8) into the threaded holes. Ref. No. Screws description Tightening torques 2 Screw M20x1.5 (|)(5)Screw M20x1.5 4 Screw MI2xI.75 43 ± 6 Nm (8)



I. Connections for electro-injectors - 2. Engine coolant temperature sensor - 3. Fuel pressure sensor cable - 4. Engine oil temperature and pressure sensor - 5. Crankshaft sensor - 6. EDC control unit 7 - 7. Pressure regulator cable - 8. Fuel heater and fuel temperature sensor cable - 9. Timing phase sensor - 10. Air temperature and pressure sensor - 11. Electro-injector.

Disconnect the engine cable from the connectors: (1) injector wiring; (10) air pressure/temperature sensor; (3) fuel pressure sensor; (6) control unit; (9) timing gear phase sensor; (2) engine coolant temperature sensor on thermostat; (5) engine rpm sensor.

Remove the clamps that hold it to the crankcase and remove it completely.





Ref.	No.	Screws description		
(2)	2	Screw MI2xI.75		
(3)		Cartridge M20x1.5		
(6)		Sensor MI4x1.5		
Figure 20				
 Unscrew the unions (1). Unscrew the screws (3). Remove the Rail supply high pressure pipe (2). 				
Ref.	No.	Screws description		

Ref.	No.	Screws description	
(1)	2	Connector M14x1.5	
(3)	2	Screw M6x1x12	

Feed pump removal


(3)





Ref.	No.	Screws description	Tightening torques
()	4	Screw MI2x1.75	24 ± 4 Nm
(3)	3	Nut MI0x1.5	-
(4)	3	Stud MI0xI.5x20	-

Oil discharge pump removal



- Unscrew the screw (1) and remove the oil discharge pump (3).
- Undo the discharge valve (2) and drain the oil.

Ref.	No.	Screws description
(1)	l	Screw M8x1.25x40
(2)	_	Valve M22x1,5




Avoid skin contact with the engine oil: in case of contact, wash thoroughly with water.

The engine oil is highly pollutant: it must be disposed of according to applicable laws.


2


T)

202147




202148





Ref.	No.	Screws description
(2)	I	Screw MI0x1.5
(5)	6	Screw MI2xI.25x78.5
(6)	6	Screw MI0x1.25x40


DISASSEMBLY OF ENGINE AT BENCH (COMPONENTS ON THE LEFT SIDE) Àir filter removal Figure 33 NEF67 TE1F/TE2F engine L WITH THE 2 214313 II NEF67 TM1F engine Page 17 Unscrew the screws (4) and remove the air filter (1) from its support. Unscrew the screws (2) together with the relative nuts and remove the fan mount (3). Ref. No. Screws description 2 Screw M8x1.25x100 (2)





Screw M8x1.25x100

2

(4)








Prior to removing the cylinder head, fit the bracket into the original position and fasten it with the screws of the thermostat body


Screw M6x1

(5)

3




High pressure fuel pipe removal



Unscrew the bracket (3) fastening screws (4).


Ref.	No.	Screws description
(1)	10	Screw M8x1.25
(4)	2	Screw M8x1.25x16





202163

Unscrew the fittings (1) connecting to the injectors (2).

Ref.	No.	Screws description
(1)	6	Nut MI4xI.5








 \Box Extract the 10 smooth bushings [h = 11 mm] (4).

Ref.	No.	Screws description
()	7	Screw M8x1.25x25




(2)	6	Ring nut M24x1.5

Screws description

Cylinder head unit removal

No.

Ref.





Using tool 99360595 via the lifting eyelets (5), remove the cylinder head (3) together with all the elements relating to the timing:


- Intake valves;
- Exhaust valve;
- Valve springs;
- Plates;
- Cotters.
- Recover the gasket (4).

Recover the cable reference dowel pins between the cylinder head assembly and the crankcase.

Ref.	No.	Screws description
(1)	6	Screw MI2xI.75x70
(2)	14	Screw MI2xI.75xI40









Ref.	No.	Screws description
(1)	8	Nut MI4xI.5
(3)	3	Screw M8x1.25x125

NOTE In unlocking the fittings securing the pipes to the rail, it is necessary to use a special wrench to prevent possible rotation of the flow limiters.








Unscrew the double stem screws (5).


Ref.	No.	Screws description
(1)	4	Nut M8x1.25
(3)	I	Plug M38x3
(5)	4	Screw M8x1.25x17

Rocker assembly removal




- Unscrew the screws (2).
- Loosen the nuts (1) on the electro-injectors.
- Remove the connectors (3) on the electro-injectors.


Ref.	No.	Screws description
(1)	12	M4 nut
(2)	3	Screw M6x1x16




- Unscrew the screws (2 and 5).
- Remove the housing (3) and the rocker arm control rods
 (4) together with the housing seats and the balls.

Ref.	No.	Screws description
(1)	12	Screw M8x1.25x55
(2)	2	Screw M8x1.25x50
(5)	5	Screw M8x1.25x70






DISASSEMBLY OF ENGINE AT BENCH (COMPONENTS ON RIGHT SIDE) Electronic Control Unit Removal




- Unscrew the screws (3 and 6).
- Unscrew the nut (4) and the corresponding stud (5).
- \Box Remove the control unit (2).
- Unscrew the Voss fitting (7).
- \Box Remove the support (1).

Ref.	No.	Screws description
(3)	7	Screw M6x1x30
(4)		Nut M6x1
(5)		Stud M6x1x25
(6)	3	Screw M8x1.25x45
(7)		Connector MI2xI.25


4





Ref.	No.	Screws description
(1)	4	Screw MI0x1.5
(2)	2	Screw M8x1.25x20
(8)	I	Screw M8x1.25x45

DISASSEMBLY OF ENGINE AT BENCH (COMPONENTS ON RIGHT SIDE) Injection pump removal




IF NEF67 TETF/TE2F engine Page 34


Fit the tool 99360339 (1) in the starter motor seat to turn the flywheel.

If it is necessary to replace the feed pump, this spare is supplied preset.

If however the pump needs to be disassembled and refitted without having undergone any repair interventions, preset it while it is still fitted on the engine and only then remove it.


The following procedure refers to the second possibility as this is the more complex one.







To search for the position of Ist cylinder at top dead, end of compression stroke, remove the rocker arm cover of the Ist cylinder, remove the Ist injector and position the tool (99395097 (1). Pre-load the dial gauge 99395604.

The required condition is obtained by turning the crankshaft appropriately until the maximum value appears on the dial gauge and making sure that the intake and exhaust valves are both closed.







Rotate the flywheel until it pushes the pin 99360616 (1), this will not block the gear (2), obtaining the TDC of the 1^{st} cylinder.



- Partially unscrew the screw (1) locking the pump spindle and move the spacer with the slot (2) to the largest part of the hole to allow the screw to fit in completely.
- Apply a torque of between 11.9 and 12.4 Nm to tighten the locking screw (1) flush with the spacer locking the pump spindle rotation.






NOTE Support the pump drive gear to prevent interference or sticking when the timing gears rotate.

Ref.	No.	Screws description
(1)	3	Stud M8x1.25
(4)	2	Screw M5x0.8
(6)	3	Nut M8x1.25

Check correct setting of rotating feed pump






1. Slot on hydraulic rotor hub - 2. Synchronisation pin 99365196 - 3. Plate.

The synchronisation pin 99365196(2) has been designed for use in the event that the rotor shaft has been accidentally released.

The correct pump/engine synchronisation is obtained when synchronisation pin 99365196(2), inserted into the hole in the plate (3), engages in the slot (1) on the outside of the hydraulic rotor hub.


Therefore:

- Remove the screw plug (3) at the centre of the plate.
- □ Insert synchronisation pin (1) 99365196 into the hole in the plate (3). The synchronized position is obtained when the synchronisation pin (2) is inserted in the slot on the hydraulic rotor hub.
- Lock the drive shaft in the correct position using the screw (1, Figure 82).
- Remove the synchronisation pin and fit the screw plug of the plate (3). Tighten the plug to a torque of 2.3 ÷ 3.4 Nm.





Γ	Ref.	No.	Screws description
	(2)	6	Screw M8x1.25

Timing gear case removal




Ref.	No.	Screws description
(1)	4	Screw M8x1.25x40
(2)	5	Screw MI0x1.5x30
(3)	I	Screw MI2xI.75x30





Removal of flywheel housing





- Unscrew the screws (1, 2, 3 and 4).
- Remove the flywheel housing (5).


Ref.	No.	Screws description
(1)	2	Screw M12x1.75
(2)	2	Screw MI0x1.5
(3)	10	Screw MI0x1.5
(4)	6	Screw MI2x1.75


NOTE Note the assembly position of the screws since they are of different sizes.


Removal of timing gear
















Screw M8x1.25x10


4



Tappet removal



Withdraw the tappets (1) from the crankcase.



Once the engine is disassembled, thoroughly clean the cylinder-crankcase assembly.

Use the proper rings to handle the cylinder block.


Carefully inspect the crankcase for cracks.

Check the condition of casting hole plugs. If the caps are rusted, or if there is any doubt about the efficiency of the seal, replace them.

Inspect the surfaces of the cylinder liners; they should not be scored, seized, ovalised, conical or worn to excess.


The internal diameter of the cylinder liners is checked to ascertain the extent of ovalization, taper and wear, using the bore meter (1) fitted with a dial gauge previously reset on the ring gauge (2) of the diameter of the cylinder liner.


NOTE Should the ring gauge be not available, use a micrometer for zero-setting.





Measurements shall be performed on each cylinder, at three different heights in the bore and on two planes perpendicular with each other: one parallel to the longitudinal axis of the engine (A) and the other perpendicular to it (B); the greatest wear is usually found to be on this surface and during the first measurement.


Should ovalization, taper or wear be found, bore and grind the cylinders. The refacing of the cylinder liners should be made in relation to the diameter of the pistons supplied as spare parts, which are oversized by 0.4 - 0.8 mm of the nominal value and to the prescribed assembly clearance.













Place the plate (1) retaining the camshaft (3) with the slot facing the top side of the crankcase and the marking facing you, tighten the screws (2).


Ref.	No.	Screws description	Tightening torques
(2)	2	Screw M8x1.25x16	24 ± 4 Nm




Check the axial clearance of the camshaft (1). It must be 0.23 ± 0.13 mm.



Lubricate the camshaft support bushing and fit the camshaft (1) taking care not to damage the shaft support seats or bushing during this operation.







To replace bushing (1), use driver 99360362 (2) and handgrip 99370006 (3) for dismounting and mounting the bushing.

The gear bushings shown in Figure 126 can be replaced when worn. After driving the bushing, proceed to bore it to obtain the diameter indicated in Figure 126.


- **NOTE** The hammering of the bushing into the gear must be carried out in the direction of the arrow by placing it at the point indicated inFigure 126.
- **NOTE** During assembly, the bushing (1) must be oriented so that the lubrication holes match with the ones on the seats of the crankcase.


Rated assembling play between gear bushings and pins: 0.038 \div 0.152 mm






MAIN JOURNAL ON T SYSTEM DRIVE SID	IMING DE	INTERMEDIATE MAIN JOURNALS	FIRST MAIN JOURNAL ON FRONT SIDE
	45	2x45°-+	45° 45° 45° 45° 1
TOLERANCES	CHARACTE	RISTIC SUBJECT OF TOLERANCE	GRAPHIC SYMBOL
	C'and a site		
SHAPE	Circularity		0
SHAPE	Cylindricity		/0/
	Cylindricity Alignment		/\)/ //
SHAPE	Cylindricity Alignment Perpendicularity		/0/
ORIENTATION	Cylindricity Alignment Perpendicularity Straightness	oaxiality	/O/ //
ORIENTATION POSITION	Cylindricity Alignment Perpendicularity Straightness Concentricity or co		/\)/ // ()
ORIENTATION	Cylindricity Alignment Perpendicularity Straightness		/O/ //
ORIENTATION POSITION OSCILLATION	Cylindricity Alignment Perpendicularity Straightness Concentricity or co Circular oscillation Total oscillation		/ () / //
ORIENTATION POSITION OSCILLATION CLASS OF IMPORT,	Cylindricity Alignment Perpendicularity Straightness Concentricity or co Circular oscillation Total oscillation		
ORIENTATION POSITION OSCILLATION CLASS OF IMPORT,	Cylindricity Alignment Perpendicularity Straightness Concentricity or co Circular oscillation Total oscillation		/○/ // ⊥ @ @ GRAPHIC SYMBOL @
ORIENTATION POSITION OSCILLATION CLASS OF IMPORT,	Cylindricity Alignment Perpendicularity Straightness Concentricity or co Circular oscillation Total oscillation		
ORIENTATION POSITION OSCILLATION CLASS OF IMPORT,	Cylindricity Alignment Perpendicularity Straightness Concentricity or co Circular oscillation Total oscillation		/○/ // ⊥ @ @ GRAPHIC SYMBOL @











The clearance control of the shoulder is carried out by placing a dial gauge (2) to the magnetic base on the crankshaft (3) as shown in the figure, the normal mounting clearance is $0.068 \div 0.410$ mm.


If a greater clearance is found, replace the main half bearings of the second last rear support (1) carrying the thrust bearings and repeat the clearance check between the main half bearings and crankshaft pins.













Measuring the diameter of the gudgeon pin (1) with a micrometer (2).

Conditions for correct pin-piston coupling





Lubricate the pin (1) and the relevant housing on the piston hubs with engine oil; Pin must be inserted in the piston with a light finger pressure and it should not come out by gravity.



Using a micrometer (2), measure the piston diameter (1) to determine the assembly clearance; The diameter has to be detected at the value indicated in figure.


Print P4D32N009 E






5

61696



Check the torsion of the connecting rod (5) by comparing two points (**A** and **B**) of the pin (3) on the horizontal plane of the axis of the connecting rod.

Position the dial gauge (2) support (1) to obtain a preload of ~ 0.5 mm on the pin (3) in point A and then set the dial gauge (2) to zero. Move the spindle (4) with the connecting rod (5) and compare any deviation on the opposite side **B** of the pin (3): the difference between A and B must be no greater than 0.08 mm.




Bending check

Check the bending of the connecting rod (5) by comparing two points C and D of the pin (3) on the vertical plane of the axis of the connecting rod.

Position the vertical support (1) of the dial gauge (2) so that it rests on the pin (3) at point C. Swing the connecting rod forward and backward to find the highest position of the pin and when that is reached, reset the dial gauge (2).

Move the spindle (4) with the connecting rod (5) and repeat on the opposite side D, controlling the highest point of the pin (3). The difference between point C and point D should not be greater than 0.08 mm.





Box "I": month and year of registration;


Box "N": engine variant to be completed according to engine records (last three digits of the theoretical code);

Box "P": Serial number to be assigned in the manufacturing plant;


For the remaining data to be entered onto the plate, refer to the engine details of P.N. 504257007 (file in D.B. Matrix)








Intake and exhaust valves










Valve descale, check and grind

Remove all carbon deposits from the valves using a wire brush. Check that the valves show no signs of seizing, cracks or burns.

Regrind the valve seats, if required, removing as little material as possible.








 \Box Unscrew the screws (1) and remove the lifting eyelet (2).

Ref.	No.	Screws description
(1)	2	Screw MI2x1.75x25
(5)	4	Screw MI2xI.25x25

Surfaces on lower side of cylinder head


Distortion found along the whole cylinder head shall not exceed 0.20 mm.


If measurement results exceed this value, regrind the cylinder head according to the values and instructions provided in the figure below.




The rated thickness A for the cylinder head is 95 ± 0.25 mm, max. metal removal must not exceed thickness B by 0.13 mm.

NOTE After regrinding, check the valve recessing and if necessary regrind the valve seats to meet the prescribed valve recess.






Use a bore gauge, measure the internal diameter of the valve guides; it must be equal to the value shown in the figure.



Regrinding - replacing the valve seats

Check the valve seats (2). If light scratches or burns are found, go over the surface with a suitable tool (1) according to the slope values given in Figure 183.



NEF67 TE1F/TE2F engine

641

49.02

38.20


H2


75758

Height		Under a load of
mm		Ν
H (free)	47.75	0
HI	35.53	339.8 ± 19
H2	25.2	741 ± 39


gauge 99395603 (1).


After regrinding, check that valve (3) recessing value is the specified one by using the stand 99370415 (2) and the dial








Ref.	No.	Screws description	Tightening torques
(1)		Plug	
(2)		Plug	
(4)		Plug	
(5)		Plug 1/2''	




















Ref.	No.	Screws description	Tightening torques
(2)	4	Screw M8x1.25	
		I st step	8 ± 1 Nm
		2 nd step	24 ± 4 Nm


Removing the front cover sealing ring



218549








NOTE Before each assembly operation, check that the thread on the holes and the screws shows no sign of wear or dirt.

Screw MI0x1.5

(5)

2

47 ± 5 Nm



()|3

Õ

10

3 \bigcirc

70215

Ì

2

3

4 202485

Tightening torques

85 ± 10 Nm

49 ± 5 Nm

49 ± 5 Nm

85 ± 10 Nm

ŝ

Ø അ


 $\overline{\bigcirc}$

С 5


12


Ø

ŝ



Base - March 2014





စ်

3

С

2

10

8 Ô

5

75711


1.0

2

3

202192

0



Tightening torques

 24 ± 4 Nm

47 ± 5 Nm

77 ± 12 Nm







Figure 234


☐ Align the crankshaft (2) and the camshaft (4) so that when the driven gear (1) is mounted onto the latter, the sign stamped on the gear (1) coincides with the bevel gear tooth (3).




Set the dial gauge 99395604 (1) on the timing gear (2) and check that the clearance between the gears (2) and (3) is between 0.076 and 0.280 mm.











Perfect seal is only obtained by cleaning accurately the surface to seal.


Smear the case with LOCTITE 5999 to obtain a bead of few mm diameter.


Application must be uniform (no lumps), without any air bubbles, thin areas or gaps.


Any flaws must be corrected in as short a time as possible.

Avoid using too much material to seal the joint. Excessive sealant could come out from joint sides and cause lubricant passage clogging.


The joints must be assembled within 10 minutes after applying the sealant.








Apply the tool 99360339 (1) to the flywheel housing to stop the rotation of the flywheel (3), using an adjustable wrench on the nut (2) and a pin (4).





Tighten the screws (2) securing the engine flywheel (1).


Ref.	No.	Screws description	Tightening torques
(2)	8	Screw M12x1.25x30	50 ± 5 Nm
		l st phase 2 nd phase	60°

NOTE Before each assembly operation, check that the thread on the holes and the screws shows no sign of wear or dirt.









NOTE The idling speed adjustment screw (4) does not allow achievement of the minimum in the "classic" sense of the term, as the injection pump regulator imposes a higher rotation speed since it is the injection pump for the generator unit.

Switching from 60 Hz to 50 Hz

To switch from a speed of 60 Hz to a speed of 50 Hz, operate similarly to what was seen above, remembering to turn the adjustment screw for the droopsetting (2, Figure 253), rotating it 3 turns counterclockwise from the position in which it is located for operation at 60 Hz.

Stabilisation of rotation speed

In case of instability of the engine rotation speed, turn the adjustment screw for the droopsetting (2, Figure 253) slightly rotating it clockwise/counterclockwise until the rotation speed of the engine is stabilised.

Identification plate


Figure 254



116976


If you do not find the FPT plate because it is an engine with the injection pump calibrated at 50 Hz, it is necessary to apply the plate to the area shown as in SENZA CODICE stamping it as shown in the figure.


Blank identification plates can be ordered through our Spare Parts Service.




116977

If the FPT plate is already present on the injection pump, mark the new identification suffix for the new calibration and cancel the identification of the previous calibration, as shown in the figure.








In the electrostop **ETR** kit there is the joint tool (1) which must be used to position the electrostop arm (2) correctly and to reassemble the cover on the injection pump.

NOTE This tool (1) allows to keep the arm of the electrostop (2) in the excitation position, allowing the correct assembling of the cover and avoiding dangerous overrevving when the engine is started.


Once the cover is put on the assembling seat and the relative screws are pointed on the injection pump, rotate the joint tool (1) and then pull it carefully from underneath the cover (3), making sure not to move or damage the gasket of the cover.

Proceed then to the closing of the screws, with a torque of $4.0 \div 5.1$ Nm, being careful not damage the connecting element to ground of the electrostop terminal.




The placement of the cover (2) should be carried out in the reverse order to what is described about the disassembly, taking care that it fits perfectly on the mounting seat, without forcing (obviously for the ETR variant the pump cover will fit on the mounting seat only after the removal of the retaining tool).


NOTE A blue seal is included in the kit which has to be positioned on the screw (1), after the cover reassembling operations (2): when new, the seal is not blue.



If replacing the electrostop originally supplied and changing the characteristics (different voltage, ETR rather than ETSO, etc.), you must apply a plate (1) identifying the area indicated.


The plate must be stamped (1) as shown in detail in the figure.






Ref.	No.	Screws description	Tightening torques
(1)	4	Screw MI0x1.55	43 ± 5 Nm
(2)	2	Screw M8x1.25x20	24 ± 4 Nm
(8)		M8x1.25x45	24 ± 4 Nm

Oil sump refitting




Ref.	No.	Screws description	Tightening torques
()	10	Screw M8x1.25x20	24 ± 4 Nm
(2)	4	Screw M8x1.25x45	24 ± 4 Nm



Ref.	No.	Screws description	Tightening torques
(2)	2	Plug M14x1.5	10 ± 2 Nm
(6)	2	Plug MT0x1	10 ± 2 Nm
(7)	2	Screw M8x1.25,20	65 ± 10 Nm

Electronic Control Unit Refitting



Position the support (1).


Tighten the Voss fitting (7).

Position the control unit (2) in its seat.


Tighten the stud (5) and the corresponding nut (4).


Tighten the screws (3 and 6).


Ref.	No.	Screws description	Tightening torques
(3)	7	Screw M6x1x30	10 ± 2 Nm
(4)		Nut M6x1	10 ± 2 Nm
(5)		Stud M6x1x25	10 ± 2 Nm
(6)	3	Screw M8x1.25x45	24 ± 4 Nm
(7)		Connector MI2xI.25	12 ± 2 Nm





- Position the cover (8), together with the gasket, and tighten the screws (7).
- \Box Insert the oil level dipstick (5).
- Tighten the plugs (2 and 6).
- Insert the core plugs (1, 3 and 4).


















L	1.01.	110.	bei ettis deseription	ingricering conques
	()	6	Screw M8x1.25x25	24 ± 4 Nm
	(2)		Screw M6x1x20	10 ± 2 Nm
	(4)	6	Screw M6x1x20	10 ± 2 Nm
	(8)		Screw M8x1.25x70	24 ± 4 Nm

Common Rail Refitting




Ref.	No.	Screws description	Tightening torques
()		Screw M6x1	10 ± 2 Nm
(2)	2	Coupling M12x1.5x11	20 ± 2 Nm


Position the pipe (3) and the threaded fittings (2).

Tighten the support screw (1) to the clamp.


Insert the engine breather pipe (4).


ع C 202471




















<u>FIRING ORDER: | - 5 - 3 - 6 - 2 - 4</u>

Start and rotation crankshaft	Rocker arm clea- rance adjustment intake and exhaust valves - cylinder n°
Cyl. no.1 at TDC	
Turn 120°	5
Turn 120°	3
Turn 120°	6
Turn 120°	2
Turn 120°	4





ASSEMBLY OF ENGINE AT BENCH (COMPONENTS ON RIGHT SIDE)




Tighten the water temperature sensor (4).

Connect all the electrical connections to the feed pump.


Connect the connections (1) to the water temperature sensor (4).

Connect the connections to the contactor (2).


Ref.	No.	Screws description	Tightening torques
(3)		Sensor MI0x1	28 ± 2 Nm
(4)		Sensor 1/2 x14"	28 ± 2 Nm



F	Ref.	No.	Screws description	Tightening torques
	()	2	Plug ½''-14 0.610	36 ± 6 Nm
	(2)		Plug	14 ± 2 Nm
	(3)	2	Plug MT0x1	24 ± 4 Nm
	(6)		Plug M18x1.5	35 ± 4 Nm




Refitting low pressure pipes



To connect lower pressure fuel pipes from their couplings, press clip (1) as shown in figure B.


After removing the pipe, move the clip (I) to the locked position (Figure A).





Position the exhaust pipes (1) from the injectors (2).


Connect the 6 threaded fittings (3) passing through the injectors (2).

Ref.	No.	Screws description	Tightening torques
(3)	6	Nut M6x1x10	80 ± 8 Nm











SECTION 6 - GENERAL MECHANICAL OVERHAUL **Turbocharger refitting** Figure 338 L 4 3 214314 Insert the new gasket on the exhaust manifold. Position the turbocharger (4) and tighten the nuts (3). Tighten the fittings (1) of the oil delivery pipe (2) to the turbocharger (4).

Ref.	No.	Screws description	Tightening torques
(1)	2	Connector MI0xI.25	36 ± 5 Nm
(3)	4	Nut M8x1.25	24 ± 4 Nm

ASSEMBLY OF ENGINE AT BENCH (COMPONENTS AT THE REAR) **Àir filter refitting**






2nd step

Screw MI0x1.25x40

90°


 24 ± 4 Nm



Insert the crankshaft rpm sensor (4) and tighten the screw (1).

Ref.	No.	Screws description	Tightening torques
()		Screw M6x1x20	24 ± 4 Nm
(2)		Screw	-

Refitting of automatic belt tensioner and fan mount





- Position the fan mount (2) in the relative seat and tighten the screws (6).
- Position the spacer (4) in its seat, together with the drive pulley (3) and tighten the screws (5).
- Position the belt tensioner mount (9) in the relative seat and tighten the screws (1).
- Position the automatic belt tensioner (8) in the relative seat and tighten the screw (7).

Ref.	No.	Screws description	Tightening torques
(1)	2	Screw M8x1.25x30	43 ± 6 Nm
(5)	4	Screw MI0xI.5xII0	43 ± 6 Nm
(6)	4	Screw	43 ± 6 Nm
(7)		Screw MI0x1.5x70	43 ± 6 Nm

6


(6)





- Position the alternator in its seat, together with the bracket (2).
- Position but do not tighten the screw (3) anchoring the alternator to its lower mount and the screw (1).

Ref.	No.	Screws description	Tightening torques
()		Screw MI0x1.5	-
(3)		Screw MI0x1.5	-




- 202147
- Use the tool (5) to turn the automatic tensioner (1) in the direction of the arrow and put on the belt (2).
- ☐ Tighten the screw (4) securing the alternator to the bracket and the screw (3) securing the alternator to the lower mount.

Ref.	No.	Screws description	Tightening torques
(3)		Screw MI0x1.5	43 ± 6 Nm
(4)		Screw MI0x1.5	43 ± 6 Nm
(4)	l	Nut MI0x1.5	43 ± 6 Nm

(6)

MI0x1.5x70

43 ± 6 Nm




Position the oil discharge pump (3) and tighten the screw (1).


Ref.	No.	Screws description	Tightening torques
(1)		Screw M8x1.25x40	24 ± 4 Nm
(2)	I	Valve M22x1,5	60 ± 9 Nm

Engine completion

To complete the engine assembly operations, remove the rotating stand.




Ref.	No.	Screws description	Tightening torques
()	3	Nut M10x1.5	43 ± 6 Nm
(2)	4	Screw MI2x1.75	-
(4)	3	Stud MI0xI.5x20	43 ± 6 Nm




- (2).
- Tighten the nut (3).


Ref.	No.	Screws description	Tightening torques
(3)		Nut M18x15	105 ± 5 Nm

Supply pump refitting



Ref.	No.	Screws description	Tightening torques
(2)	3	Stud M8x1.25x5	24 ± 4 Nm
(3)	3	Nut M8x1.25	24 ± 4 Nm







I. Connections for electro-injectors - 2. Engine coolant temperature sensor - 3. Fuel pressure sensor cable - 4. Engine oil temperature and pressure sensor - 5. Crankshaft sensor - 6. EDC control unit 7 - 7. Pressure regulator cable - 8. Fuel heater and fuel temperature sensor cable - 9. Timing phase sensor - 10. Air temperature and pressure sensor - 11. Electro-injector.

Connect the engine cable from the connectors: electro-injector wiring (1); (10) air pressure/temperature sensor; (3) fuel pressure sensor; (6) control unit; (9) timing gear phase sensor; (2) engine coolant temperature sensor on thermostat; (5) engine rpm sensor.

Insert the clamps that hold it to the crankcase.




After removing the pipe, move the clip (1) to the locked position (Figure A).



Screw MI2x1.75

Engine completion

To complete the engine assembly operations, remove the rotating stand.




□ NEF45 TETF/TE2F engine Page 120

From the left side:

- Lift the engine with arm 99360595 and remove it from the rotating stand 99322205.
- Unscrew the screws (1) and remove the bracket 99361037 (2).

Ref.	No.	Screws description	Tightening torques
()	3	Screw MI2xI.75	-


Refitting starter motor




R	ef.	No.	Screws description	Tightening torques
(I)	4	Screw MI2xI.75	-
(2	2)	3	Nut MI0xI.5	43 ± 6 Nm
(4	4)	3	Stud M10x1.5x20	43 ± 6 Nm

(8)


4






Ref.	No.	Screws description	Tightening torques
(2)		Screw M7x1	13 ± 2 Nm









- Fit the pipe (4) complete with sleeves, from the engine side, acting on the relative clamps (5).
- Fit the pipe (2) complete with sleeves, from the engine side, acting on the relative clamps (3).
- Fit the pipe (1) complete with sleeves, from the engine side, acting on the relative clamps (6).

Ref.	No.	Screws description	Tightening torques
(3)	2	Screw M6x1x16	43 ± 6 Nm
(5)	2	Screw M8x1.25x16	43 ± 6 Nm
(6)	2	Screw M6x1x16	43 ± 6 Nm

NOTE Check the state of wear of the rubber sleeves.





SECTION 7

Technical specifications

	Page	
	0	

TIGHTENING TORQUES (NEF67 TM1F) 9

TIGHTENING TORQUES (NEF67 TE1F/TE2F) .

OATA - INSTALLATI	ON CLEARANC	ES		
	Туре		(NEF67 TMIF)	NEF67 TE1F/TE2F
CYLINDER ASSEMBLY AN	ID CRANK GEARS		n	าท
	Cylinder liners	>Ø		÷ 104.024).4
	Pistons Measuring point Outer diameter Seat for pin	X Ø I Ø 2	55.9 103.714 ÷ 103.732 38.010 ÷ 38.016	49.5 103.739 ÷ 103.757 38.010 ÷ 38.016
	Piston - cylinder lir	ners	0.268 ÷ 0.310	0.243 ÷ 0.285
昌 >	Piston diameter	ØI	C).4
X	Piston position from crankcase	×	0.28	÷ 0.52
Ø 3	Piston pin	Ø 3	37.994	÷ 38.000
	Piston pin - pin sea	at	0.010	÷ 0.022

	Туре	(NEF67 TM1F)	NEF67 TE1F/TE2F
	D CRANK GEARS	m	lm
	XI Circlip slots X 2 X 3	2.705 ÷ 2.735 2.440 ÷ 2.460 4.030 ÷ 4.050	2.705 ÷ 2.735 2.420 ÷ 2.440 4.030 ÷ 4.050
$\square \blacksquare \blacksquare$	Circlips S I S 2 S 3	2.350 -	÷ 2.605 ÷ 2.380 ÷ 3.990
	Circlips - slots 2 3	0.100 ÷ 0.175 0.060 ÷ 0.110 0.040 ÷ 0.080	0.100 ÷ 0.175 0.040 ÷ 0.09 0.040 ÷ 0.080
昌 >	Piston rings	C	.4
$\int_{x_3}^{x_1} \left\{ \begin{array}{c} x \\ x \\ x \\ x \end{array} \right\}$	Piston ring end gap in cylinder liner: X I X 2 X 3	0.60	÷ 0.40 ÷ 0.80 ÷ 0.55
	Connecting rod small end bush seat Ø 1 Connecting rod bearings seat Ø 2		÷ 41.013 ÷ 73.013
	Connecting rod small end bush diameter Internal 실(Ø 3 Connecting rod half-bearings S		÷ 38.033 ÷ 1.968
	Piston pin - bushing	0.019 -	÷ 0.039
直 >	Connecting rod half-bearings	0.250	; 0.500

	Туре		(NEF67 TMIF)	NEF67 TE1F/TE2F
	ND CRANK GEARS		m	m
×	Measuring point Maximum error on parallelism of connec axles	ting rod	-	
	Main journals Crankpins	Ø 1 Ø 2	82.99 - 68.987 -	
SI S ²	Main half-bearings Connecting rod half-bearings	S I S 2	2.456 ÷ 1.955 ÷	
Ø 3	Main journals No. 1-7 No. 2-3-4-5-6	Ø3 Ø 3	87.982 - 87.977 -	
	Half-bearings - Main jou No. 1-7 No. 2-3-4-5-6 Half bearings - crankpins	umals	0.058 ÷ 0.038 ÷	
≜ >	Main half-bearings Connecting rod half-b	earings	0.250;	0.500
	Thrust main journal	XI	37.475 ÷ 37.550	37.475 ÷ 37.545
× 2	Main journal support for thrust	X 2	32.180 :	- 32.280
×3	Thrust half rings	Х 3	37.28 -	- 37.38
	Crankshaft thrust		0.095 ÷ 0.270	0.095 ÷ 0.265

	Туре		(NEF67 TMIF)	NEF67 TE1F/TE2F
LINDER HEAD - TIMING	SYSTEM		m	 m
	Valve guide seats on cylinder head	ØI	8.019 ÷ 8.039	7.042 ÷ 7.062
$\bigotimes^{\bigotimes 2}$	Valve guide	Ø 2 Ø 3	-	-
	Valves:	$\bigotimes 4$ α $\bigotimes 4$	7.960 ÷ 7.980 60°± 0° 7' 30'' 7.960 ÷ 7.980	6.990 ÷ 7.01 60°± 0° 7' 30'' 6.990 ÷ 7.01
	Valve stem and related	α	45°± 0° 10'	
	Housing on head for valve seat:	ØI	46.987 ÷ 47.013 43.637 ÷ 43.663	34.837 ÷ 34.863 34.837 ÷ 34.863
	Valve seat outside d valve housing inclina cylinder head:		47.063 ÷ 47.089 60°± 0.5° 43.713 ÷ 43.739 45°± 0.5°	34.917 ÷ 34.931 60°± 0° 7' 30'' 34.917 ÷ 34.931 45°± 0.5°
×	X Recessing X		1.000 ÷ 1.520 1.000 ÷ 1.520	0.390 ÷ 0.910 0.760 ÷ 1.280
<i>5</i>	Between valve seat and cylinder head		0.050 ÷ 0.102 0.050 ÷ 0.102	0.054 ÷ 0.094 0.054 ÷ 0.094
昌 >	Valve seats			-

	Туре		(NEF67 TMIF)	NEF67 TE1F/TE2F
CYLINDER HEAD - TIMING	SYSTEM			mm
	Valve spring height:			
$\overline{\mathbb{Q}}$	free spring	н	63.50	47.75
	under a load of: 329 N 641 N	HI H2	49.02 38.20	
	339.8 ± 19 N 741 ± 39 N	HI H2		35.33 25.2
×	Injector protrusion	×	lt canno	t be adjusted
	Seat for camshaft bush timing system No. I (flywheel side)	iings	59.222	2 ÷ 59.248
	Camshaft seats n° 2-3-4-5-6-7		54.089) ÷ 54.139
	Camshaft journal diameter: I ⇒ 7		53.995	5 ÷ 54.045
Ø	Outer diameter of bus	hings Ø		-
Ø	Inner diameter of bushings	Ø	54.083	3÷ 54.147
	Bushings and supportir	ng pins	0.038	3 ÷ 0.152

	Туре		(NEF67 TMIF)	NEF67 TE1F/TE2F
LINDER HEAD - TIMI	NG SYSTEM		m	່ າm
	Useful cam height:			
Н		н		-
		Н		-
Ø	Tappet washer seat in crankcase	ØI	16.000	÷ 16.030
	Tappet outside diame	eter: Ø 2 Ø 3	5.929 ÷ 5.959 5.965 ÷ 5.980	5.924 ÷ 5.954 5.960 ÷ 5.975
	Between tappets and	seats		-
昌 >	Tappets			-
	Rocker-arm shaft	ØI	8.963 ÷ 8.975	21.965 ÷ 21.977
Ø 2	Rocker arms	Ø 2	9.000 ÷ 9.026	22.001 ÷ 22.027
	Between rockers and	shaft	0.025 ÷ 0.063	0.024 ÷ 0.062

TIGHTENING TORQUES (NEF67 TMIF)

DETAIL				TORQUE	
		40	Quantity	Nm	Kgm
Cooling nozzles		48	6	15 ± 3	1.5 ± 0.3
Screws for camshaft shoulder plate	M8×1	25	2	24 ± 4	2.4 ± 0.4
Screws for main bearing caps	MI2xI.75		14	80 ± 6 90	8.0 ± 0.6 ° C
Screw for timing gear case	MI2x1.75			77 ± 12	7.7 ± 1.2
Screws for timing gear case	M8×1.25		4	24 ± 4	2.4 ± 0.4
Screws for timing gear case	MI0x	1.5	5	47 ± 5	4.7 ± 0.5
Screws for timing gear	M8×1.25		6	36 ± 2	3.6 ± 0.2
Screws for connecting rod caps	MI0xI	25	12	60 ± 5	6.0 ± 0.5 0°
Nut for injection pump gear	MI4x	15		90 ± 5	9.0 ± 0.5
Nuts for securing injection pump	M8x1		3	90 ± 3 24 ± 4	9.0 ± 0.3 2.4 ± 0.4
Plug for heat exchanger valve	M22x			24 ± 4 80 ± 8	2.4 ± 0.4 8.0 ± 0.8
Screws securing heat exchanger	M8x1.		15	26 ± 4	0.0 ± 0.8 2.6 ± 0.4
ociews securing near excilanger	1.10X1	23	U U	20 ± 4 60 ± 5	2.6 ± 0.4 6.0 ± 0.5
		L = 70			6.0 ± 0.5) °
Screws securing cylinder head	MI2xI.75 L = 140		26	40 ± 5	4.0 ± 0.5 + 90°)
					,
		L = 180		70 ± 5	7.0 ± 0.5
<u> </u>	N40 - I	25	,	· · ·	+ 90°)
Screws securing rocker arms	M8×1		6	24 ± 3	2.4 ± 0.3
Nuts for tappet adjuster	M8×1.25		12	24 ± 4	2.4 ± 0.4
Screws securing tappet cover	M8×1		6	24 ± 4	2.4 ± 0.4
Screws for sound-proofing plate	MIOx		14	43 ± 5	4.3 ± 0.5
Screws securing suction strainer	M8×1		2	24 ± 4	2.4 ± 0.4
Screws securing suction strainer bracket	MIOx	1.5	2	43 ± 5	4.3 ± 0.5
Screws fixing the oil pump	M8×1	25	4	8 ± 1 24 ± 4	0.8 ± 0.1
Screws securing front cover	M8×1	25	13	24 ± 4 24 ± 4	2.4 ± 0.4 2.4 ± 0.4
Screws securing flywheel housing	MI2xI		8	85 ± 10	8.5 ± 1.0
Screws securing flywheel housing	MIOx		12	49 ± 5	4.9 ± 0.5
Screws securing oil sump	M8×1		18	24 ± 4	2.4 ± 0.4
Plug on oil sump	MI8x			65 ± 10	6.5 ± 1.0
				50 ± 5	5.0 ± 0.5
Screws securing front hub	MI2xI		6)°
Screws for pulley on front hub	MIOXI		6	68 ± 7	6.8 ± 0.7
Plugs on cylinder head		/2"	3	24 ± 4	2.4 ± 0.4
Plugs on cylinder head		3/4**	2	36 ± 5	3.6 ± 0.5
Plug on cylinder head		/4''		12 ± 2	1.2 ± 0.2
Ring nut securing injectors	M24x		6	60 ± 5	6.0 ± 0.5
Screws securing intake manifold	M8×1	25	8	24 ± 4	2.4 ± 0.4
Screws securing sling hook	MI2xI	.75	2	77 ± 12	7.7 ± 1.2
Screws securing sling hook	M8×1	25	4	36 ± 5	3.6 ± 0.5

			TORQUE	
DETAIL		Quantity	Nm	Kgm
Screws securing alternator	M10x1.5	3	43 ± 6	4.3 ± 0.6
Nut for compressor gear control	M18x1.5 lh	I	165 ± 10	6.5 ± .0
Nut securing compressor	MI2x1.75	2	77 ± 12	7.7 ± 1.2
Screws securing compressor support bracket	M8×1.25	4	24 ± 4	2.4 ± 0.4
Screws securing thermostat cover	M6x1	3	10 ± 2	1.0 ± 0.2
Nuts securing starter motor	M10x1.5	3	43 ± 6	4.3 ± 0.6
Nuts securing turbocharger	M10x1.5	4	43 ± 6	4.3 ± 0.6
Screws securing exhaust manifold	M10x1.5	8	55 ± 3	5.5 ± 0.3
Screws for alternator mount	M10x1.5	3	43 ± 6	4.3 ± 0.6
Screws for oil pressure sensor	M6x1	2	10 ± 2	1.0 ± 0.2
Plugs to crankcase	M18x1.5	3	24 ± 4	2.4 ± 0.4
Screws for plate 4896952	M6x1	2	24 ± 4	2.4 ± 0.4
Screws for water pump	M8×1.25	2	24 ± 4	2.4 ± 0.4
Screws for power steering pump	MI0x1.5	2	43 ± 6	4.3 ± 0.6
Fitting for turbocharger oil delivery pipe	MI6	2	36 ± 5	3.6 ± 0.5
Screws for turbocharger oil drain pipe	M8×1.25	2	24 ± 4	2.4 ± 0.4
Oil level sensor	MI2xI.5		10 ± 2	1.0 ± 0.2
Screws securing oil level dipstick bracket	M8×1.25	2	24 ± 4	2.4 ± 0.4
Screw for oil dipstick fastening clamp	M6x1		10 ± 2	1.0 ± 0.2
Oil filter	M27x2		20 ± 2	2.0 ± 0.2
Screw for crankshaft speed sensor	M6x1		10 ± 2	1.0 ± 0.2
Screws for fuel filter bracket	MI2×1.75	2	80 ± 8	8.0 ± 0.8
Intake elbow clam	M7x1		13 ± 2	I.3 ± 0.2
Screws for exhaust elbow bracket	M8×1.25	4	24 ± 4	2.4 ± 0.4
Screw for belt tensioner	MI0x1.5		43 ± 6	4.3 ± 0.6
Screw for idler pulley 4898548	M10x1.5		43 ± 6	4.3 ± 0.6
Screw for idler pulley 4892356	M10×1.5	I	43 ± 6	4.3 ± 0.6
Flywheel screws	M12×1.25	8	50 ± 5 6	5.0 ± 0.5 0°
Plug	MIOxI		24 ± 4	2.4 ± 0.4


TIGHTENING TORQUES (NEF67 TEIF/TE2F)

			TORQUE		
DETAIL		Quantity	Nm	Kgm	
Cooling nozzles	M8	6	15 ± 3	1.5 ± 0.3	
Screws for camshaft shoulder plate	M8x1.25	2	24 ± 4	2.4 ± 0.4	
Screws for main bearing caps	MI2×1.75	14	80 ± 6 90	8.0 ± 0.6	
Screw for timing gear case	MI2xI.75		77 ± 12	7.7 ± 1.2	
Screws for timing gear case	M8x1.25	4	24 ± 4	2.4 ± 0.4	
Screws for timing gear case	M10x1.5	5	47 ± 5	4.7 ± 0.5	
Screws for timing gear	M8x1.25	6	36 ± 2	3.6 ± 0.2	
Screws for connecting rod caps	M10x1.25	12	50 ± 5	5.0 ± 0.5 0°	
Nut for injection pump gear	M18x1.5				
Nuts for securing injection pump	M8×1.25	3	24 ± 4	2.4 ± 0.4	
Plug for heat exchanger valve	M22×1.5		80 ± 8	8.0 ± 0.8	
Screws securing heat exchanger	M8×1.25	15	26 ± 4	2.6 ± 0.4	
L = 130			35 ± 5 (90° -	3.5 ± 0.5 + 90°)	
Screws securing cylinder head	MI2×1.75	26 0	55 ± 5	5.5 ± 0.5	
Screws securing rocker arms	M8x1.25	2	$(90 - 36 \pm 5)$	+ 90°) 3.6 ± 0.5	
Nuts for tappet adjuster	M8x1.25	2	24 ± 4	2.4 ± 0.4	
Housing securing screws	M8x1.25	5	24 ± 4	2.4 ± 0.4	
Nuts securing tappet cover	MI0x1.5	6	21 ± 1 24 ± 4	2.1 ± 0.1 2.4 ± 0.4	
Screws for sound-proofing plate	MI0x1.5	4	43 ± 5	4.3 ± 0.5	
Nuts fixing wiring on injectors	M4	12	1.5 ± 0.25	0.2 ± 0.03	
Screws securing suction strainer	M8×1.5	2	24 ± 4	2.4 ± 0.4	
Screws securing suction strainer bracket	MI0x1.5	2	43 ± 5	4.3 ± 0.5	
Screws fixing the oil pump	M8x1.25	4	8 ± 1	0.8 ± 0.1	
			24 ± 4	2.4 ± 0.4	
Screws securing front cover	M8x1.25	13	24 ± 4	2.4 ± 0.4	
Screws securing flywheel housing	MI2xI.75	8	85 ± 10	8.5 ± 1.0	
Screws securing flywheel housing	M10x1.5	12	49 ± 5	4.9 ± 0.5	
Screws securing oil sump	M8×1.25	18	24 ± 4	2.4 ± 0.4	
Plug on oil sump	M18x1.5		60 ± 9	6.0 ± 0.9	
Screws securing front hub	M12×1.25	6	50 ± 5 90	5.0 ± 0.5	
Screws for pulley on front hub	MI0x1.25	6	68 ± 7	6.8 ± 0.7	
Plugs on cylinder head	1/2"	3	24 ± 4	2.4 ± 0.4	
Plugs on cylinder head	3/4''	2	36 ± 5	3.6 ± 0.5	
Plug on cylinder head	1/4 ''		2 ± 2	1.2 ± 0.2	
<u> </u>			3.5 ± 0.35	0.4 ± 0.04	
Injector retaining screws	M6x1	12	7,5 ± 0,35	0.8 ± 0.04 5° + 25°	
Connectors on cylinder head	M22x1.5	6	25 + 2	5 + 25 5.5 ± 0.5	
Screws securing intake manifold	M8x1.25	10	55 ± 5 24 ± 4	5.5 ± 0.5 2.4 ± 0.4	
Screws securing sling hook	MI2x1.75	2	77 ± 12	7.7 ± 1.2	
JULEWS SECULING SILLY HOOK	TTTZX1./J	Ĺ	// <u>L</u> Z	/./ ± I.Z	

DETAIL			TORQUE	
		Quantity	Nm	Kgm
Screws securing sling hook	M8×1.25	4	36 ± 5	3.6 ± 0.5
Screws securing rail to intake manifold	M8×1.25	4	36 ± 5	3.6 ± 0.5
Screws securing alternator	M10x1.5	3	43 ± 6	4.3 ± 0.6
Nut for compressor gear control	M18x1.5 lh		65 ± 0	16.5 ± 1.0
Nut securing compressor	MI2xI.75	2	77 ± 12	7.7 ± 1.2
Screws securing compressor support bracket	M8×1.25	4	24 ± 4	2.4 ± 0.4
Screws securing thermostat cover	M6x1	3	10 ± 2	1.0 ± 0.2
Nuts securing starter motor	M10x1.5	3	43 ± 6	4.3 ± 0.6
Nuts securing turbocharger	M10x1.5	4	43 ± 6	4.3 ± 0.6
Screws securing exhaust manifold	M10x1.5	12	53 ± 5	5.3 ± 0.5
Screws for alternator mount	M10x1.5	3	43 ± 6	4.3 ± 0.6
Screws for oil pressure sensor	M6x1	2	10 ± 2	1.0 ± 0.2
Plugs to crankcase	M18x1.5	3	24 ± 4	2.4 ± 0.4
High pressure pipe fittings	M14x1.5	2	24 ± 4	2.4 ± 0.4
Rail pipe bracket screw	M10x1.5		40 ± 5	4.0 ± 0.5
Fittings 4896491 and 4897881	M16x1.5	4	24 ± 4	2.4 ± 0.4
Screws for plate 4896952	M6x1	2	24 ± 4	2.4 ± 0.4
Screws for water pump	M8×1.25	2	24 ± 4	2.4 ± 0.4
Screw for camshaft rpm sensor	M6x1		10 ± 2	1.0 ± 0.2
Screws for power steering pump	M10x1.5	2	43 ± 6	4.3 ± 0.6
Sensor on cylinder heads (temperature)	M14x1.5		24 ± 4	2.4 ± 0.4
Union 4891285	3⁄4" - 14		36 ± 4	3.6 ± 0.4
Screws for turbocharger oil drain pipe	M8×1.25	2	10 ± 2	1.0 ± 0.2
Breather plate screws	M6x1	3	10 ± 2	1.0 ± 0.2
Plate screw fixing breather on tappet cover	M6x1	3	10 ± 2	1.0 ± 0.2
Fittings securing breather 4899219	MI2xI.5	3	20 ± 4	2.0 ± 0.4
Oil level sensor	MI2xI.5		10 ± 2	1.0 ± 0.2
Screws securing oil level dipstick bracket	M8×1.25	2	24 ± 4	2.4 ± 0.4
Screw for oil dipstick fastening clamp	M6x1		10 ± 2	1.0 ± 0.2
Voss fitting 4896329 on cylinder head	MI2xI.5		22 ± 2	2.2 ± 0.2
Oil filter	M27x2		20 ± 2	2.0 ± 0.2
Screw for crankshaft speed sensor	M6x1		10 ± 2	1.0 ± 0.2
Screws for fuel filter bracket	MI2xI.75	2	80 ± 8	8.0 ± 0.8
Intake elbow clam	M7x1		13 ± 2	1.3 ± 0.2
Screws for exhaust elbow bracket	M8×1.25	4	36 ± 5	3.6 ± 0.5
Plugs securing the control unit	M8×1.25	3	24 ± 4	2.4 ± 0.4
Screw for belt tensioner 4898548	M10x1.5		43 ± 6	4.3 ± 0.6
Screw for idler pulley 4897031	M10x1.5		43 ± 6	4.3 ± 0.6
Screw for idler pulley 4892356	M10x1.5		43 ± 6	4.3 ± 0.6
		0	30 ± 4	3.0 ± 0.4
Flywheel screws	M12×1.25	8	60	C°
Plug 4899009	MI0x1		24 ± 4	2.4 ± 0.4
Screws securing control unit to support	M6x1	8	10 ± 2	1.0 ± 0.2
Nuts securing heater	M8×1.25	8	13 ± 3	I.3 ± 0.3
Voss fitting 4896542 on control unit supp.	MI2xI.25		12 ± 2	1.2 ± 0.2
Screws securing sensor on intake manifold.	M6x1	2	10 ± 2	1.0 ± 0.2

SECTION 8 Tools	
	Page
EQUIPMENT	3

EQUIPMENT				
TOOL No.	Ь. ""	NAME	F4GE	F4HE
99305453		Tool for checking diesel fuel system and com- mon rail injection system		\checkmark
99317915		Set of five 9x12 spintite wrenches (14 - 15 - 17 - 18 - 19)		\checkmark
99322205		Revolving stand for overhauling units (capacity 1000 daN, torque 120 daNm)	~	~
99340035		Extractor for engine injection pump gear	\checkmark	
99340055		Extraction tool for crankshaft front ring seal	\checkmark	\checkmark
99340056		Extraction tool for crankshaft rear gasket	~	\checkmark



TOOL No.		NAME	F4GE	F4HE
99346253		Key to fit crankshaft rear gasket	\checkmark	\checkmark
99360076		Tool to remove oil filter (engine)	\checkmark	\checkmark
99360183		Tool for piston ring removal and assembly (65-110mm)	\checkmark	\checkmark
99360221		Engine flywheel rotation tool (use with 99360222)		\checkmark
99360222) Pinion (use with 99360221)		\checkmark
99360268	Constant of the second se	Tool to take down and fit back engine valves	\checkmark	\checkmark

99360339 Image: Coupling for compression control in cylinders (use with 99395682) Image: Coupling for compression control in cylinders (use with 99395682) 99360351 Image: Coupling for compression control in cylinders (use with 99395682) Image: Coupling for compression control in cylinders 99360351 Image: Coupling for compression control in cylinders Image: Coupling for compression control in cylinders 99360351 Image: Coupling for compression control in cylinders Image: Coupling for compression control in cylinders 99360362 Image: Coupling for compression control in cylinders Image: Coupling for compression control in cylinders 99360362 Image: Coupling for compression control in cylinders Image: Coupling for compression control in cylinders 99360500 Image: Coupling for compression control in cylinders Image: Coupling for compression control in cylinders 99360500 Image: Coupling for compression control in cylinders Image: Coupling for compression control in cylinders 99360500 Image: Coupling for compression control in cylinders Image: Coupling for compression control in cylinders 99360500 Image: Coupling for compression control in cylinders Image: Coupling for compression control in cylinders 99360500 Image: Coupling for compression control in cylinders Image: Coupling for compression control in cylinders	TOOL No.	NAME	F4GE	F4HE
99360351 Image: Constraint of the second	99360339	Tool to retain and rotate engine flywheel	\checkmark	
99360362 Image: Constraint of the second	99360344	Coupling for compression control in cylinders (use with 99395682)	\checkmark	
99360500 Tool for lifting the crankshaft	99360351	Tool to retain flywheel	\checkmark	\checkmark
99360500 Tool for lifting the crankshaft	99360362	Drift tool for removing/fitting camshaft bushings (to be used with 99370006)	\checkmark	\checkmark
99360595 Arm for removing and refitting engine	99360500	Tool for lifting the crankshaft	\checkmark	\checkmark
	99360595	Arm for removing and refitting engine	\checkmark	\checkmark

TOOL No.		NAME	F4GE	F4HE
99360605		Clamp for fitting piston into cylinder liners (60 ÷ 125 mm)	\checkmark	~
99360616		Tool for engine T.D.C. positioning	\checkmark	
99361037		Brackets for fastening engine to 99322205 rotary stand	\checkmark	\checkmark
99363204	Jest to the second	Tool to remove gaskets	\checkmark	\checkmark
99365196		Tool for positioning injection pump at delivery start	\checkmark	
99367121		Manual pump for measuring pressure and vacuum	~	~

TOOL No.		NAME	F4GE	F4HE
99370006		Handgrip for interchangeable drift tools	\checkmark	\checkmark
99370415		Base of dial gauge for various measurements (use with 99395603)	\checkmark	\checkmark
99389829	C. C. C.	9x12 coupling torque wrench (5-60 Nm)		\checkmark
99389834		Torque screwdriver for connector retention nut adjustment injector solenoid valve (1- 6 Nm)		\checkmark
99395097		Tool for top dead centre control (use with 99395604)	\checkmark	
99395216		Pair of gauges for angular tightening with 1/2" and 3/4" square heads	\checkmark	\checkmark
			1	I

TOOL No.	NAME	F4GE	F4HE
99395603	Dial gauge (0 ÷ 5 mm)	~	\checkmark
99395604	Comparator gauge (0 ÷ 10 mm)	\checkmark	
99395682	Diesel engine cylinder compression test device	\checkmark	
		1	

Page

Appendix

SAFETY REGULATIONS	 3

We direct your attention on some precautions that must be necessarily followed in a regular work environment and, in case of non-compliance, any other precaution will not be sufficient to protect the safety of the staff in charge of maintenance.

- Please obtain information and inform the staff on applicable laws on safety, making the informative material available for consultation.
- Please keep the rooms as clean as possible and properly ventilated.
- Equip the rooms with specific, well-visible first-aid boxes, always stocked up with suitable medical aids.
- Be equipped with suitable fire extinguishing devices, properly signalled and never obstructed. Check their operation on a regular basis and train the staff on the intervention priorities and methods.
- Arrange meeting points for the evacuation of premises, signalling suitable escape routes.
- Absolutely prohibit smoking in the areas where the works subject to fire hazard are carried out.
- Draw the attention on prohibitions and indications with suitable signs, which are immediately comprehensible always in case of emergency.

Accident prevention

- Do not wear cloths with loose edges, rings and chains, while working near engines and moving organs.
- Use protective gloves and glasses when:
 - refuelling inhibitors or antifreeze;
 - replacing or refuelling lubricant oil;
 - using air or liquids under pressure (allowed pressure ≤ 2 bar).
- Wear a protective helmet if working in an area with suspended loads or overhead systems.
- Always wear safety shoes and cloths fitted to the body, better if equipped with rubber bands at the edges.
- Use protective creams for hands.
- Change wet clothes as soon as possible.
- In the presence of voltage higher than 48-60V, check the effectiveness of the ground electric connections. Make sure your hands and feet are dry and perform the work standing on insulating platforms. Do not proceed if not qualified!
- Do not smoke or spark free flames near batteries and any combustible material.
- Return oily rags or solvents to fire-proof containers.

- Do not perform operations without the necessary instructions.
- Do not use equipment to perform works other than those for which they have been designed, you may sustain accidents, even of serious type.
- □ In case of checks or calibrations that require the engine to be on, make sure that the room is properly ventilated and use proper fans to remove exhaust gases: intoxication and death hazard.

During maintenance

- □ Never open the filling cap of the cooling circuit when the engine is hot. The operating pressure will spill the high temperature liquid with serious risk of burns. Wait until the temperature drops below 50 °C.
- Never add coolant to an overheated engine and only use appropriate fluids.
- Always operate with engine off: if special circumstances require maintenance with the engine running, consider all risks these operations entail.
- Use adequate and safe containers for draining the engine fluids and exhaust oil.
- Keep the engine clean from oil, diesel and/or chemical solvents.
- ☐ The use of solvents or detergents during maintenance may develop toxic vapours. Always ventilate the work rooms. Use safety masks when required.
- Do not leave cloths soaked with flammable substances near the engine.
- When starting up the engine after a repair operation, arrange for suitable measures to stop air suction in case of over-revving.
- $\hfill\square$ Do not use quick screwers.
- Do not disconnect the batteries whilst the engine is running.
- Before any interventions involving the electrical circuits, disconnect the batteries.
- Disconnect the batteries from the on-board network while charging.
- After each intervention, make sure the polarity of the battery's terminals is respected and the latter are well tightened and protected against accidental short circuits and oxidation phenomena.
- Do not disconnect and connect the electric connections when power is on.
- Before carrying out removal operations on pipes (pneumatic, hydraulic or fuel pipes) check the possible presence of fluid or air under pressure. Adopt the necessary precautions, exhausting the residual pressures or closing the shut-off valves. Always wear suitable masks or protective glasses. Failure to follow these rules may cause serious accidents and intoxication.

4 APPENDIX

		_	
	Avoid improper tightening operations or out of torque. The engine's components may be damaged also seriou-	Pr	rotection of the environment
_	sly, thus prejudicing their life cycle.		Allows prioritise protection of the environment imple- menting all necessary precautions to protect the safety
	Avoid draughts from fuel tanks in copper alloy and/or pipes without filters.		and health of staff.
	Do not apply changes to the cabling, their length must not be modified.		Make sure you and all staff are fully aware of current stan- dards for the treatment and disposal of fluids and engine oils. Set up adequate signage and specific courses to
	Do not connect any utility to the engine's electric equip- ment, if not specifically approved by FPT.		ensure a full understanding of the rules and the basic pre- vention measures.
	Do not modify the fuel or hydraulic systems without authorisation from FPT. Any unforeseen change will void the warranty and may prejudice the engine's duration and life cycle.		Collect used oil in a suitable, airtight container and ensure storage environments that are properly marked, ventilated, away from heat sources and free of fire hazards.
For	engines equipped with electronic units:		Handle batteries with care in well ventilated areas and
	Do not carry out any arch welding without previously removing the electronic units.		in antacid containers. Beware of fumes coming from the batteries: they may pose a serious risk of poisoning and contamination of the environment.
	Remove the electronic control units in case of interven- tions in which the temperatures will exceed 80 °C.		
	Do not paint the electronic components and connections.		
	Do not modify or alter the data contained in the engine management electronic control unit. Any manipulation or alteration of the electronic components will totally void the engine's service guarantee and may prejudice the engine's duration and life cycle.		